

ServoOne junior

Operation Manual

Servocontroller

BG2 to BG5
2.0 A – 16 A





Sizes

BG2

BG3

BG4

BG5

ServoOne junior Operation Manual

ID no.: 1300.20B.6-00

Date: 03/2020

Applicable as from firmware version: V1.25-01

The German version is the original of this operation manual.

ServoOne junior high-performance drives

The modularity of the ServoOne junior guarantees you optimum integration into the machine process. Whether in high-speed field bus communication with the central multi-axis machine controller or with distributed programmable Motion Control intelligence in the drive controller, the ServoOne junior is a master of both.

Subject to technical change without notice.

This operation manual has been prepared based on DIN EN 82079-1. The content was compiled with the greatest care and attention based on the latest information available to us.

We should nevertheless point out that this document cannot always be updated simultaneously with the on-going technical development of our products.

Information and specifications may be subject to change at any time. For information on the latest version, please visit www.keba-lti.com.

Table of contents

1	General	5	3	Mechanical installation	13
1.1	Target group	5	3.1	Notes for operation	13
1.2	Prerequisites	5	3.2	Wall mounting	13
1.3	Reference documents	5	3.2.1	Dimensions of the devices	14
1.4	Order code	6	3.2.2	Mounting clearances	15
1.5	Data on manufacture	7	4	Electrical installation	17
1.6	Scope of supply	7	4.1	Notes for installation	17
1.7	Pictograms	7	4.2	Overview of the connections	18
1.8	Disclaimer	7	4.3	Connection diagram, BG2 to BG4	20
1.9	Disposal	7	4.4	Connection diagram, BG5	21
1.10	Support	8	4.5	Effective EMC installation	22
2	Safety	9	4.5.1	Interference immunity of drive controllers	22
2.1	Overview	9	4.5.2	Specimen setup	22
2.2	Measures for your safety	9	4.6	Protective earth conductor connection	26
2.3	General safety instructions and warnings	10	4.7	Electrical isolation concept	26
2.4	Intended use	10	4.8	Connection of the supply voltages	27
2.4.1	Repair	11	4.8.1	Connection of control supply (+24 V DC)	27
2.5	Misuse	11	4.8.2	Connection of mains supply	28
2.6	Responsibility	11	4.8.3	Connected load and mains fuse	29
2.7	Relevant laws, standards and directives applied	11	4.9	Control connections	31
2.8	Declaration of conformity	12	4.9.1	Specification of the control connections	32
			4.9.2	Connection of motor brake X13	33
			4.10	Specification of the Ethernet interface	33
			4.11	Option 1	33
			4.12	Option 2	34

4.13	Encoder connection	34	6	Diagnostics	53
4.13.1	Resolver connection.....	35	6.1	Device states	53
4.13.2	Connection for high-resolution encoders	36	6.2	Error indication	53
4.14	Motor connection	37	6.3	Error codes.....	53
4.14.1	Motor temperature sensor.....	37	6.4	Status and error indication in DM5	54
4.14.2	Connection of LSH/LST motors	37	7	Safe Torque Off (STO)	57
4.14.3	Switching in the motor cable	38	A	Appendix	59
4.15	Brake chopper connection	38	A.1	Current carrying capacity of the servocontrollers	59
4.15.1	Protection in case of brake chopper fault.....	38	A.2	Technical data, ServoOne junior.....	62
4.15.2	Design with integrated braking resistor (BG3+4+5)	38	A.3	Power connections.....	64
4.15.3	Connection of an external braking resistor	40	A.5	Ambient conditions.....	64
5	Commissioning	43	A.6	UL certification	65
5.1	Notes for operation.....	43	Glossary.....		67
5.2	Initial commissioning	43			
5.2.1	Switching on control supply	44			
5.2.2	Establish connection between PC and drive controller	44			
5.2.3	Parameter configuration	44			
5.2.4	Controlling drive using DriveManager 5.....	44			
5.3	Serial commissioning.....	46			
5.4	Integrated control unit.....	46			
5.4.1	Function of buttons T1 and T2	47			
5.4.2	Display	48			
5.4.3	Parameter menu (PA)	48			
5.4.4	Ethernet IP address menu (IP).....	49			
5.4.5	Field bus address menu (Fb)	51			

1 General

The product DVD from KEBA Industrial Automation Germany GmbH contains the complete documentation for the related product series. The documentation for a product series includes the operation manual (hardware description), device help (software description) as well as further user manuals (e.g. field bus description) and specifications. The documents are available in PDF format.

1.1 Target group

Dear user,

The documentation forms part of the device and contains important information on operation and service. It is aimed at all persons who undertake mounting, installation, commissioning and servicing work on the product.

1.2 Prerequisites

Prerequisites for the usage of devices from KEBA:

- The documentation on the devices is to be stored so it legible, accessible at all times and for the entire life of the product.
- Read and ensure you understand the documentation on your device.
- Qualification: to prevent injury or damage, personnel may only work on the device if they have electrical engineering qualifications.
- Knowledge required:
 - National health and safety regulations (e.g. DG UV regulation 3 in Germany)
 - Mounting, installation, commissioning and operation of the device

Work in other areas, for example transport, storage and disposal is only allowed to be undertaken by trained personnel.



NOTE

This operation manual applies to the servocontroller ServoOne junior (referred to in the following as the servocontroller or SOJ for short). This manual does not replace the operation manuals for the ServoOne single-axis and multi-axis system.

1.3 Reference documents

Document	Contents	ID no. Format
ServoOne junior - Operation Manual	Safety, mechanical installation, electrical installation, commissioning, diagnostics, specifications, certification and applicable standards, technical data	1300.20B.x PDF
ServoOne Single-Axis System - Operation Manual	Safety, mechanical installation, electrical installation, commissioning, diagnostics, specifications, certification and applicable standards, technical data	1100.20B.x PDF
ServoOne Multi-Axis System - Operation Manual	Safety, mechanical installation, electrical installation, commissioning, diagnostics, STO, operation with servocontroller as supply, project planning, application example, specifications, certification and applicable standards, technical data	1101.20B.x PDF
ServoOne Multi-Axis System Supply Unit - Operation Manual	Safety, mechanical installation, electrical installation, commissioning, diagnostics, specification, certification and applicable standards, technical data	1101.21B.x PDF
ServoOne Sercos II - User Manual	Safety, commissioning, communication phases, parameter interface, error, warning and status messages, operation modes, weighting, referencing, touchprobe, parameter lists	1100.09B.x PDF
ServoOne Sercos III - User Manual	Safety, installation and connection, commissioning and configuration, setting parameters, data transmission, scaling and weighting, functionality, error messages and diagnostics, parameter lists	1108.06B.x PDF
ServoOne Field Bus Options CANopen/EtherCAT - User Manual	Safety, commissioning, data transmission, operation modes, referencing, parameters, technical data	1108.08B.x
ServoOne System - System Catalogue	Information, notes on ordering, specifications and technical data on: ServoOne junior, ServoOne single-axis system, ServoOne multi-axis system, safety technology, communication, technology, function packages, accessories and motors	1100.04B.x PDF
ServoOne - Device Help	Description of the software functionality ServoOne, firmware versions: - SO junior from V1.30-xx - SO single-axis system from V3.25-xx - SO multi-axis system from V3.25-xx	0842.06B.x PDF and HTML
Program Help DriveManager 5 PC user software	Context-sensitive help for DriveManager version 5.x graphic PC user software for initial commissioning and serial commissioning, operation, diagnostics and project management	0842.05B.x HTML, chm

1.4 Order code

The ServoOne junior (SOJ) has the article designation *SO2x.xxx.xxxx.x*. This provides information on the related variant of the SOJ supplied. The significance of the individual characters of the article designation is given in the following order code. You will find the complete order code with all values in the ServoOne System Catalogue.

Article designation		S02	4	. 004	. 0	0	2	1	. 0	0	0	0	.
<i>ServoOne junior (SOJ)</i>													
<i>Supply voltage:</i>		3 x 400 V 1/3 x 230 V	4 2										
<i>Rated current</i>	<i>BG2</i>	2.0 A 3.0 A	002 003										
	<i>BG3</i>	3.5 A 5.9 A	004 006										
	<i>BG4</i>	6.5 A 8 A	007 008										
	<i>BG5</i>	12 A 16 A	012 016										
<i>Mains supply</i>		AC				0							
<i>Safety technology</i>		STO				0							
<i>Option 1 Communication</i>		Not included <i>Sercos II</i> <i>PROFIBUS</i> <i>EtherCAT</i> <i>CANopen</i> <i>PROFINET</i> <i>Sercos III</i>					0 1 2 3 4 7 8						
<i>Option 2 Technology</i>		Not included <i>Second SinCos encoder</i> <i>TTL encoder simulation/TTL master encoder</i> <i>TTL encoder with commutation signals</i> <i>Analogue/digital input/output expansion (MIO)</i> <i>Digital input/output expansion (DIO)</i> <i>One-cable interface</i>					0 1 2 5 6 8 D						
<i>Housing/cooling method</i>		<i>Air-cooled (standard)</i> <i>Air-cooled with internal braking resistor (not BG2)</i>					0 1						
<i>Function package</i>		<i>Basic (without additional function package)</i> <i>iPlc</i>					0 1						
<i>Special design</i>		None									0		
<i>Protection</i>		<i>Standard</i> <i>PCBs with protective varnish</i>										0 1	
<i>Hardware version</i>		(May be multi-digit)											

1.5 Data on manufacture

On rating plates for the drive controllers you will find the serial number, from which you can identify the date of manufacture based on the following key. For the location of the rating plate on the SOJ refer to "Figure 4.1 Layout ServoOne junior BG2 to BG4" and "Figure 4.2 Layout ServoOne junior BG5".




Figure 1.1 Hardware rating plate, example ServoOne junior SO24.012

1.6 Scope of supply

The scope of supply includes:

- ServoOne junior drive controller
- Terminal kit for control and power terminals (depending on device power and variant)
- Set with shield connection plates and fixing material
- Product DVD with booklet

1.7 Pictograms

The pictograms used in this operation manual signify the following for the user:



NOTE

Useful information or reference to other documents.

1. (digit)

ACTION TO BE TAKEN

Action undertaken by the user or the system.

You will find the pictograms used in this operation manual for "safety instructions and warnings" in *chapter 2 Safety*.

1.8 Disclaimer

Following the documentation on the devices from KEBA is a prerequisite:

- For safe operation.
- To achieve stated performance features and product characteristics.

KEBA does not accept any liability for injuries, damage or financial losses that result from the failure to follow the documentation.

1.9 Disposal

Follow the current national regulations! If necessary, dispose of individual parts, depending on their characteristics and existing national regulations, e.g. as:

- Electrical waste
- Plastic
- Metal

Or engage a certified disposal organisation with scrapping

1.10 Support

Address: KEBA Industrial Automation Germany GmbH
Gewerbestrasse 5-9
35633 Lahnau

If you have any questions about the project planning for your machine or the commissioning of your device, our Helpline will provide you with quick, specific assistance.

The Helpline is available by e-mail or telephone:

Service hours: Mo.-Fr.: 8 a.m. - 5 p.m. (CET)

E-mail: helpline@keba.de

Telephone: +49 6441 966-180

Internet: www.keba-lti.com



NOTE:

You will find detailed information about our services on our web site
www.keba-lti.com ➔ Service

2 Safety

2.1 Overview

Our devices are state-of-the-art and comply with recognised safety regulations, nevertheless hazards can arise. In this chapter:

- We provide information on residual risks and hazards that can emanate from our devices on usage as intended.
- We warn about the foreseeable misuse of our devices.
- We refer to the necessary care and measures to be taken to prevent risks.

2.2 Measures for your safety



NOTE

Only install and place in operation your device taking into account the documentation for the related device family!

Our devices are quick and safe to operate. For your own safety and for the safe function of your device, please be sure to observe the following points:

1. Follow safety instructions for the devices:

Follow all safety instructions and warnings in the entire documentation related to the device series.

2. Electric drives are dangerous:

- Due to electrical voltages up to 480 V AC and up to 800 V DC
- Even 10 min. after switching off the mains supply, dangerously high voltages of ≥ 50 V may still be present (capacitor charge). So check that electrical power is not present! See also the warning label on the front panel on the device.
- Rotating parts
- Automatically starting drives.
- Hot components and surfaces

3. Protection against magnetic and/or electromagnetic fields during installation and operation.

Persons fitted with heart pacemakers, metallic implants and hearing aids etc. must not be allowed access to the following areas:

- Areas in the immediate vicinity of electrical equipment!
- Areas where electronics components and drive controllers are installed, repaired and operated!
- Areas where motors are installed, repaired and operated!
Motors with permanent magnets pose particular hazards.




4. During installation observe the following:

- Comply with connection conditions and technical data as per the documentation and the rating plate!
- Comply with standards and directives on electrical installation, such as cable cross-section, shielding, etc.!
- Do not touch electronic components and contacts!
Electrostatic discharge can harm people and destroy components!
- Take protection measures and use protective devices as per the applicable regulations (e.g. EN 60204 or EN 61800-5-1)!
- Take "device earthing" protection measure!

5. Ambient conditions

- Follow the instructions on the transport, storage and correct operation of the devices stated in the operation manual in "A Appendix".

2.3 General safety instructions and warnings




DANGER!	Risk of injury due to electrical power!
	<ul style="list-style-type: none"> • Carelessness will result in serious injuries or death. Follow safety instructions and warnings in this document and on the device.
WARNING!	Risk of injury due to electrical power!
	<ul style="list-style-type: none"> • Carelessness may result in serious injuries or death. Follow safety instructions and warnings in this document and on the device.
CAUTION!	Risk of injury or damage to the device due to incorrect operation!
	<ul style="list-style-type: none"> • Carelessness may result in minor injuries or damage. Follow safety instructions and warnings in this document and on the device.
WARNING!	Risk of injury due to hot surfaces and components!
	<ul style="list-style-type: none"> • Carelessness may result in serious burns. Electronic components may become hot during operation! Follow safety instructions and warnings in this document and on the device!
CAUTION!	Damage due to electrostatic discharge!
	<ul style="list-style-type: none"> • Electrostatic discharge can destroy components. Do not touch electronic components and contacts! Follow safety instructions and warnings in this document and on the device!
DANGER!	Risk of injury due to rotating parts on the motor!
	<ul style="list-style-type: none"> • Carelessness will result in serious injuries or death. Follow safety instructions and warnings in this document.

Pay attention to **special safety instructions and warnings** that are given here in the document before a specific action and that warn the user about a **specific hazard**!



NOTE:

The pictograms may also be used on their own with the signal word, e.g. in the connection diagrams, however they have the same function as in the complete warning.

DANGER	WARNING	CAUTION
		

2.4 Intended use

Our devices are components intended for stationary electrical systems and machines in the industrial and commercial sector.



The devices in the product range ServoOne junior conform to the **Machinery Directive 2006/42/EC**

Tested and certified in accordance with applicable standards (see declaration of conformity in chap. 2.8).

When installed in machines it is prohibited to start-up intended operation until it has been ascertained that the completed machine fully complies with the provisions of the Machinery Directive (2006/42/EC); compliance with EN 60204 is mandatory.

Starting up intended operation is only permitted on compliance with the EMC Directive 2014/30/EU.

The devices meet the requirements of the harmonised product standard EN 61800-5-1.

You will find information on the installation of your device in chapter “3 Mechanical installation”.

2.4.1 Repair

Only have repairs undertaken by authorised repair shops. Unauthorised repairs could lead to death, injury or damage (see previous sections). The warranty provided by KEBA will be rendered void.

2.5 Misuse

Our devices are:

- Not intended for installation in vehicles. Deployment of the device in mobile equipment is classed as non-standard ambient conditions and is permissible only by special agreement.
- Not intended for installation in environments with harmful oils, acids, gases, vapours, dusts, radiation etc.
- Not approved for usage in special applications (e.g. in potentially explosive atmospheres or areas in which there is a risk of fire).
- Not approved for usage outside a switch cabinet
- Not approved for the generation of high-frequency onboard networks for which the devices are not designed

2.6 Responsibility

Electronic devices are not fail-safe. The installer and/or operator of a complete machine or system is responsible:

- For ensuring the drive is rendered safe if the device fails
- For ensuring the safety of personnel and machinery
- For ensuring the complete machine is in correct working order
- For the risk assessment on the complete machine or system according to DIN EN 12100:2011 (formerly DIN EN 14121:2007) and EN ISO 13849-1

Pay attention to the topic of "Electrical equipment of machines" in EN 60204-1:2006 "Safety of machinery".

- The safety requirements on electrical machines defined there are intended to protect personnel and machinery or systems.

- The emergency stop function (as per EN 60204-1:2006) shuts down the supply of power to a machine, which results in the drives coasting down in an uncontrolled manner. To avert hazards, check whether it is appropriate:
 - To keep individual drives in operation
 - To initiate specific safety procedures
 - To incorporate a Safe Torque Off function (Safe Torque Off: movement stop by "switching off the electrical supply" - STO)

2.7 Relevant laws, standards and directives applied

For information on the laws, standards and directives applied by KEBA, refer to the declaration of conformity.



NOTE:


Depending on the specific application for the devices, other laws, standards and directives with provisions on "safety" may apply. If necessary, contact the machine or system manufacturer.

2.8 Declaration of conformity

		EU-Konformitätserklärung <i>EU Declaration of Conformity</i>	
Der Hersteller <i>The manufacturer</i>		LTI Motion GmbH Gewerbestraße 5-9 35633, Lahnau	
erklärt hiermit, dass die folgenden Produkte <i>declares that the following products</i>			
Produktbezeichnung: <i>Product designation:</i>		Servoregler Servo Controller	
Produkttypen: <i>Product types:</i>		ServoOne Baugröße 1-6, ServoOne Junior Baugröße 2-4 ServoOne Size 1-6, ServoOne Junior Size 2-4	
ab Seriennummer: <i>from serial number:</i>		1110XXXXX 1110XXXXX ServoOne Baugröße 7 ServoOne Size 7 1639XXXXX 1639XXXXX ServoOne Junior Baugröße 5 ServoOne Junior Size 5 14400XXXX 14400XXXX	
den Sicherheitsbestimmungen der nachstehenden EG- und EU-Richtlinien entsprechen: <i>comply with the essential requirements of the following EC and EU Directives:</i>			
2006/42/EG 2006/42/EC		[Maschinenrichtlinie] [Machinery-Directive]	
2014/30/EU 2014/30/EU		[EMV-Richtlinie] [EMC-Directive]	
und dass folgende angeführten harmonisierten Normen angewandt wurden: <i>and that the following harmonised standards have been applied:</i>			
EN ISO 13849-1:2008 + AC:2009 EN 61800-3:2004 + A1:20012 EN 60204-1:2006 + A1:2009 + AC:2010 (in extracts)		EN 50178:1997 EN 61800-5-1:2007 EN 61800-5-2:2007	
Folgende weitere Norm wurde angewandt: <i>The following additional standard has been applied:</i>			
IEC 61508 1-7:2010			
Jahr der CE-Kennzeichnung / Year of CE-marking: 2011 / 2014 / 2016			
EG-Baumusterprüfung / EC type examination			
Benannte Stelle / Notified body:		TÜV Rheinland Industrie Service GmbH Am Grauen Stein, 51105 Köln	
Kennnummer / Identification-No.:		0035	
EG Baumusterprüfung Bescheinigung Nr.: 01/205/5036.01/15 EC type examination Certificate-No.:			
Unterschrift / signature		 	
Name / name:		Dr. Hartmut Braun	
Stellung:		Geschäftsführer Managing Director	
Datum / date:		28.09.2016	
Dokument: 1110.00K.3-00_ServoOne_STO		Matthias Wagner Dokumentationsbeauftragter Responsible for documentation 28.09.2016	
FB 0108 EU Konformitätserklärung 201004 A			

3 Mechanical installation

3.1 Notes for operation

CAUTION	Damage to the device due to incorrect installation conditions!
	<p>The device may suffer irreparable damage. For this reason</p> <ul style="list-style-type: none"> Moisture must not be allowed to enter the device There must not be any aggressive or conductive substances in the ambient air Foreign bodies such as drilling chips, screws, washers etc. must not be allowed to enter the device The ventilation openings must not be covered

Note the following points:

- Cooling air must be able to flow through the device without restriction.
- On installation in switch cabinets with convection (= heat loss is dissipated to the outside via the cabinet walls), always fit an internal fan.
- The backing plate must be well-earthed.
- The device is intended only for vertical installation in switch cabinets. The switch cabinet must provide IP4x protection as a minimum.
- To attain the best result for effective EMC installation you should use a chromated or galvanised backing plate. If backing plates are varnished, remove the coating from the contact area! The devices themselves have an aluminium back panel.
- Maximum pollution degree 2 according to EN60664-1
- The devices must not be installed in areas where they are exposed to continuous vibration. You will find more information in the appendix, Table A.9.
- The device heats up during operation and the temperature on the heat sink may reach 100 °C. Pay attention to this aspect for neighbouring components.



NOTE

According to EN ISO 13849-2 the switch cabinet must have IP54 protection or higher on using the STO (Safe Torque OFF) safety function.

Further information on ambient conditions can be found in the appendix.

3.2 Wall mounting

Step	Action	Comment
1.	Mark out the position of the tapped holes on the backing plate. Cut a thread for each fixing screw in the backing plate.	For dimensional drawings/hole spacing see Figure 3.1, Figure 3.2 The thread surface area will provide good contact.
2.	Mount the servocontroller vertically on the backing plate.	Observe the mounting clearances! The contact area must be bare metal.
3.	Mount the other components, such as the mains filter, mains choke etc., on the backing plate.	The cable between mains filter and servocontroller may be max. 30 cm long.
4.	You will find the next steps for the electrical installation in chapter 4.	


Table 3.1 Mechanical installation



NOTE

Forced cooling by external air flow is necessary for all sizes of the ServoOne junior. The air must be able to flow unhindered through the device. If a thermal cut-out occurs, the cooling conditions must be improved.

Air flow: at least 1.2 m/s



3.2.1 Dimensions of the devices

Size	BG2	BG3	BG4	BG5
ServoOne junior	S022.003 S024.002	S022.006 S024.004	S022.008 S024.007	S024.012 S024.016
Weight [kg]	1.0	1.5	2.8	5.9
B (width)	55			90
H (height) ¹⁾	210		290	291
T (depth) ¹⁾	142	189	235.5	
A	27.5			20
A1	-	-	40	50
C	225		305	313
C1	5			6
D Ø	4.8			
H1	235		315	324
Screws	2 x M4		4 x M4	

All dimensions in mm

1) Without terminals/connections

Table 3.2 ServoOne junior dimensions - see Figure 3.1 and Figure 3.2




Figure 3.1 Dimensional drawing BG2, BG3, BG4




Figure 3.2 Dimensional drawing BG5

3.2.2 Mounting clearances

The minimum distances specified in the table apply for devices of the same power. On butt mounting devices with different drive powers, you should arrange the devices in order by power rating (e.g., viewed from the left, BG5-BG4-BG3-BG2). This arrangement will minimise the thermal interaction.




NOTE

If ServoOne junior devices are attached to other product ranges, corresponding measures must be taken to prevent the devices affecting each other thermally.

Size	BG2	BG3	BG4	BG5
ServoOne junior	S022.003 S024.002	S022.006 S024.004	S022.008 S024.007	S024.012 S024.016
E	Direct butt mounting			

Drawing:
Dimensions in mm




1) The bending radius of the connection cables must be taken into account

Table 3.3 ServoOne junior mounting clearances

Size	BG2	BG3	BG4	BG5
F ¹⁾	≥100		≥150	
G ¹⁾	≥235		≥280	

Drawing:
Dimensions in mm





1) The bending radius of the connection cables must be taken into account

Table 3.3 ServoOne junior mounting clearances

4 Electrical installation

4.1 Notes for installation

DANGER	Risk of injury due to electrical power!
	<ul style="list-style-type: none">• Carelessness will result in serious injuries or death. <p>Never make or disconnect electrical connections while they are electrically live! Always disconnect the power before working on the device. Even 10 min. after switching off the mains supply, dangerously high voltages of ≥ 50 V may still be present (capacitor charge). So check that electrical power is not present!</p> <p>Work on the device must only be carried out after the DC link voltage has dropped below a residual voltage of 50 V (indicated by monitoring LED H1 and to be measured on terminals X1/L- and L+).</p> <p>A dangerous voltage may be present at the device, even if the device does not emit any visual or audible signals/indications (e.g. with mains voltage applied to terminal X3 and missing control supply +24 V on X2)!</p>
WARNING!	Risk of injury due to hot surfaces on the device (heat sink)!
	<ul style="list-style-type: none">• Carelessness may result in serious burns. <p>The device and especially the heat sink heat up significantly during operation and can reach temperatures of up to 100 °C. Before starting work, make sure the device has cooled down. On touching there is a risk of burns to the skin. For this reason provide protection against touching. During mounting maintain an appropriate distance to neighbouring assemblies.</p>

The following general guidelines apply for the installation of drive controllers:

- *Compliance with the EMC product standard*
 - Commissioning (i.e. starting intended operation) is only permitted on compliance with the EMC product standard EN 61800-3. The installer/operator of a machine and/or system must provide proof of compliance with the protection targets stipulated in the standard.
- *Cable type*
 - Use only shielded mains, motor and signal lines with double copper braiding with 60 to 70 % coverage.

- *Routing of cables*
 - Route mains, motor and signal cables separated from one another. If possible, keep a distance of at least 0.2 m, otherwise use separators. They should not run in parallel. If crossovers are unavoidable, they should wherever possible be configured perpendicular (at a 90° angle).
 - Always route the motor cable without interruptions and the shortest way out of the switch cabinet. If a motor contactor for example is used, the component should be directly mounted to the drive controller and the shielding of the motor cable should not be stripped back too far.
 - If possible, signal cables should only enter from one side into the switch cabinet.
 - Wires for the same electric circuit must be twisted.
 - Avoid unnecessary cable lengths and loops.
- *Earthing measures*
 - Earthing measures of relevance for the drive controller are described in section “4.6 Protective earth conductor connection”.
- *Shielding measures*
 - Do not strip the cable shields back too far, and lay them with large area connections both on the component and on the backing plate or on the PE rail (main earth) for the backing plate.
- *External components*
 - Place larger loads near the supply.
 - Contactors, relays, solenoid valves (switched inductances) must be wired with suppressors. The wiring must be directly connected to the respective coil.
 - Any switched inductance should be at least 0.2 m away from the process controlled assemblies.
- You will find *additional information* in the corresponding connection description. If you require further detailed information on installation you should consult the KEBa Helpline (see “Commissioning” on page 43).

4.2 Overview of the connections

In the following you will find the layouts with the corresponding positions of connectors and terminals. For improved clarity we have added an abbreviation to the designation for the connectors and terminals.




Figure 4.1 Layout ServoOne junior BG2 to BG4

Number	Designation
D1, D2	7-segment display
H1	Indicator LED for DC link voltage (only size BG2 to BG4)
OP1	Installation space for Option 1 (Communication)
T1, T2	Button
X1	Power connections (only size BG2 to BG4)
X2	Connection for control supply U_v
X3	AC mains connection
PE (bottom)	Device protective earth conductor connection
X4	Control terminals
X5	Motor temperature monitoring
X6	Resolver connection
X7	Connection for high-resolution encoders
X8	Option 2 (Technology)
X9	Ethernet interface
X13	Connection for motor brake

Table 4.1 Key to layout ServoOne junior BG2 to BG4




Figure 4.2 Layout ServoOne junior BG5

Number	Designation
D1, D2	7-segment display
OP1	Installation space for Option 1 (Communication)
T1, T2	Button
PE (top)	Motor PE connection
X1.a	Motor connection (only size BG5)
X1.b	Measuring point for DC link voltage (only size BG5)
X1.c	Connection for braking resistor (only size BG5)
X2	Connection for control supply U_v
X3	AC mains connection
PE (bottom)	Device protective earth conductor connection
X4	Control terminals
X5	Motor temperature monitoring
X6	Resolver connection
X7	Connection for high-resolution encoders
X8	Option 2 (Technology)
X9	Ethernet interface
X13	Connection for motor brake
S	Receptacle for shield plate (see "Detail 1: Motor cable" on page 23)
T. Software	Software rating plate
T. Hardware	Hardware rating plate

Table 4.2 Key to layout ServoOne junior BG5

4.3 Connection diagram, BG2 to BG4





Figure 4.3 Connection diagram, BG2 to BG4

Number	Designation	Details
D1, D2	7-segment display	Page 48
T1, T2	Button	Page 48
X1	Connection for motor, braking resistor and measurement of DC link voltage	Page 37
X2	Connection for control supply	Page 27
X3	Connection for AC power supply	Page 28
X4	Control terminals	Page 31
X5	Connection for motor temperature monitoring ¹⁾	Page 37
X6	Connection for resolver ¹⁾	Page 35
X7	Connection for high-resolution encoder ¹⁾	Page 36
Option 1	Communication	Page 33
PE	PE connection	Page 26
X8 (Option 2)	Technology	Page 34
X9	Ethernet interface	Page 33
X13	Connection for motor brake	Page 33
1)	Screen connections via separate shield plates	Page 22
	Connection for housing PE conductor	Page 26

1) NOTE: The temperature sensor for the motor winding can be connected either via the encoder cables (X6 or X7) or to terminal X5.

Table 4.3 Key to connection diagram, BG2 to BG4

4.4 Connection diagram, BG5




Figure 4.4 Connection diagram, ServoOne junior BG5

Number	Designation	Details
D1, D2	7-segment display	Page 48
T1, T2	Button	Page 48
X1.a	Connection for motor	Page 37
X1.b	Measuring point for DC link voltage	-
X1.c	Connection for braking resistor	Page 37
X2	Connection for control supply	Page 27
X3	Connection for AC power supply	Page 30
X4	Control terminals	Page 31
X5	Connection for motor temperature monitoring ¹⁾	Page 37
X6	Connection for resolver ¹⁾	Page 35
X7	Connection for high-resolution encoder ¹⁾	Page 36
Option 1	Communication	Page 33
PE	Connection for PE conductor	Page 26
X8 (Option 2)	Technology	Page 34
X9	Ethernet interface	Page 33
X13	Connection for motor brake	Page 33
1)	Screen connections via separate shield plates	Page 22

1) NOTE: The temperature sensor for the motor winding can be connected either via the encoder cables (X6 or X7) or to terminal X5.

Table 4.4 Key to connection diagram

4.5 Effective EMC installation

4.5.1 Interference immunity of drive controllers



NOTE

This is a restricted availability product according to IEC 61800-3. This product may cause radio interference; in such cases the operator may need to take appropriate measures.

External RFI filters (EMCxxx) are available for the drive controllers. With the measurement method specified and the external mains filter, these drive controllers conform to the EMC product standard IEC 61800-3 for "First environment" (residential C2) and "Second environment" (industrial C3).

4.5.2 Specimen setup

The specimen setup presented on the following pages is intended to illustrate the key measures necessary to ensure an effective EMC installation.



NOTE

The specimen setup merely presents a recommendation, and does not automatically guarantee compliance with applicable EMC directives. The installer/operator of a machine and/or system must provide proof of compliance with the protection targets stipulated in the standard.

Overview

Figure 4.5 presents an overview of the minimum components required:

- A. Backing plate with cable ducts
- B. ServoOne junior
- C. Mains filter
- D. Mains choke
- E. Distributor rail for AC power supply and control supply (+24 V DC)

The layout and cabling are based on the requirements in section 4.1. The numbered red arrows refer to four very important detailed notes presented on the following pages.




Figure 4.5 Specimen setup - overview

Detail 1: Motor cable

On devices BG2 to BG4 make sure the motor connection is connected to terminal (X1) and on devices BG5 to terminal (X1a, X1b, X1c):

- Fasten the shield connection plate supplied (shield plate for BG2 to BG4 see Figure 4.6, shield plate for BG5 see Figure 4.7) to the top of the device. Ensure the plate is in contact over a large area with the heat sink on the ServoOne junior and with the backing plate. Use a serrated washer.



Figure 4.6 Shield plate BG2 to BG4




Figure 4.7 Shield plate BG5

- Strip the shielding of the motor cable back only as far as absolutely necessary.
- Connect the motor cable shield with a large area connection to the shield connection plate using the clamp supplied.



NOTE

Ready made motor cables are available for KEBA servomotors. You will find details in the System Cables Order CatalogueS.




Figure 4.8 Detail 1: Motor cable BG2 to BG4



Figure 4.9 Detail 1: Motor cable BG5

Detail 2: Control supply (+24 V DC)

At the connection for the control supply (X2):

- Secure the second of the two shield connection plates supplied to the mount on the bottom of the unit using the screw. Ensure the plate is in contact over a large area with the heat sink on the ServoOne junior and with the backing plate. Use a serrated washer.
- Pull a shielding sleeve over the control supply cable and strip it back only as far as necessary before the control supply connection (X2).
- Connect the shielding sleeve on the control supply cable with a large area connection to the shield connection plate using the clamp supplied.




Figure 4.10 Specimen setup - detail 2: Control supply

Detail 3: Mains filter and mains connection

At the output of the mains filter and the AC mains connection (X3):

- Connect the litz wire on the output of the mains filter directly to the AC mains connection (X3) on the ServoOne junior. The litz wires must **not** be extended, so the mains filter should be installed correspondingly close to the ServoOne junior. But be sure to maintain the necessary minimum clearance (see "Table 3.3 ServoOne junior mounting clearances").
- Fix the litz wire to the shield connection plate using a cable tie as necessary.
- The leakage current of the ServoOne junior is >3.5 mA. So:
 - Connect the protective earth conductor from the output of the mains filter to connection (X3) on the ServoOne junior BG2 to B4 or to the housing of the ServoOne junior BG5 **and**
 - Connect one of the PE connections on the heat sink on the ServoOne junior using a cable of at least the same cross-section to the main earth for the distributor rail.




Figure 4.11 Specimen setup - detail 3: Mains filter and mains connection

Detail 4: Control cables

At the control terminals (X4) of the ServoOne junior, BG2 to BG4:

- Strip the shield on the control cables back only as far as absolutely necessary.
- Connect the shield on the control cables with a large area connection to the shield connection tab on the mains filter using the clamp supplied. If this is not possible, connect the control cable shield directly to the backing plate with a large area connection directly adjacent to the ServoOne junior.



Figure 4.12 Specimen setup - detail 4: Control cables BG2 to BG4

At the control terminals (X4) of the ServoOne junior, BG2 to BG5 pay attention to:

- Fasten the shield connection plate supplied (for control terminal shield plate for BG5 see Figure 4.14) to the underside of the device. Ensure the plate is in contact over a large area with the heat sink on the ServoOne junior and with the backing plate. Use a serrated washer.
- Strip the shield on the control cables back only as far as absolutely necessary.
- Connect the shield on the control cables with a large area connection to the shield connection plate using the clamp supplied.



Figure 4.13 Specimen setup - detail 4:
Control cables BG5



Figure 4.14 Control terminal shield plate BG5

4.6 Protective earth conductor connection

Step	Action	PE mains connection according to DIN EN 61800-5-1
1.	Earth each of the drive controllers! Connect the terminal \oplus in a star configuration and with a large area connection to the PE rail (main earth) in the switch cabinet.	For the PE connection the following applies (as leakage current >3.5 mA): Use protective earth conductors with the same cross-section as the mains power cables, though at least 10 mm ² . Also comply with local and national regulations and conditions.
2.	Also connect the protective earth conductor connections on all other components, such as mains choke, filter, etc. in a star configuration and with a large area connection to the PE rail (main earth) in the control cabinet.	




Figure 4.15 Star configuration layout for the PE conductor

4.7 Electrical isolation concept

The control electronics, with their logic (μP), the encoder terminals and the inputs and outputs, are electrically isolated from the power section (power supply/DC link). All control terminals are designed as safety extra low voltage/protective extra low voltage (SELV/PELV) circuits and must only be operated with such SELV/PELV voltages, as per the relevant specification. This provides reliable protection against electric shock on the control side.

A separate control supply, compliant with the requirements of a SELV/PELV, is therefore needed.

The overview opposite shows the potential references for the individual connections in detail.

This concept also delivers higher operational safety and reliability of the drive controller.

SELV = Safety Extra Low Voltage
PELV = Protective Extra Low Voltage




Figure 4.16 Electrical isolation concept ServoOne junior

4.8 Connection of the supply voltages

The supply of power to the ServoOne junior is separate for the control and power sections. The control supply should always be connected **first**, so that the device parameters can be set with DriveManager 5 and, above all, the device set to the correct supply for the power section.

CAUTION!

Damage to the device due to incorrect operation!



• Carelessness can cause damage to the device.

Only when the mains voltage has been pre-set in the device firmware and the device has been restarted (if the mains voltage or switching frequency has been changed) may the mains power supply for the supply for the power section be activated.

4.8.1 Connection of control supply (+24 V DC)




Figure 4.17 Connection of control supply ServoOne junior


Control supply (specification)

Control supply	X2/+ X2/-	<ul style="list-style-type: none"> • $U_v = +24 \text{ V DC} \pm 10\%$, stabilised and filtered. • $I_v = 2 \text{ A}$ (BG2 to BG5) • Internal polarity reversal protection • The power supply unit used must have safe and reliable isolation in relation to the mains as per EN 50178 or EN 61800-5-1
----------------	--------------	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

Table 4.5 Specification of control supply ServoOne junior

**NOTE**

Suitable measures must generally be applied to provide adequate cable protection.

DANGER	Risk of injury due to electrical power!
	<ul style="list-style-type: none"> Carelessness will result in serious injuries or death. <p>When the mains voltage is switched on at terminal X3 and there is no control supply (+24 V DC at X2), a dangerous voltage is present on the device with no visual signal on the display or acoustic indication by fan noise. If visible in the installed state, LED H1 (see Fig. Figure 4.1) indicates whether power is connected to the device. Even if H1 is completely off, X1 must be checked to ensure no electrical power is present.</p>

**NOTE**



The start-up current for the supply voltage for the BG2 to BG5 may be 2-3 times the operating current for a short time.

4.8.2 Connection of mains supply

Procedure:

Step	Action	Comment
1.	Specify the cable cross-section depending on the maximum current and ambient temperature.	Cable cross-section according to local regulations and conditions.
2.	Wire the drive controller with the mains filter ¹⁾ , max. cable length 0.3 m (with non-shielded cable)!	
3.	Wire the mains choke ¹⁾ (if fitted)	Reduces the distortion (THD) in the system and prolongs the life of the drive controller.
4.	Install a mains isolating device K1 (power circuit breaker, contactor, etc.).	Do not switch on the power!
5.	Use mains fuses (utilisation class gG) to isolate all poles of the drive controller from the mains supply.	For compliance with equipment safety requirements as per EN 61800-5-1

¹⁾ Optional

DANGER!	Risk of injury due to electrical power!
	<ul style="list-style-type: none"> Carelessness will result in serious injuries or death. <p>Never make or disconnect electrical connections while they are electrically live! Always disconnect the power before working on the device. Even 10 min. after switching off the mains supply, dangerously high voltages of ≥ 50 V may still be present (capacitor charge). So check that electrical power is not present!</p>
CAUTION!	Risk of injury or damage to the device due to incorrect residual current device!
	<ul style="list-style-type: none"> Carelessness may result in injuries or damage. <p>If local regulations require the installation of a residual current device, the following applies: In the event of a fault the drive controller is able to generate DC leakage currents without zero crossing. Drive controllers therefore must only be operated with residual current devices (RCDs) ¹⁾ type B for AC fault currents, pulsating or smooth DC fault currents, which are suitable for servo controller operation, see IEC 60755. RCMs ²⁾ can also be used for monitoring purposes.</p>
<p>1) Residual Current Device 2) Residual Current Monitor</p>	

Note the following points:

Switching the mains power:

- In the event of excessively frequent switching the device protects itself by means of high-resistance decoupling from the mains. After a rest phase of a few minutes the device is ready to start once again.

TN and TT system: operation is permitted if:

- In the case of single-phase devices for 1 x 230 V AC the supply system conforms to the maximum overvoltage category III as per EN 61800-5-1.
- In the case of three-phase devices with phase conductor voltages 3 x 230 V AC, 3 x 400 V AC, 3 x 460 V AC and 3 x 480 V AC
- **The star point** of the supply system **is earthed** and
- The supply system conforms to the maximum overvoltage category III as per EN 61800-5-1 at a system voltage (phase conductor → star point) of maximum 277 V.

IT system: operation is **not** permitted!

- If there is an earth fault the voltage is approx. twice as high. Clearances and creepages to EN 61800-5-1 are no longer maintained.

Connection of the drive controllers via a mains choke is imperative:

- Where the drive controller is used in applications with disturbance variables corresponding to environment class 3, as per EN 61000-2-4 and above (harsh industrial environment)
- In the case of single-phase mains supply
- For compliance with EN 61800-3 or IEC 61800-3

You will find further information on current carrying capacity, technical data and ambient conditions in the appendix.



NOTE

Please note that the ServoOne junior is not designed for the mains quality in for environment class 3 (EN61000-2-4). Further measures are essential to achieve this environment class! For further information please consult your project engineer.



NOTE

The minimum cross-section of the mains power cable depends on the local regulations and conditions, as well as on the rated current of the drive controller.

CAUTION!	Damage to the device due to incorrect operation!
	<ul style="list-style-type: none"> • Carelessness can cause damage to the device. <p>Only when the mains voltage has been pre-set in the device firmware and the device has been restarted (if the mains voltage or switching frequency has been changed) may the mains power supply for the power section be activated.</p>

4.8.3 Connected load and mains fuse

Drive controller	Device connected load ¹⁾ [kVA]		Max. cable cross-section ²⁾ of the terminal [mm ²]		Specified mains fuse, utilisation class [A]
	With mains choke (4% u_R)	Without mains choke	Ferr. with insul. ³⁾	Ferr. w/o insul. ³⁾	
S022.003	1.3	1.6	2.5	2.5	1 x 16 max. (1-phase) 3 x 16 max. (3-phase)
S024.002	1.5	1.9			3 x 6 max
S022.006	2.6	3.2	2.5	2.5	1 x 16 max. (1-phase) 3 x 16 max. (3-phase)
S024.004	2.7	3.3			3 x 10 max.
S022.008	3.5	4.3	4	4	1 x 20 max. (1-phase) 3 x 20 max. (3-phase)
S024.007	5.0	6.1			3 x 16 max.
S024.012	8.1	10.5	4	6	3 x 32 max.
S024.016	10.2	13.2			3 x 40 max.

¹⁾ At 3 x 230 V AC or 3 x 400 V AC mains voltage and $f_T \geq 8$ kHz

²⁾ The minimum cross-section of the mains power cable depends on the local regulations and conditions, as well as on the rated current of the drive controller.

³⁾ Ferr. with insul. = Ferrule with plastic insulation, Ferr. w/o insul. = Ferrule without plastic insulation

Table 4.6 Connected load and mains fuse

Mains supply for BG2 and BG3 devices



NOTE

Before commissioning, the value of the connected mains voltage must be set on the drive controller (factory setting = 3 x 230 V AC / 3 x 400 V AC).




Figure 4.18 Connection of BG2 and BG3 to mains supply 3 x 230 V (SO22.xxx) or 3 x 400 V (SO24.xxx) depending on device design




Figure 4.19 Connection of BG2 and BG3 to mains supply 1 x 230 V (SO22.XXX)

Mains supply for BG4 devices



NOTE

Before commissioning, the value of the connected mains voltage must be set on the drive controller (factory setting = 3 x 230 V AC / 3 x 400 V AC).




Figure 4.20 Connection of BG4 to mains supply 3 x 230 V (SO22.xxx) or 3 x 400 V (SO24.xxx) depending on device design




Figure 4.21 Connection of BG4 to mains supply 1 x 230 V (SO22.XXX)

Mains supply for BG5 devices



NOTE:

Before commissioning, the value of the connected mains voltage must be set on the drive controller (factory setting = 3 x 400 V AC).




Figure 4.22 Connection of BG5 to mains supply 3 x 400 V (SO24.xxx) depending on device design

4.9 Control connections

Step	Action	Comment
1.	Check whether complete device settings are already available, i.e. whether the drive has already been configured.	
2.	If so, a special control terminal assignment applies. Please contact your project engineer to obtain the terminal assignment!	
3.	Choose a terminal assignment.	Initial commissioning
4.	Wire the control terminals using shielded cables. The following are imperative: request STO X4/22, ENPO X4/10 and a start signal (with control via terminal).	Earth the cable shields over a large area at both ends. Rigid conductor sizes: 0.2 to 1.5 mm ² Flexible conductor sizes: - Ferrule without plastic sleeve: 0.2 to 1.5 mm ² - Ferrule with plastic sleeve: 0.2 to 0.75 mm ²
5.	Keep all contacts open (inputs inactive).	
6.	Check all connections again!	

Note the following points:

- Always wire the control terminals with shielded cables.
- Lay the control cables separately from the mains power and motor cables.
- A cable type with double copper braiding, with 60 - 70% coverage, must be used for all shielded connections.


4.9.1 Specification of the control connections

Des.	Term.	Specification	Electrical isolation
Analogue inputs			
ISA0+ ISA0- ISA1+ ISA1-	X4/3 X4/4 X4/5 X4/6	<ul style="list-style-type: none"> $U_{IN} = \pm 10 \text{ V DC}$ Resolution 12 bits; R_{IN} approx. 101 kΩ Terminal scan cycle in "IP mode" = 125 μs, otherwise = 1 ms Tolerance: $U \pm 1\%$ of the measuring range end value 	No
Digital inputs			
ISD00 ISD01 ISD02 ISD03 ISD04	X4/15 X4/16 X4/17 X4/18 X4/19	<ul style="list-style-type: none"> Frequency range <500 Hz Terminal scan cycle in = 1 ms Switching level low/high: $\leq 4.8 \text{ V} / \geq 18 \text{ V}$ $U_{IN \max} = +24 \text{ V DC} + 20\%$ I_{IN} at +24 V DC = typ. 3 mA 	Yes
ISD05 ISD06	X4/20 X4/21	<ul style="list-style-type: none"> Frequency range $\leq 500 \text{ kHz}$ Switching level low/high: $\leq 4.8 \text{ V} / \geq 18 \text{ V}$ $U_{IN \max} = +24 \text{ V DC} + 20\%$ $I_{IN \max}$ at +24 V DC = 10 mA, R_{IN} approx. 3 kΩ Internal signal delay < 2 μs suitable as trigger input for quickly saving actual position 	Yes
ENPO	X4/10	<ul style="list-style-type: none"> Disable restart inhibit (STO) and enable power stage = High level OSSD support Response time approx. 10 ms Switching level low/high: $\leq 4.8 \text{ V} / \geq 18 \text{ V}$ $U_{IN \max} = +24 \text{ V DC} + 20\%$ I_{IN} at +24 V DC = typ. 3 mA 	Yes
Digital outputs			
OSD00 OSD01 OSD02	X4/7 X4/8 X4/9	<ul style="list-style-type: none"> No destruction in case of short circuit (+24 V DC -> DGND), but device may briefly shut down. $I_{\max} = 50 \text{ mA}$, PLC-compatible Terminal scan cycle in = 1 ms High-side driver 	Yes

Table 4.7 Specification of the control connections X4

Des.	Term.	Specification	Electrical isolation
STO "Safe Torque Off"			
ISDSH (STO)	X4/22	<ul style="list-style-type: none"> Input "Request STO" = low level OSSD support Switching level low/high: $\leq 4.8 \text{ V} / \geq 18 \text{ V}$ $U_{IN \max} = +24 \text{ V DC} + 20\%$ I_{IN} at +24 V DC = typ. 3 mA 	Yes
RSH RSH	X4/11 X4/12	Diagnostics STO, both shut-off channels active, one NO contact with automatically resetting circuit breaker (polyswitch) <ul style="list-style-type: none"> 25 V / 200 mA AC, $\cos \varphi = 1$ 30 V / 200 mA DC, $\cos \varphi = 1$ 	Yes
Relay outputs			
REL	X4/23 X4/24	Relay, 1 NO contact <ul style="list-style-type: none"> 25 V / 1.0 A AC, $\cos \varphi = 1$ (AC1) 30 V / 1.0 A DC, $\cos \varphi = 1$ (DC1) Switching delay approx. 10 ms Cycle time 1 ms 	Yes
Auxiliary voltage			
+24 V	X4/2 X4/14	<ul style="list-style-type: none"> Auxiliary voltage output (U_H) for feeding the digital control inputs $U_H = U_V - \Delta U$ (ΔU typically approx. 1.2 V), no destruction in case of short circuit (+24 V DC -> DGND), but device may briefly shut down. $I_{\max} = 80 \text{ mA}$ (per pin) with self-resetting circuit breaker (polyswitch) 	Yes
Digital ground			
DGND	X4/1 X4/13	Reference ground for +24 V DC	Yes

Table 4.7 Specification of the control connections X4



4.9.2 Connection of motor brake X13

The connector X13 is intended to be used to connect a motor brake.

Des.	Term.	Connection	Specification
OSD03 GND	X13/2 X13/1	<p>$I_{BR} < 2.0 \text{ A}$</p> <p>Front</p> <p>X13</p> <p>V+ 4</p> <p>GND 3</p> <p>OSD03 2</p> <p>GND 1</p> <p>24 V DC ext. supply</p> <p>Brake (+)</p> <p>Brake (-)</p> <p>$I_{BR} > 2.0 \text{ A}$</p> <p>Front</p> <p>X13</p> <p>V+ 4</p> <p>GND 3</p> <p>OSD03 2</p> <p>GND 1</p> <p>24 V DC ext. supply</p> <p>24 V DC</p> <p>Brake (-)</p> <p>Brake (+)</p>	<ul style="list-style-type: none"> • Short circuit proof • External control supply +24 V DC ($I_{IN} = 2.1 \text{ A}$) required via X13/3 (GND) and X13/4 (V+) • $U_{BR} = U_V - \Delta U$ (ΔU typically approx. 1.4 V) • For operating a motor holding brake up to $I_{BR} = 2.0 \text{ A}$ max. • Overcurrent causes cyclic shutdown • Also usable as configurable digital output • Cable break monitoring: With the brake driver switched on, cable break is detected at output currents $< 200 \text{ mA}$. The cable break monitoring can be disabled.
GND V+	X13/3 X13/4		

Table 4.8 Specification of the terminal connections X13

NOTE:

For brakes with higher current requirements ($> 2.0 \text{ A}$), a relay must be provided. The cable break monitoring on X13 is then no longer usable and must be provided externally.

4.10 Specification of the Ethernet interface

The service and diagnostic interface X9 is designed as a TCP/IP Ethernet interface. It is suitable for connection of a PC for commissioning, service and diagnostics and for programming of the drive controller.

The following software can communicate with the drive controller via the Ethernet interface:

- DriveManager 5 for commissioning, service and diagnostics on the ServoOne junior
- CoDeSys 3.x programming system for programming the ServoOne junior in the languages of IEC 61131-3. For this purpose a drive controller licence is required.

Interface specification:

- Transfer rate 10/100 Mbits/s BASE
- Transmission profile IEEE802.3 compliant
- Connection via standard commercially available crosslink cable, CAT 5 (e.g. KEBA accessory CC-ECL03, see also ServoOne system catalogue)

4.11 Option 1

Depending on the ServoOne junior variant, Option 1 is factory-configured with various options. Field bus options such as EtherCAT or SERCOS are available.

You will find all available options in the ServoOne System Catalogue. The user manuals for the respective options provide detailed information on commissioning.

4.12 Option 2

Option 2 can be factory-configured with various technology options. Additional or special encoders can be evaluated here for example.

You will find all available options in the ServoOne System Catalogue. The user manuals for the respective options provide detailed information on commissioning.

4.13 Encoder connection

All encoder connections are located on the top of the unit.

Motor, encoder and cable allocation

Compare the rating plates of the components. Make absolutely sure you are using the correct components according to variant A, B or C!




Figure 4.23 Overview of motor, encoder and cable allocation



NOTE:

Do not cut the encoder cable, for example to route the signals via terminals in the switch cabinet. The knurled screws on the D-Sub connector housing must be tightly locked!


**NOTE:**

You will find the Order Catalogue (ID no: 0966.24B.x) and the latest information on our products on our website:

www.keba-lti.com in **Service > Downloads**


4.13.1 Resolver connection

A resolver is connected to slot X6 (9-pin D-Sub socket).

Figure	X6/pin	Function
	1	Sin+ / (S2) analogue differential input track A
	2	Refsin / (S4) analogue differential input track A
	3	Cos+ / (S1) analogue differential input track B
	4	Supply voltage 5 ... 12 V, internally connected to X7/3
	5	9+ (PTC, KTY, Klixon) internally connected to X7/10 ¹⁾
	6	Ref+ / (R1) analogue excitation
	7	Ref- / (R2) analogue excitation (ground reference point for pin 6 and pin 4)
	8	Refcos / (S3) analogue differential input track B
	9	9- (PTC, KTY, Klixon) internally connected to X7/9 ¹⁾

1) Be sure to pay attention to the note headed "ATTENTION" in !

Table 4.9 Pin assignment X6 resolver connection

CAUTION	Damage to the device due to incorrect insulation of the motor winding!
	<ul style="list-style-type: none"> • Carelessness can cause damage to the motor/device <p>The motor temperature sensor must, in relation to the motor winding, on connection to X5 be provided with basic insulation, on connection to X6 or X7 with reinforced insulation as per EN 61800-5-1.</p>

4.13.2 Connection for high-resolution encoders

The interface X7 makes possible the evaluation of the following encoder types.


Figure	Function
	SinCos encoder with zero pulse e.g. Heidenhain ERN1381, ROD486
	Heidenhain SinCos encoder with EnDat interface e.g. 13-bit singleturn encoder (ECN1313-EnDat01) and 25-bit multiturn encoder (EQN1325-EnDat01)
	Heidenhain encoder with digital EnDat interface Single or multiturn encoder (EQN1337-EnDat22)
	SinCos encoder with SSI interface e.g. 13-bit singleturn and 25-bit multiturn encoder (ECN413-SSI, EQN425-SSI)
	Sick-Stegmann SinCos encoder with HIPERFACE® interface Single and multiturn encoder, e.g. SRS50, SRM50

Table 4.10 Suitable encoder types on X7



NOTE:

- The usage of encoders not included in the range supplied by KEBA requires special approval by KEBA.
- The maximum signal input frequency is 500 kHz.
- Encoders with a power supply of 5 V ±5% must have a separate sensor cable connection. The sensor cable detects the actual supply voltage at the encoder; it is then possible to compensate for the voltage drop on the cable. Only by using the sensor cable is it ensured that the encoder is supplied with the correct voltage. The sensor cable must always be connected.

Select the cable type specified by the motor or encoder manufacturer. During this process bear in mind the following boundary conditions:

- Always used shielded cables. Connect the shield at both ends.
- Connect the differential track signals A/B, R or CLK, DATA using twisted pairs.
- Do not cut the encoder cable, for example to route the signals via terminals in the switch cabinet.

X7 pin	SinCos and TTL	SinCos absolute value encoder SSI/EnDat	Absolute value encoder EnDat (digital)	Absolute value encoder HIPERFACE®
1	A-	A-	-	REFCOS
2	A+	A+	-	+COS
3	+5 V DC ±5 %, IOUT max = 250 mA (150 mA for hardware versions 0..1), monitoring via sensor cable			7 to 12 V (typ. 11 V) max. 100 mA
4	R+	Data +	Data +	Data +
5	R-	Data -	Data -	Data -
6	B-	B-	-	REFSIN
7	-	-	-	U _s - switch
8	GND	GND	GND	GND
9	9- (PTC, KTY, Klixon) internally connected to X6/9 ¹⁾			
10	9+ (PTC, KTY, Klixon) internally connected to X6/5 ¹⁾			
11	B+	B+	-	+SIN
12	Sense +	Sense +	Sense +	U _s - switch
13	Sense -	Sense -	Sense -	-
14	-	CLK+	CLK+	-
15	-	CLK -	CLK -	-

¹⁾ It is imperative you pay attention to the note headed "ATTENTION" in Table 4.12!

Table 4.11 Pin assignment for the connector X7



NOTE:

The encoder supply on X7/3 is short circuit proof on both 5 V and 11 V operation. The controller remains in operation enabling the generation of a corresponding error message on evaluating the encoder signals.

The sum of the currents tapped at X7/3 and X6/4 must not exceed the specified value!

After connecting pin 7 to pin 12, a voltage of 11.8 V is set on X7, pin 3!


4.14 Motor connection

Step	Action	Comment
1.	Specify the cable cross-section depending on the maximum current and ambient temperature.	Cable cross-section according to local and country-specific regulations and conditions
2.	Connect the shielded motor cable to terminals X1/ U, V, W and connect the motor to earth at \oplus .	Connect the shield at both ends to reduce interference emissions.
3.	Wire the motor temperature sensor and activate temperature evaluation using DriveManager. See also related note.	Connect the shield at both ends to reduce interference emissions.

4.14.1 Motor temperature sensor

Connection SOJ	Type of sensor	Insulation
X5	Temperature switch (Klixon), PTC	Sensor with basic insulation
X6	Temperature switch (Klixon), PTC, KTY	Sensor with increased insulation
X7	Temperature switch (Klixon), PTC, KTY	Sensor with increased insulation

Table 4.12 Motor temperature sensor terminal configuration

CAUTION	Damage to the device due to incorrect insulation of the motor winding!
	<ul style="list-style-type: none"> Carelessness can cause damage to the motor/device <p>The motor temperature sensor must, in relation to the motor winding, on connection to X5 be provided with basic insulation, on connection to X6 or X7 with reinforced insulation as per EN 61800-5-1.</p>

i	NOTE:
	In the event of a short circuit or earth fault in the motor cable, the power stage is disabled and an error message is output.

4.14.2 Connection of LSH/LST motors

i	NOTE:
	For the connection of the servomotor product range LSH xxx and LST xxx, please use the ready made motor cable from the System Cables Order Catalogue.






Figure 4.24 Connection of the motor, BG2 Figure 4.25 Connection of the motor, BG5 to BG4

DC link: connection on BG2 to BG4 X1/L+, L- connection on BG5 X1.b/ L+, L-

CAUTION!	Damage to the device due to DC link coupling!
	<ul style="list-style-type: none"> Carelessness can cause damage to the device <p>Coupling together the DC links on several drive units is not allowed.</p>

4.14.3 Switching in the motor cable

CAUTION!	Damage to the device due to switching in the motor cable!
	<ul style="list-style-type: none"> • Carelessness can cause damage to the device <p>Switching in the motor cable must take place with the power switched off and the power stage disabled, as otherwise problems such as burned contactor contacts or power stage damage may occur.</p>

To ensure unpowered switch-on, you must make sure that the contacts on the motor contactor are closed before the drive controller power stage is enabled. At the moment the contactor is switched off it is necessary for the contact to remain closed until the drive controller power stage is shut down and the motor current is 0. This is achieved by using appropriate safety delays for the switching of the motor contactor in the control sequence for your machine.


**NOTE:**

Despite these measures, the possibility cannot be ruled out that the drive controller may malfunction during switching in the motor cable.

4.15 Brake chopper connection

In regenerative operation, e.g. when braking the drive, the motor feeds energy back to the drive controller. This increases the voltage in the DC link. If the voltage exceeds a threshold value, the internal braking transistor is activated and the regenerated power is converted into heat by means of a braking resistor.


4.15.1 Protection in case of brake chopper fault

WARNING!	Risk of injury due to hot surfaces caused by a faulty brake chopper!
	<ul style="list-style-type: none"> • Carelessness may result in serious burns or damage. <p>If the brake chopper is overloaded the internal brake chopper transistor may be switched on continuously, which will result in the overheating of the device and the braking resistor. Temperatures of up to 250 °C may be reached. To prevent more serious damage we recommend the activation of the following software function:</p> <p>You can activate this function by assigning BC_FAIL(56) to any digital output (DriveManager 5 ► "I/O configuration" ► Digital outputs ► OSD00 to OSD02). In the event of a fault the selected output then switches from 24 V to 0 V.</p> <p>With this signal it is to be ensured that the drive controller is safely disconnected from the mains supply.</p>

For detailed information on setting parameters refer to the "ServoOne device help".

4.15.2 Design with integrated braking resistor (BG3+4+5)

For drive controllers with an integrated braking resistor (**model SO2x.xxx.xxxx.1xxx**) only the peak braking power is stated in the appendix. The permissible continuous braking power must be calculated. It depends on the effective utilisation of the controller in the corresponding application.

CAUTION!	Damage to the device with integrated braking resistor due to connection of an ext. braking resistor!
	<ul style="list-style-type: none"> • Carelessness can cause damage to the device <p>No additional external braking resistor may be connected to drive controllers S022.006 to S024.016 with integrated braking resistor.</p>

The drive controller is thermally designed in such a way that no energy input by the internal braking resistor is permitted during continuous operation at rated current and at maximum ambient temperature.

Consequently, a controller design featuring an integrated braking resistor only makes sense when the effective drive controller utilisation is $\leq 80\%$ or the braking resistor is designed for one-off emergency stop. In the event of an emergency stop, only the thermal capacity of the braking resistor can be used for a one-off braking action. The permissible energy W_{IBr} can be taken from the following table.

Device	Technology	Rated resistance R_{BR}	Peak braking power P_{PBr}	Pulse energy W_{IBr}	K1 5)
S022.006	Wire resistance	100 Ω	1500 W 1)	150 Ws	120 W
S024.004		420 Ω	1000 W 2) 1300 W 3) 1400 W 4)	140 Ws	50 W
S022.008		90 Ω	1690 W 1)	6000 Ws	170 W
S024.007			4700 W 2) 6170 W 3) 6500 W 4)	6000 Ws	120 W
S024.012			4700 W 2) 6170 W 3) 6500 W 4)	6000 Ws	120 W
S024.016		90 Ω	4700 W 2) 6170 W 3) 6500 W 4)	6000 Ws	120 W

1) Data referred to 1 x 230 V AC mains voltage (BR switch-on threshold 390 V DC)

2) Data referred to 3 x 400 V AC mains voltage (BR switch-on threshold 650 V DC)

3) Data referred to 3 x 460 V AC mains voltage (BR switch-on threshold 745 V DC)

4) Data referred to 3 x 480 V AC mains voltage (BR switch-on threshold 765 V DC)

5) K1 = Factor for the calculation of the permissible continuous braking power, see next page

Table 4.13 Data of the integrated braking resistor (design S02x.xxx.xxx.1xxx)

If the drive is not permanently operated at its power limit, the reduced power dissipation of the drive can be used as braking power.



NOTE:

The rest of the calculation assumes that the drive controller is used at maximum permissible ambient temperature. This means that any additional energy input for the internal braking resistor due to a lower ambient temperature will be neglected.

Method to calculate the continuous braking power:

- Calculation of effective drive controller utilisation in a cycle T:

$$I_{eff} = \sqrt{\frac{1}{T} \int_0^T i^2 dt}$$

- Determination of permissible continuous braking power based on unused drive power:

$$P_{DBr} = \left(1 - \frac{I_{eff}}{I_N}\right) \times K1$$

Marginal conditions

- A single braking action must not exceed the maximum pulse energy of the braking resistor.

$$W_{IBr} \geq P_{PBr} \times T_{Br}$$

- The continuous braking power calculated for the device must be greater than the effective braking power for a device cycle.

$$P_{DBr} \geq \frac{1}{T} \times \int_0^T P_{PBr} dt_{Br}$$

This results in the minimum permissible cycle time T with calculated continuous braking power:

$$T = \frac{P_{PBr}}{P_{DBr}} \times \int_0^T dt_{Br}$$

The maximum total on-time of the braking resistor over a specified cycle time T with calculated continuous braking power is:

$$T_{BrSum} = \frac{P_{PBr}}{P_{DBr}} \times T$$

4.15.3 Connection of an external braking resistor



NOTE

- Be sure to follow the installation instructions for the external braking resistor.
- The temperature sensor (bimetallic switch) on the braking resistor must be wired in such a way that the power stage is deactivated and the connected drive controller is disconnected from the mains supply if the braking resistor overheats.
- The minimum permissible connection resistance of the drive controller must not be infringed, for technical data see appendix.
- The braking resistor must be connected using a shielded cable.








Figure 4.26 Connection of braking resistor

WARNING! 	Risk of injury due to hot surfaces on the ext. braking resistor! <ul style="list-style-type: none"> • Carelessness may result in serious burns. <p>The braking resistor heats up very significantly during operation and can reach temperatures of up to 250 °C. On touching there is a risk of serious burns to the skin.</p>
CAUTION 	Damage to the ext. braking resistor due to lack of temperature monitoring! <ul style="list-style-type: none"> • Carelessness can result in overheating of the ext. braking resistor! <p>The external braking resistor must be monitored by the controller. The temperature of the braking resistor is monitored by a temperature sensor (Klixon). In the event of overheating the drive controller must be disconnected from the mains supply.</p>

DANGER! 	Risk of injury due to electrical power! <ul style="list-style-type: none"> • Carelessness will result in serious injuries or death. <p>Never make or disconnect electrical connections while they are electrically live! Always disconnect the power before working on the device. Even 10 min. after switching off the mains supply, dangerously high voltages of ≥ 50 V may still be present (capacitor charge). So check that electrical power is not present!</p>
-------------------------------------------------------------------------------------------------------	-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

Available braking resistors (excerpt)

Article designation	Continuous braking power	Resistance ¹⁾	Peak braking power ²⁾	Protection	Figure
BR-090.01.540-UR	35 W	90 Ω	6250 W	IP54	
BR-090.02.540-UR	150 W		6250 W	IP54	
BR-090.03.540-UR	300 W		6250 W	IP54	
BR-090.10.650-UR	1000 W		6250 W	IP65	

1) Tolerance ±10%

2) Is the maximum possible braking power depending on the ON-time and cycle time

Table 4.14 Technical data - braking resistors





NOTE:

The available braking resistors with the exact specifications, in particular with regard to surface temperature, maximum supply voltage and high-voltage strength, are set out in the Installation Manual Braking Resistor and ServoOne System Catalogue. See "1.3 Reference documents"

5 Commissioning

5.1 Notes for operation

CAUTION	Damage to the device due to detrimental ambient conditions!
	The device may be irreparably damaged due to harmful ambient conditions during operation. For this reason <ul style="list-style-type: none">• Moisture must not be allowed to enter the device• There must not be any aggressive or conductive substance in the ambient air• Foreign bodies such as drilling chips, screws, washers etc. must not be allowed to fall into the device• The ventilation openings must not be covered
WARNING	Risk of injury due to hot surfaces on the device!
	<ul style="list-style-type: none">• Carelessness may result in burns. The device heats up during operation and the temperature on the heat sink may reach 100 °C. On touching there is a risk of burns to the skin.

5.2 Initial commissioning

Once the ServoOne junior has been installed as described in chapter 3 "Mechanical installation" and wired with all required power supplies and external components as described in chapter 4 "Installation", initial commissioning can be performed in the following sequence:

Step	Action	Comment
1.	Install and start PC software	See Installation Manual DriveManager 5
2.	Switch on control supply	See section 5.2.1
3.	Establish connection between PC and drive controller	See section 5.2.2
4.	Parameter configuration	See section 5.2.3
5.	Control drive using DriveManager 5	See section 5.2.4

Table 5.1 Initial commissioning steps table



NOTE:

Details on STO (Safe Torque Off) have not been taken into account for initial commissioning, see chapter "7 Safe Torque Off (STO)"

5.2.1 Switching on control supply

2. To initialise and set parameters initially only switch on the +24 V DC control supply. Do **not** yet switch on the AC mains supply.

Display indication after switching on the control supply



D1	D2	Action	Explanation
		Switch on the external +24 V DC control supply	Initialisation in progress
		Initialisation completed	Not ready to switch on

Table 5.2 Switch-on status of the ServoOne junior (with +24 V DC control supply)



NOTE:

You will find details on the control supply in chapter “4.8.1 Connection of control supply (+24 V DC)”

5.2.2 Establish connection between PC and drive controller

3. The PC can be connected to the drive controller via Ethernet (TCP/IP). Connect PC and drive controller with an Ethernet connection cable.



NOTE:

- Initialisation
The communication link between PC and drive controller can only be set up after the drive controller has completed its initialisation.
- TCP/IP configuration
If the PC does not detect the drive controller connected, please check the settings for the Ethernet interface (see Installation Manual DriveManager 5).

5.2.3 Parameter configuration

4. The initial commissioning wizard in DriveManager 5 is provided for making the settings for the drive system. Start the wizard.



NOTES:

- DriveManager help
A detailed description of DriveManager 5 as well as the initial commissioning wizard can be found in the DriveManager help.
- Motor dataset
When using KEBA servomotors the latest version of the required motor dataset can be downloaded from www.keba-lti.com, category "Downloads".

5.2.4 Controlling drive using DriveManager 5

5. Switch on the AC mains supply. Then enable the power stage and activate the control. The drive should be tested without the coupled mechanism.

DANGER!

Risk of injury due to rotating parts on the motor!



• Carelessness will result in serious injuries or death.

Before commissioning motors with feather keys in the end of the shaft, the keys must be reliably secured against throwing out, as far as this is not already prevented by drive elements such as belt pulleys, couplings or similar.

CAUTION!

Damage to the system/machine due to uncontrolled or inappropriate commissioning!



• Carelessness may result in damage to the system/machine.

- It is imperative attention is paid to the limitations of the movement range. You are responsible for a safe process. KEBA will not assume liability for any damage that occurs

Important information for the usage of motors!

- Certain motors are only intended for operation on the drive controller. Direct connection to the mains supply can cause irreparable damage to the motor.
- The motor surfaces may become extremely hot. No temperature sensitive parts may touch or be fastened to these areas, appropriate measures to prevent physical contact must be taken wherever necessary.
- The temperature sensor installed must be connected to the terminals of the temperature monitoring system for the drive controller also during the test run to avoid overheating of the motor.
- The motor holding brake (if installed) should be checked for correct function before commissioning the motor. Motor holding brakes are only designed for a limited number of emergency braking operations. Use as a service brake is not allowed.

Display indication after switching on the AC mains supply

D1	D2	Action	Reaction	Explanation
52		Switch on the AC mains supply	Controller ready, power stage ready, control deactivated	Device is ready to switch on

Table 5.3 Display D1/D2 after switching on the AC mains supply



NOTE:

- Inputs "ISDSH" and "ENPO"
For step 1 in Table 5.1 at least the two inputs "ISDSH" and "ENPO" on terminal X4 must be connected.
- Manual mode window
Step 2 in Table 5.1 is best undertaken via the "Manual mode" window in DriveManager 5, details can be found in DriveManager help.
- Configuration of the inputs/outputs
If step 2 is to be implemented via the inputs on terminal X4, the sources for "START CONTROL" and speed setpoint must be configured accordingly in "Inputs/Outputs" in DriveManager 5.

Power-up sequence for starting the drive




Figure 5.1 Power-up sequence

Display indication after starting the drive

D1	D2	Action	Reaction	Explanation
3		"STO" and power stage "ENPO" enabled	Ready to switch on	Power stage ready

Table 5.4 D1/D2 indication during activation of motor

CAUTION!	Damage to the device due to incorrect operation!
	<ul style="list-style-type: none"> • Carelessness may result in damage. Before the next step "Enable start" you must specify a plausible setpoint, because the pre-set setpoint is transferred to the drive directly after the motor control has started.

D1	D2	Action	Reaction	Explanation
5		"Start" enabled	Technology ready	Motor energised, control active

Table 5.5 D1/D2 indication during activation of motor

Details for optimising the drive on your application can be found in the DriveManager help and in the ServoOne device help.

5.3 Serial commissioning

An existing parameter data set can be transferred to other ServoOne junior drive controllers using DriveManager 5. Details can be found in the DriveManager help.

5.4 Integrated control unit

The built-in control unit permits diagnostics on the ServoOne junior. The control unit comprises the following elements, all located on the front of the device:

- 2-digit 7-segment display (D1, D2)
- 2 buttons (T1, T2)




Figure 5.2 Integrated control unit ServoOne junior

The following functions and displays are available:

- Indication of the device status (see chapter "6.1 Device states")
The device status is indicated after switching on the control supply. If no input is made via the keypad for 60 seconds, the display switches back to the indication of the device status.
- Indication of the device error status (see chapter "6.2 Error indication")
On the occurrence of an error in the device, the display is immediately switched to the indication of the error code.
- Parameter configuration (indication "PA") (see chapter 5.2.3)
Resetting device parameters to their factory setting
- Ethernet IP address configuration (indication "IP") (see chapter 5.4.4)
Ethernet IP address and subnet mask setting
- Field bus settings (indication "Fb") (see chapter 5.4.5)
E.g. field bus address setting

5.4.1 Function of buttons T1 and T2

These buttons are used to activate the different menus and to control the corresponding functions.

Button	Function	Comment
T1 (left)	<ul style="list-style-type: none"> • Activate the menu (exit the device status display) • Scroll through the menus/sub-menus • Set values - left segment display (D1) 	The button T1 can be held pressed for any length of time because the display will only scroll through the menu options for the corresponding level. No settings will be changed.
T2 (right)	<ul style="list-style-type: none"> • Selection of chosen menu • Set values - right segment display (D2) 	The button T2 must NOT be held pressed for any length of time because the display will change from one menu level to the next within the menu structure and then change the parameter that is reached at the end. You should therefore always release the button T2 after each change in display.
T1 and T2 together	<ul style="list-style-type: none"> • Menu level up • Accept selection • Acknowledge 	After pressing T1 and T2 at the same time, the value applied flashes for five seconds. During this time the save procedure can still be aborted by pressing any button, without applying the value set. Otherwise the new value will be saved after five seconds.
General		The time the button needs to be held depressed until an action is executed is approx. 1 second. If there is no action by the user for a period of 60 seconds, the display returns to the indication of the device status.

Table 5.6 Function of buttons T1 and T2

5.4.2 Display

The following table defines various indications and items of status information provided via the display.







Display	Meaning
	Menu entries ("PA" in this case serves as an example, for further possible entries see sections 5.4.4 and 5.4.5)
	[Flashing decimal points] Selected function in progress
	[Two dashes] Entry/function not available
	[OK] Action executed successfully, no errors
	[Error] Action via control unit not executed successfully, "Er" flashes alternately with the error number (see section 5.4.3) Device error indication, "Er" flashes alternately with error number and error location (see "ServoOne Application Manual")
	Numerical values ("10" in this case serves as an example) In the parameter menu (PA) error numbers are shown in decimal . All other values are displayed in hexadecimal . In these cases the 10 displayed would represent the decimal value 16.

Table 5.7 Meaning of display



NOTE:

If no input is made via the keyboard for a period of 60 s, the display returns to the indication of the device status.

5.4.3 Parameter menu (PA)

On the Parameter menu the device settings can be reset to the factory setting.

Menu level 1	Menu level 2	Parameter	Value range	Meaning	Explanation
PA	Pr	-	-	Parameter reset	Reset device settings to factory setting

Table 5.8 Parameter menu

Error numbers

A failed user action is indicated by an error message. The message consists of the alternating display of "Er" and the error number.



NOTE:

The error messages displayed during user data entry should not be confused with drive error messages. For detailed information on the error codes and on error management refer to the "ServoOne device help".

Error number	Meaning
01	File System Any file system error
02	File System command rejected
03	File System function parameter invalid
04	File System create file error
05	File System open file error
17	Parameter reset to factory settings failed
18	Parameter write access failed
19	Save parameter data set non volatile failed
20	Not all parameters written
21	Error while reset to factory settings

Table 5.9 Error numbers

5.4.4 Ethernet IP address menu (IP)

An Ethernet TCP/IP port is available as a service and diagnostics interface. The IP address is set by default to 192.168.39.5 and the subnet mask to 255.255.255.0. Both can be changed using the IP address menu.

Menu level 1	Menu level 2	Parameter	Value range	Meaning	Explanation
IP	lu	b0	00..FF	IP address update byte 0	Setting for byte 0 of the IP address in hexadecimal format (e.g. "05" in 192.168.39. 5)
		b1	00..FF	IP address update byte 1	Setting for byte 1 of the IP address in hexadecimal format (e.g. "27" for 192.168. 39 .5)
		b2	00..FF	IP address update byte 2	Setting for byte 2 of the IP address in hexadecimal format (e.g. "A8" for 192. 168 .39.5)
		b3	00..FF	IP address update byte 3	Setting for byte 3 of the IP address in hexadecimal format (e.g. "C0" at 192 .168.39.5)
	lr	-	-	IP reset to factory setting	Reset IP address to factory setting (192.168.39.5)
	Su	b0	00..FF	Subnet mask update byte 0	Setting for byte 0 of the subnet mask in hexadecimal format (e.g. "00" in 255.255.255. 0)
		b1	00..FF	Subnet mask update byte 1	Setting for byte 1 of the subnet mask in hexadecimal format (e.g. "FF" in 255.255. 255 .0)
		b2	00..FF	Subnet mask update byte 2	Setting for byte 2 of the subnet mask in hexadecimal format (e.g. "FF" in 255. 255 .255.0)
		b3	00..FF	Subnet mask update byte 3	Setting for byte 3 of the subnet mask in hexadecimal format (e.g. "FF" in 255 .255.255.0)
	Sr	-	-	Subnet mask reset to factory setting	Reset subnet mask to factory setting (255.255.255.0)

Table 5.10 IP address menu

Example configuration of the subnet mask

In this example the subnet mask is changed from 255.255.255.0 to 122.255.255.0.



NOTE:

- During the flashing phase the save procedure can still be aborted by pressing any button, without applying the value set. Otherwise the new value will be saved after five seconds.
- Changes to the IP address menu are only applied when the control electronics are subsequently restarted.




Figure 5.3 Example configuration of the subnet mask

5.4.5 Field bus address menu (Fb)

The functions available on this menu item depend on the device expansion module. For detailed information refer to the relevant specification.

Menu level		Parameter	Value range	Meaning	Explanation
1	2				
Fb	Ad	-	00..xx or - -	Field bus address	Setting for field bus address (only if field bus option used), otherwise indication "- _" (the maximum value that can be programmed depends on the option)
	Po	-	0..3 or - -	Transmit power	Setting for fibre-optic power output (only with SERCOS II option), otherwise indication "- -"

Table 5.11 Field bus address menu

Example configuration of the field bus address

In this example the field bus address is changed from 1 to 23.



NOTE:

Changes on the field bus address menu are only applied when the control electronics are subsequently restarted.













Figure 5.4 Example configuration of the field bus address



6 Diagnostics

The device states and error indications are shown on the device using the 7-segment display on the integrated control unit.

6.1 Device states

Display	System state
	Device in reset state
	Self-initialisation on device startup
	Not ready to switch on (no DC link voltage) ¹⁾
	Start inhibit (DC link OK, power stage not ready) ¹⁾
	Ready to switch on (power stage ready)
	Switched on (power applied to drive) ²⁾
	Drive ready (power applied to drive and drive ready for reference value input) ²⁾
	Quick stop ²⁾
	Error response active ²⁾

^{*)} Not a "safe indication" as specified in EN 61800-5-2.

¹⁾ S. flashes if the function STO (Safe Torque Off) is active, indication extinguishes if function is inactive.

²⁾ The point flashes if the power stage is active.

Table 6.1 Device states

6.2 Error indication

The specific error codes are indicated via the 7-segment display. Each error code comprises the alternating sequence ► "Er" ► error number ► error location.




Display	Meaning
	Device error
↓ Display changes after approx. 1 s	
	Error number (decimal) Example: 05 = Overcurrent
↓ Display changes after approx. 1 s	
	Error location (decimal) Example: 01 = Hardware monitoring
↑ Display changes back top ER after approx. 1 s	

Table 6.2 Indication of the error code



NOTE:

The errors can be reset in accordance with their programmed reaction (ER) or only via a +24 V reset (X2) (ER.). Errors marked with a point can only be reset once the cause of the error has been rectified.

6.3 Error codes



NOTE:

For detailed information on the error codes and on error management refer to the "ServoOne device help".

6.4 Status and error indication in DM5

Click the "Device status" button in the header for the DM5 to open the "Device status" window.




Figure 6.1 "Device status" button in the header

Use the "Error history..." button to retrieve information on the last 20 errors that have occurred.




Figure 6.2 "Device status" window

On the occurrence of an error, a "pop-up" window appears immediately with more detailed information on the actual error.




Figure 6.3 Error message

The **parameter 31** "Alarms & Warnings (Details)" contains detailed information on an error or warning that has occurred.

1. In the "Project" window, select in the project tree "Drive Settings"
2. Then, in the project tree that opens, double-click the lowest level "Alarm & warning details".




Figure 6.4 Parameter 31 "Alarms & Warnings (Details)"



NOTE:

You will find further information on parameter 31 in the ServoOne junior device help (article no.: 0842.26B.x).

7 Safe Torque Off (STO)



NOTE:

You will find all information on the "STO" function in the 24-language document "Description of the STO Safety Function" (ID no. 1100.10B.x).

Space for your own notes

A Appendix

A.1 Current carrying capacity of the servocontrollers

The maximum permissible drive controller output current and the peak current are dependent on the mains voltage, the motor cable length, the power stage switching frequency and the ambient temperature. If the conditions change, the maximum permissible servocontroller current carrying capacity also changes.

ServoOne junior for 1/3 x 230 V

Device	Switching frequency of the power stage [kHz]	Ambient temperature max. [°C]	Rated current I_N [A _{eff}]	Overload capacity 1 x 230 V AC				Overload capacity 3 x 230 V AC			
				Overcurrent		Peak current		Overcurrent		Peak current	
				[A _{eff}]	For time [s]	[A _{eff}]	For time [s]	[A _{eff}]	For time [s]	[A _{eff}]	For time [s]
S022.003	4	45	3.0	6.0	10 ²⁾	9.0	0.08 ²⁾	6.0	10	9.0	0.08 ²⁾
	8	40	3.0	6.0	10 ²⁾	6.0 (9.0) ¹⁾	0.08 ²⁾	6.0	10	6.0 (9.0) ¹⁾	0.08 ²⁾
	16	40	2.0	4.0	10 ²⁾	4.0 (9.0) ¹⁾	0.08 ²⁾	4.0	10	4.0 (9.0) ¹⁾	0.08 ²⁾
S022.006	4	45	5.9	11.8	10 ²⁾	3)	3)	11.8	10	17.7	0.08 ²⁾
	8	40	5.9	11.8	10 ²⁾	3)	3)	11.8	10	11.8 (17.7) ¹⁾	0.08 ²⁾
	16	40	5.9	11.8	10 ²⁾	3)	3)	11.8	10	11.8 (17.7) ¹⁾	0.08 ²⁾
S022.008	4	45	8.0	16.0	10 ²⁾	3)	3)	16.0	10	24.0	0.08 ²⁾
	8	40	8.0	16.0	10 ²⁾	3)	3)	16.0	10	16.0 (24.0) ¹⁾	0.08 ²⁾
	16	40	5.4	10.8	10 ²⁾	3)	3)	10.8	10	10.8 (24.0) ¹⁾	0.08 ²⁾

1) With activation of the function "Automatic power stage switching frequency change to 4 kHz".

2) Shutdown as per I²T characteristic

3) Operation at this operating point is not possible

Data apply for a motor cable length ≤ 10 m. Maximum permissible motor cable length 30 m. All current ratings with recommended mains choke.

Table A.1 Rated current and peak current, BG2 to BG4 (1/3 x 230 V AC)

ServoOne junior for 400 / 460 / 480 V

Device	Power stage switching frequency [kHz]	Ambient temperature max. [°C]	Overload capacity 400 V AC					Overload capacity 460 V AC					Overload capacity 480 V AC				
			Rated current	Overcurrent		Peak current		Rated current	Overcurrent		Peak current		Rated current	Overcurrent		Peak current	
			I_N [A _{eff}]	[A _{eff}]	For time [s]	[A _{eff}]	For time [s]	I_N [A _{eff}]	[A _{eff}]	For time [s]	[A _{eff}]	For time [s]	I_N [A _{eff}]	[A _{eff}]	For time [s]	[A _{eff}]	For time [s]
S024.002	4	45	2.0	4.0	10 ²⁾	6.0	0.08 ²⁾	2.0	4.0	10 ²⁾	6.0	0.08 ²⁾	2.0	4.0	10 ²⁾	6.0	0.08 ²⁾
	8	40	2.0	4.0	10 ²⁾	4.0 (6.0) ¹⁾	0.08 ²⁾	2.0	4.0	10 ²⁾	4.0 (6.0) ¹⁾	0.08 ²⁾	1.7	3.4	10 ²⁾	3.4 (6.0) ¹⁾	0.08 ²⁾
	16	40	0.7	1.4	10 ²⁾	1.4 (6.0) ¹⁾	0.08 ²⁾	0.7	1.4	10 ²⁾	1.4 (6.0) ¹⁾	0.08 ²⁾	³⁾	³⁾	10 ²⁾	³⁾	0.08 ²⁾
S024.004	4	45	5.5	7.1	10 ²⁾	10.5	0.08 ²⁾	4.8	6.2	10 ²⁾	9.2	0.08 ²⁾	4.6	6.0	10 ²⁾	8.8	0.08 ²⁾
	8	40	3.5	7.0	10 ²⁾	7.0 (10.5) ¹⁾	0.08 ²⁾	3.5	6.2	10 ²⁾	6.2 (9.2) ¹⁾	0.08 ²⁾	2.6	5.2	10 ²⁾	5.2 (8.8) ¹⁾	0.08 ²⁾
	16	40	2.9	5.8	10 ²⁾	5.8 (10.5) ¹⁾	0.08 ²⁾	2.2	4.4	10 ²⁾	4.4 (9.2) ¹⁾	0.08 ²⁾	³⁾	³⁾	10 ²⁾	³⁾	0.08 ²⁾
S024.007	4	45	8.5	13.0	10 ²⁾	19.5	0.08 ²⁾	7.4	11.8	10 ²⁾	17.0	0.08 ²⁾	7.0	10.7	10 ²⁾	16	0.08 ²⁾
	8	40	6.5	13.0	10 ²⁾	13.0 (19.5) ¹⁾	0.08 ²⁾	6.5	11.8	10 ²⁾	11.8 (17.0) ¹⁾	0.08 ²⁾	6.5	10.7	10 ²⁾	16	0.08 ²⁾
	16	40	4.0	8.0	10 ²⁾	8.0 (19.5) ¹⁾	0.08 ²⁾	2.4	4.8	10 ²⁾	4.8 (17.0) ¹⁾	0.08 ²⁾	1.9	3.8	10 ²⁾	3.8 (16) ¹⁾	0.08 ²⁾

1) With activation of the function "Automatic power stage switching frequency change to 4 kHz".

2) Shutdown as per I²t characteristic

3) Operation at this operating point is not possible

Data apply for a motor cable length ≤ 10 m. Maximum permissible motor cable length 30 m.

Table A.2 Rated current and peak current, BG2 to BG5 (400 / 460 / 480 V AC)

Device	Power stage switching frequency [kHz]	Ambient temperature max. [°C]	Overload capacity 400 V AC					Overload capacity 460 V AC					Overload capacity 480 V AC				
			Rated current I_N [A _{eff}]	Overcurrent		Peak current		Rated current I_N [A _{eff}]	Overcurrent		Peak current		Rated current I_N [A _{eff}]	Overcurrent		Peak current	
				[A _{eff}]	For time [s]	[A _{eff}]	For time [s]		[A _{eff}]	For time [s]	[A _{eff}]	For time [s]		[A _{eff}]	For time [s]	[A _{eff}]	For time [s]
S024.012	4	40	13	26	10 ²⁾	39	0.10 ²⁾	11.5	23	10 ²⁾	34.5	0.10 ²⁾	11	22	10 ²⁾	33	0.10 ²⁾
	8	40	12	24	10 ²⁾	28.8 (39) ¹⁾	0.10 ²⁾	10.5	21	10 ²⁾	25.2 (34.5) ¹⁾	0.10 ²⁾	10	20	10 ²⁾	24 (33) ¹⁾	0.10 ²⁾
	16	40	10.5	15.8	10 ²⁾	16.8 (39) ¹⁾	0.10 ²⁾	8.0	12	10 ²⁾	12.8 (34.5) ¹⁾	0.10 ²⁾	7.5	11.3	10 ²⁾	12 (33) ¹⁾	0.10 ²⁾
S024.016	4	40	20	40	10 ²⁾	60	0.10 ²⁾	20	40	10 ²⁾	60	0.10 ²⁾	20	40	10 ²⁾	60	0.10 ²⁾
	8	40	16	32	10 ²⁾	33.6 (60) ¹⁾	0.10 ²⁾	15	30	10 ²⁾	31.5 (60) ¹⁾	0.10 ²⁾	14	28	10 ²⁾	29.4 (60) ¹⁾	0.10 ²⁾
	16	40	9	14.4	10 ²⁾	15.3 (60) ¹⁾	0.10 ²⁾	6.5	10.4	10 ²⁾	11 (60) ¹⁾	0.10 ²⁾	6	9.6	10 ²⁾	10.2 (60) ¹⁾	0.10 ²⁾

1) With activation of the function "Automatic power stage switching frequency change to 4 kHz".

2) Shutdown as per I²t characteristic

3) Operation at this operating point is not possible

Data apply for a motor cable length ≤ 10 m. Maximum permissible motor cable length 30 m.

Table A.2 Rated current and peak current, BG2 to BG5 (400 / 460 / 480 V AC)

A.2 Technical data, ServoOne junior

SO22.003, SO22.006 and SO22.008

Designation	S022.003	S022.006	S022.008	
Technical data				
Output, motor side				
Voltage	3-phase U _{Mains}			
Continuous current, effective (I _N)	3 A ^{1) 2)}	5.9 A ^{1) 2)}	8 A ^{1) 2)}	
Peak current (2 x I _N / 3 x I _N)	See Table A.1			
Rotating field frequency	0 ... 400 Hz			
Switching frequency of the power stage	4, 8, 16 kHz			
Input, mains side				
Mains voltage	(1 x 230 V AC / 3 x 230 V AC) -20%/+15%			
Device connected load (with mains choke)	1.3 kVA ¹⁾	2.6 kVA ¹⁾	3.5 kVA ¹⁾	
Current consumption (with mains choke)	1 x 230 V AC	5.4 A	10.6 A	14.4 A
	3 x 230 V AC	3.3 A	6.5 A	8.8 A
Asymmetry of the mains voltage	±3% max.			
Permissible mains frequency	50/60 Hz ±10%			
Power dissipation at I _N	75 W ¹⁾	150 W ¹⁾	200 W ¹⁾	

1) Values refer to mains voltage 230 V AC and switching frequency of 8 kHz,

2) For rated current, pay attention to Table A.1!

3) On design with integrated braking resistor (SO2x.xxx.xxxx.1xxx). Connection of an external braking resistor is not permitted.

4) Braking resistor always integrated. Connection of an external resistor is permitted.

Table A.3 Technical data, SO22.003, SO22.006 and SO22.008

Designation	S022.003	S022.006	S022.008
Technical data			
DC link			
Brake chopper switch-on threshold	390 V DC ¹⁾		
DC link capacitance	880 µF	1320 µF	1760 µF
Minimum ohmic resistance of an externally installed braking resistor	72 Ω ⁴⁾	72 Ω ³⁾	72 Ω ³⁾
Brake chopper continuous power with external braking resistor	2.1 kW		
Brake chopper peak power with external braking resistor	2.1 kW		
Internal braking resistor	550 Ω (PTC) ⁴⁾	100 Ω ³⁾	90 Ω ³⁾
Brake chopper continuous power with internal braking resistor	0 W	Dependent on the effective utilisation of the controller in the specific application see chapter 3.15.2	
Brake chopper peak power with internal braking resistor	400 W	1500 W	1700 W

1) Values refer to mains voltage 230 V AC and switching frequency of 8 kHz,

2) For rated current, pay attention to Table A.1!

3) On design with integrated braking resistor (SO2x.xxx.xxxx.1xxx). Connection of an external braking resistor is not permitted.

4) Braking resistor always integrated. Connection of an external resistor is permitted.

Table A.3 Technical data, SO22.003, SO22.006 and SO22.008



NOTE:

You will find more information on the brake chopper switch-on threshold in chapter "4.15 Brake chopper connection"

SO24.002 to SO24.016

Designation	S024.002	S024.004	S024.007	S024.012	S024.016
Technical data					
Output motor side ¹⁾					
Voltage	3-phase U _{Mains}				
Continuous current, effective (I _N)	2 A ^{1) 2)}	3.5 A ^{1) 2)}	6.5 A ^{1) 2)}	12 A ^{1) 2)}	16 A ^{1) 2)}
Peak current (2 x I _N / 3 x I _N)	See Table A.2				
Rotating field frequency	0 ... 400 Hz				
Switching frequency of the power stage	4, 8, 16 kHz				
Input, mains side					
Mains voltage	(3 x 400 V AC / 3 x 460 V AC / 3 x 480 V AC) ±10%				
Device connected load (with mains choke)	1.5 kVA ¹⁾	2.7 kVA ¹⁾	5.0 kVA ¹⁾	9.1kVA ¹⁾	12.2kVA ¹⁾
Current consumption (with mains choke)	2.2 A ¹⁾	3.9 A ¹⁾	7.2 A ¹⁾	13.5 A ¹⁾	16.8 A ¹⁾
Asymmetry of the mains voltage	±3% max.				
Frequency	50/60 Hz ±10%				
Power dissipation at I _N	42 W ¹⁾	80 W ¹⁾	150 W ¹⁾	263 W ¹⁾	316 W ¹⁾

1) Data referred to mains voltage 400 V AC and switching frequency 8 kHz,

2) For rated current, Table A.2!

3) On design with integrated braking resistor (S02x.xxx.xxxx.1xxx). Connection of an external braking resistor is not permitted.

4) Braking resistor always integrated. Connection of an external resistor is permitted.

5) On design BG5 with integrated braking resistor (S02x.xxx.xxxx.1xxx). Connection of an external braking resistor is only permitted if int. braking resistor is disconnected. Parallel operation of both resistors is not permitted!

Table A.4 Technical data, S024.002 to S024.016

Designation	S024.002	S024.004	S024.007	S024.012	S024.016
Technical data					
DC link					
Brake chopper switch-on threshold	650 V DC ¹⁾				
DC link capacitance	220 μ F	330 μ F	440 μ F	680 μ F	1120 μ F
Minimum ohmic resistance of an externally installed braking resistor	230 Ω	180 Ω ³⁾	72 Ω ³⁾	35 Ω ³⁾	25 Ω ³⁾
Brake chopper continuous power with external braking resistor	1.8 kW	2.3 kW	5.9 kW	12 kW	16.9 kW
Brake chopper peak power with external braking resistor	1.8 kW	2.3 kW	5.9 kW	12.1 kW	16.9 kW
Internal braking resistor	7500 Ω (PTC) ⁴⁾	420 Ω ³⁾	90 Ω ³⁾	90 Ω ⁵⁾	90 Ω ⁵⁾
Brake chopper continuous power with internal braking resistor	0 W	Dependent on the effective utilisation of the controller in the specific application see chapter 3.15.2			
Brake chopper peak power with internal braking resistor	200 W ¹⁾	1000 W ¹⁾	4700 W ¹⁾	4700 W ¹⁾	4700 W ¹⁾

1) Data referred to mains voltage 400 V AC and switching frequency 8 kHz,

2) For rated current, Table A.2!

3) On design with integrated braking resistor (S02x.xxx.xxxx.1xxx). Connection of an external braking resistor is not permitted.

4) Braking resistor always integrated. Connection of an external resistor is permitted.

5) On design BG5 with integrated braking resistor (S02x.xxx.xxxx.1xxx). Connection of an external braking resistor is only permitted if int. braking resistor is disconnected. Parallel operation of both resistors is not permitted!

Table A.4 Technical data, S024.002 to S024.016


NOTE:

You will find more information on the brake chopper switch-on threshold in chapter "4.15 Brake chopper connection".

A.3 Power connections

Feature	BG2	BG3	BG4	BG5
Cable cross-section (flexible with ferrule) [mm ²]	0.25 - 2.5	0.25 - 2.5	0.25 - 4 *)	0.25 - 4 *)
Tightening torque [Nm]	Not specified	0.5	0.7	0.7

*) For ferrule without plastic sleeve up to 6 mm² possible

Table A.5 Technical data, terminals for motor cable BG1 to BG5

A.4 Current required for the control supply

Housing variant	Size	Continuous current [A]
Air cooling	BG2	0.4 ¹⁾
	BG3	0.5 ¹⁾
	BG4	0.5 ¹⁾
	BG5	0.6 ¹⁾

¹⁾ Pay attention to supply voltage 24 V basic device not including options fitted, Table 4.5 on page 27

Table A.6 Current required for the control supply

A.5 Ambient conditions

Ambient conditions	ServoOne junior
Protection	IP20 with the exception of the heat sink fan in the S024.0XX BG5 (IP10) and the terminals (IP00)
Accident prevention regulations	As per the local regulations (in Germany e.g. BGV V3)
Installation altitude	Up to 1000 m above MSL, over 1000 m above MSL with power reduction (1 % per 100 m, max. 2000 m above sea level)
Pollution degree	2
Type of mounting	Built-in unit, only for vertical mounting in a switch cabinet with min. IP4x protection, on using STO safety function min. IP54

Table A.7 Ambient conditions, ServoOne junior

Climatic conditions	ServoOne junior
In transit	As per EN 61800-2, IEC 60721-3-2 class 2K3 ¹⁾
	Temperature -25 °C to +70 °C
	Relative atmospheric humidity 95% at max. +40 °C
In storage	As per EN 61800-2, IEC 60721-3-1 class 1K3 and 1K4 ²⁾
	Temperature -25 °C to +55 °C
	Relative atmospheric humidity 5 to 95%

¹⁾ The absolute humidity is limited to max. 60 g/m³. This means, at 70 °C for example, that the relative atmospheric humidity may only be max. 40%.

²⁾ The absolute humidity is limited to max. 29 g/m³. So the maximum values for temperature and relative atmospheric humidity stipulated in the table must not occur simultaneously.

³⁾ The absolute humidity is limited to max. 25 g/m³. That means that the maximum values for temperature and relative atmospheric humidity stipulated in the table must not occur simultaneously.

Table A.8 Climatic conditions, ServoOne junior

Climatic conditions		ServoOne junior
In operation		As per EN 61800-2, IEC 60721-3-3 class 3K3 ³⁾
	Temperature	-10 °C to +45 °C (4 kHz), up to 55 °C with power reduction (2%/°C) -10 °C to +40 °C (8, 16 kHz), up to 55 °C with power reduction (2%/°C)
	Relative atmospheric humidity	5 to 85 % without condensation

1) The absolute humidity is limited to max. 60 g/m³. This means, at 70 °C for example, that the relative atmospheric humidity may only be max. 40%.

2) The absolute humidity is limited to max. 29 g/m³. So the maximum values for temperature and relative atmospheric humidity stipulated in the table must not occur simultaneously.


3) The absolute humidity is limited to max. 25 g/m³. That means that the maximum values for temperature and relative atmospheric humidity stipulated in the table must not occur simultaneously.

Table A.8 Climatic conditions, ServoOne junior

Mechanical conditions		ServoOne junior		
Vibration limit in transit		As per EN 61800-2, IEC 60721-3-2 class 2M1		
		Frequency [Hz]	Amplitude [mm]	Acceleration [m/s²]
	2 ≤ f < 9		3.5	Not applicable
	9 ≤ f < 200		Not applicable	10
	200 ≤ f < 500		Not applicable	15
Shock limit in transit		As per EN 61800-2, IEC 60721-3-2 class 2M1		
		Drop height of packed device max. 0.25 m		
Vibration limits for the system ¹⁾		As per EN 61800-2, IEC 60721-3-3 class 3M1		
		Frequency [Hz]	Amplitude [mm]	Acceleration [m/s²]
	2 ≤ f < 9		0.3	Not applicable
	9 ≤ f < 200		Not applicable	1

1) Note: The devices are only designed for stationary use.

Table A.9 Mechanical conditions, ServoOne junior

CAUTION!	Damage to the device due to incorrect operation!
	<ul style="list-style-type: none"> • Failure to observe the ambient conditions may result in damage. • No continuous vibration! The drive controllers must not be installed in areas where they would be permanently exposed to vibration. • Switch cabinet min. IP54 for STO! According to EN ISO 13849-2 the switch cabinet must have IP54 protection or higher on using the STO (Safe Torque OFF) safety function. • Observe cooling conditions! Forced cooling by external air flow necessary. Air must be able to flow unhindered through the device (air flow at least 1.2 m/s). If a temperature cut-out occurs, the cooling conditions must be improved

A.6 UL certification

You will find the description of all measures to maintain UL approval in the document "UL-Certification" (ID no.: 0927.21B.x-xx).

Glossary

Symbols

7-segment display 18, 19, 20, 21, 53

A

Air cooling 64
Ambient conditions 13, 29, 65

B

Backing plate 13
Brake chopper 38, 63, 64
Braking resistor 38, 39, 40, 62, 63
 Continuous braking power 38, 39, 41
 Peak braking power 38, 39, 41, 63, 64
Button 18, 19, 20, 21, 47

C

Cable
 Cable cross-section 28, 37
 Cable length 28, 59, 60
 Cable type 17, 31, 36
 Motor cable 64
 Routing of cables 17
Capacitor charging 9, 17, 28, 40
Clearance and clearances and creepages 29
Climatic conditions 65
CoDeSys 33
Commissioning 30, 31, 33, 34, 43, 45
Connection diagram 20, 21
Connections 64
Control 45, 46

Control connections / control terminals 18, 19, 20, 21, 25, 31
Control supply 18, 19, 20, 21, 24, 26, 27, 28, 33, 44, 47, 64
Control unit 46, 48, 53
 Button 46
Cooling
 Cooling air 13
 Cooling conditions 13, 65
 Heat sink 43

D

Date of manufacture 7
Design variants 33
Device error 47, 48, 53
Device power connection 62, 63
Device setting 31, 48
Diagnostics 32, 33, 46, 53
Dimensions 14
Display 28, 48
DriveManager 27, 33, 37, 44, 45

E

Earthing measures 17
Electrical installation 13, 17, 22
Electrical isolation concept 26, 27
EMC
 Effective EMC installation 13, 22
EN 61000 29
EN 61800 17, 26, 27, 28, 29, 35, 37, 53, 65
Encoder
 Encoder cable 34
 Encoder connection 34
 EnDat 36
 High-resolution encoder 18, 19, 36
 HIPERFACE® 36
 SinCos 36
 SSI 36

EN ISO 13849	13, 65
ENPO	31, 32, 45
Error code	47, 48, 53
Error message DM5	54
Error number	48
Ethernet interface	18, 19, 20, 21, 33

F

Field bus	
Field bus address	47, 51
Field bus settings	47
Filter	
Mains filter	13, 22, 24, 28
RFI filter	22

H

H1 (indicator LED)	17, 18, 28
--------------------------	------------

I

IEC 60721	65
IEC 60755	28
IEC 61131	33
IEC 61800	22, 29
Industrial area	22
Init	44
Initial commissioning	43
Intended use	10
Interference immunity	22
IP address menu	47, 49
ISDSH	32
IT system	29

L

Layout	18, 19
Leakage current	26

M

Mains choke	29
Mains supply	28, 45
Connected load	29
Mains connection	18, 19, 24, 26
Mains fuses	28, 29
Measures for your safety	9
Mechanical conditions	65
Mechanical installation	13
Minimum clearance	15
Motor	
LSH motor	37
LST motor	37
Motor brake	18, 19, 20, 21, 33, 45
Motor cable	23
Motor connection	37
Motor dataset	44
Motor temperature monitoring	18, 19, 20, 21
Motor temperature sensor	37
Klixon	35, 40
KTY	35
PTC	63, 64

N

Notes for operation	13
---------------------------	----

O

Option 1	18, 19, 20, 21, 33
Option 2	18, 19, 20, 21, 34
Order code	6
Overvoltage category	29

P

Parameter configuration	47
Pollution degree	13, 65

Power connection	18
Power stage	32, 37, 38, 40, 45, 53, 62, 63
Protection.....	13, 41, 65
Protective earth conductor	26
Protective earth conductor connection.....	18, 19, 26
Protective extra low voltage (PELV)	26

R

Rated current	59, 60
Rating plate	7
Residential area.....	22
Residual current device	28
Residual current device (RCD).....	28
Resolver	35
Resolver connection.....	18, 19, 35
Responsibility.....	11

S

Safety	
Safety function	57
Safety extra low voltage (SELV)	26
Safety function	13, 45, 65
Scope of supply	7
Scope of the user manual	5
Serial number.....	7
Shield connection plate	23, 24
Shielding measures.....	17
Specimen setup	22
Star point	29
Starting current	28
STO.....	57
Stop categories	
Stop category 0 (STO)	13, 31–32, 53, 65
STO (Safe Torque OFF)	
ISDSH	45
STO	45

Subnet mask.....	47, 49, 50
Supply voltage	27
Support & Service.....	8
Switch cabinet	13, 26, 34, 36, 65
Switching frequency.....	27, 62, 63
Switching frequency change	59, 60
Switching in the motor cable	38
Switching on sequence.....	45

T

Technical data	29, 40, 62
Temperature evaluation	37
Tightening torque	64
TN system	29
TT system	29

U

UL certification	66
------------------------	----

W

Wall mounting	13
---------------------	----

X

X1	18, 20, 21, 23, 28, 37
X2	17, 18, 19, 20, 21, 24, 27, 28, 53
X3	18, 19, 20, 21, 24, 28
X4	18, 19, 20, 21, 25, 31, 32
X5	18, 19, 20, 21, 35, 37
X6	18, 19, 20, 21, 35, 37
X7	18, 19, 20, 21, 35, 36, 37
X8	18, 19, 20, 21
X9	18, 19, 20, 21, 33
X13.....	18, 19, 20, 21, 33

Fit for the future with bundled competencies

KEBA AG is an internationally successful electronics business based in Linz/Austria with subsidiaries worldwide. Based on the motto „Automation by innovation.“ KEBA has for 50 years developed and manufactured innovative automation solutions of the highest quality for a very wide range of sectors

www.keba-lti.com

KEBA Industrial Automation Germany GmbH

Gewerbestraße 5-9, 35633 Lahnau/Germany
telephone: +49 6441 966-0, fax: +49 6441 966-137, info@keba.de

KEBA AG Headquarters, Gewerbepark Urfahr, 4041 Linz/Austria,
telephone: +43 732 7090-0, fax: +43 732 730910, keba@keba.com

KEBA Group worldwide

China • Germany • India • Italy • Japan • Netherlands
Austria • Romania • Switzerland • South Korea • Taiwan
Czech Republic • Turkey • USA

Copyright © 2020 KEBA All rights reserved.

All content of the documentation, in particular the text, photographs and graphics it contains are protected by copyright. The copyright lies, unless otherwise expressly stated, with KEBA Industrial Automation Germany GmbH.