



## Quick Guide – How to Connect MacTalk® via Ethernet

If you have no information about your motors IP address, first connect via a COM port and note the current IP address – or click <Set module factory defaults>:




Click on the interface roll-down menu and you will see this:




-then choose the LAN port. But as can be seen the IP address of the PC/LAN is totally wrong for connection to the motor. But after choosing the LAN/Ethernet you will get a new Tool Button:




Click the button and a Network Card Settings window will pop up:



Disable DHCP and click on <JVL Default>



-and you will get:



Click <OK>.

Previously we saw that the motor IP address was: 192.168.0.116 – so specify this address.

*Now you have successfully connected to your motor via Ethernet !*

