


MIS231, MIS232 and MIS234

**Integrated Step Motors,
QuickStep,
and Step Motor Controller
SMC75**

User Manual



JVL Industri Elektronik A/S

Important User Information



Warning



The MIS and SMC series of products are used to control electrical and mechanical components of motion control systems. You should test your motion system for safety under all potential conditions. Failure to do so can result in damage to equipment and/or serious injury to personnel.

Please contact your nearest JVL representative in case of technical assistance. Your nearest contact can be found on our web site www.jvl.dk

Copyright 1998-2008, JVL Industri Elektronik A/S. All rights reserved.
This user manual must not be reproduced in any form without prior written permission of JVL Industri Elektronik A/S.
JVL Industri Elektronik A/S reserves the right to make changes to information contained in this manual without prior notice.
Similarly JVL Industri Elektronik A/S assumes no liability for printing errors or other omissions or discrepancies in this user manual.

MacTalk and MotoWare are registered trademarks

JVL Industri Elektronik A/S
Blokken 42
DK-3460 Birkerød
Denmark
Tlf. +45 45 82 44 40
Fax. +45 45 82 55 50
e-mail: jvl@jvl.dk
Internet: <http://www.jvl.dk>

Contents

I	Introduction	5
1.1	Features pulse/direction (SMD73)	6
1.2	Features positioning - speed control (SMC75)	8
1.3	General description	10
1.4	Step Motor Controller SMC75	11
1.5	SMC75 Controller connections	12
2	Connections SMC75	15
2.1	Power Supply SMC75	17
2.2	SMC75 Inputs	20
2.3	SMC75 User Inputs	21
2.4	SMC75 Analogue Inputs	24
2.5	SMC75 User Outputs	28
2.6	SMC75 Special Outputs	30
2.7	Auto Correction	32
2.8	SMC75 Connection of motor	33
2.9	Handling noise in cables	36
2.10	Quick Start (SMC75AIMxAA)	38
3	Serial Interface	39
4	RS485 Interface	41
5	Using MacTalk	43
5.1	Using the MacTalk software	44
6	Adjustment of motor phase current	51
7	Modes	53
7.1	Passive Mode	54
7.2	Velocity Mode	55
7.3	Positioning Mode	56
7.4	Gear Mode	57
7.5	Zero search modes	58
8	Error Handling	63
9	Registers	65
9.1	Introduction and register overview	67
9.2	Register Descriptions	71
10	Programming	93
10.1	Getting started with programming	94
10.2	Programming Main window	95
10.3	Programming menu	96
10.4	How to build a program	97
10.5	General programming hints	100
10.6	Command toolbox description	101
10.7	Graphic programming command reference	102
11	CANopen Introduction	121
11.1	General information about CANopen	122
11.2	Connection and setup of the CAN bus	126
11.3	Using CanOpenExplorer	130

11.4	Objects in the DS301 standard	135
11.5	Objects used in the DSP-402 standard	141
11.6	More details of CANOpen Theory	148
12	Appendix	159
12.1	Velocity accuracy	160
12.2	Command timing	161
12.3	More about program timing	162
12.4	Motor Connections	163
12.5	Serial communication	165
12.6	MIS Ordering Information	170
12.7	SMC75 Ordering Information	171
13	MIS Motor Technical Data	173
13.1	SMC75 Technical Data	174
13.2	Torque Curves	175
13.3	Physical Dimensions	176
13.4	Trouble-shooting guide	177
14	Connection to other Equipment	179
14.1	Connecting SMI30/SMC35 to MIS/SMC75	180
14.2	Connecting SMC75 to SMD73	181
14.3	Connecting SMC75 to SMD41	182
14.4	Connecting SMC75 to MAC00BI/B4	183
14.5	Connection to PLC/PC Boards	184
15	Accessories	185
15.1	Cables	186
15.2	Power Supplies	187
15.3	Brakes and shaft reinforcement	188
16	CE Declaration of Conformity	189

1

Introduction

This user manual describes the set-up and use of the **Integrated step motors, Quick-Step types MIS231, MIS232 and MIS234** and the **SMC75 Step Motor Controller**.

The QuickStep motors types MIS231, 232 and 234 can be delivered either for pulse /direction control or for positioning and speed control.

For pulse/direction control, the QuickStep motors are delivered with the **Step Motor Driver SMD73** built in. For further information on this driver, reference should be made to the data-sheet for these drivers (LD0057) and the Technical Note (LS0003).

For positioning and speed control, the Quick Step motors are delivered with **Step Motor Controller SMC75** built in.

Both the driver SMD73 and the controller SMC75 can also be delivered separately as PCB boards for own use by the customer, and can be delivered in a metal housing with M12 connectors corresponding to the housing built together with the complete integrated motor.



Complete QuickStep motor with SMC75 built-in



SMD73 PCB



QuickStep motor with SMD73



SMC75 PCB



SMC75 in housing

1.1 Features pulse/direction (SMD73)



SMD73



MIS231 with pulse/direction

The QuickStep series of Stepper motors with integrated electronics represents a major step forward. All the necessary electronics in a stepper system are integrated in the motor itself.

In the past, a traditional motor system has typically been based on a central controller unit located remote from the motor. This configuration however has the disadvantage that installation costs are a major part of the total expense of building machinery.

The basic idea of the QuickStep motors is to minimize these costs but also to make a component that is much better protected against electrical noise, which can be a typical problem when using long cables between the controller and motor.

The stepper motor, encoder and electronics are specially developed by JVL so that together they form a closed unit, in which the power driver and controller are mounted inside the motor.

The advantages of this solution are:

- De-central intelligence.
- Simple installation. No cables between motor and driver.
- EMC safe. Switching noise remains within motor. (Noise can however be introduced in the DI/DO).
- Compact. Does not take space in cabinet.
- Low-cost alternative to separate step or servo motor and driver.

In the past decade, pulse/direction interfaces have become increasingly popular for the control of step and servo motors. This is due to the fact that pulse/direction signals provide a simple and reliable interface which is 100% digital, precise, and offers immediate response. When a pulse is sent, the motor instantaneously moves 1 step forward.

For example, if the motor has a resolution of

200 steps/revolution, it will move 1.8 degrees. By changing the frequency of the applied pulse signal, it is possible to accelerate the motor.

By counting the number of pulses, the motor's position can be determined without any error whatsoever. The direction input is used to determine the motor's direction of rotation. JVL's QuickStep motors with pulse/direction interface offer the following advantages:


- Very simple technology that is easy to understand and apply.
- High stability and low cost because the technology is simple with few components.
- Only one cable with 4 wires is required, so cabling costs are a minimum.
- No controller in the control cabinet.
- All positioning and control is performed by the PLC, so there is no duplication of software or cabling.
- Robust IP67 connector and IP55 motor housing for applications in demanding environments.
- Thermally protected against current overload and short-circuit.
- Reacts instantaneously. The motor starts within microseconds.
- 5V or 24V PNP/NPN inputs ensure compatibility with any controller.
- Step resolution of 200, 400, 800, 1000 or 1600 pulses/revolution.
- Supply voltage 12-28 VDC.
- Possibility for encoder feedback.

All the required electronics are integrated in the motor itself in a single compact unit. The motor can be supplied with the connector either on the back or side of the housing. M12 connector is standard, but cable glands or DSUB connector can be delivered on request.

For further information on the pulse/direction driver see SMD73 Data-sheet and Technical Note.

1.1 Features pulse/direction (SMD73)

1.1.1 Block diagram, Pulse/Direction Version (SMD73)



1.1.2 Driver Connections

Versions with pulse and direction control:

Connections for versions with 1 M12 connector. (See also SMD73 data-sheet)

M12 5 pin male	Description	JVL cable W11000M12 F5TxxN
1	P+ (12-28VDC)	Brown
2	Pulse	White
3	P-	Blue
4	Direction	Black
5	Signal Ground	Grey

xx: 05 for 5 metre and 20 for 20 metre cable.

Versions with cable glands and 5 m cable

Colour Code	Description
Red	P+ (12-28VDC)
Black	P-
Blue	Direction
White	Pulse
Shield	Signal ground

1.2 Features positioning - speed control (SMC75)



SMC75



SMC75 mounted in a housing



MIS232 with controller

The compact step motor controller SMC75 is designed for positioning and speed control of stepper motors. SMC75 is a PCB with dimensions 57x57mm and mounted with SMD electronics on both sides.

It is mounted directly in the housing of the JVL QuickStep motors MIS 231, 232 and 234, forming a complete integrated step motor. It may also be used with other types of step motors according to customers requirements. The basic features of the controller are:

- Serial RS485 or 5V serial position controller
- Position controller with graphic programming.
- Option for CANbus, CANopen DS-301/DSP-402 or DeviceNet (under development).
- A dual supply facility is available so that position and parameters are maintained at emergency stop
- Gear mode
- MACmotor protocol so MACmotor and Quickstep motors can be connected on the same RS485 bus
- Command for easy PLC/PC setup and communication
- Power supply 12-48VDC
- Fixed 1600 pulses/rev.
- Built-in μ processor with 8 In/Out that can be configured as inputs, PNP outputs or analogue inputs. 5V serial and RS485 interface for set up and programming.
- MODBUS interface.
- 9.6 to 1Mb communication


- Driver technology is improved as compared to SMD73 and supply voltage is 12-48VDC.

When used with the QuickStep motor or mounted on any other step motor the advantages of the controller are:

- De-central intelligence.
- Simple installation. No cables between motor and driver.
- EMC safe. Switching noise remains within motor.
- Compact. Does not take space in cabinet.
- Low-cost alternative to separate step or servo motor and driver.
- Stall detect by means of magnetic encoder with resolution of up to 1024 pulses/rev.
- Interface possibilities to the SMC75 controller:
 - From PC/PLC with serial commands via 5V serial or RS485.
 - Pulse/direction input. Encoder output.
 - CANopen, DeviceNet
 - 8 I/O, 5-28VDC that can be configured as Inputs, Outputs or analogue inputs
 - Future option for Profibus DP, Ethernet, Bluetooth and Zigbee wireless

1.2 Features positioning - speed control (SMC75)

1.2.1 Block diagram, Positioning/Speed Control (SMC75)



1.3

General description

The QuickStep motors are currently available in 4 different models: MIS230, MIS231, MIS232 and MIS234, with continuous torque ratings from 0.5 to 2.9 Nm. The basic functions and I/O features are the same for all models. MIS34x models up to 12.0 Nm are under development.

Motor Type	MIS230	MIS231	MIS232	MIS234	MIS340	MIS341	MIS342	MIS343	Unit
Torque	0.5	1.1	1.6	2.9	3.2	4.6	8.0	12.0	Nm
Inertia	0.12	0.3	0.48	0.96	1.0	1.4	2.7	4.0	kgcm ²
Flange	NEMA23 (57x57 mm)				NEMA34 (87x87mm)				
Length	82	96	118.5	154	105	120	158	196	mm
Shaft Ø	6.35	6.35	6.35	10.0	9.53	9.53	14.0	14.0	mm
Shaft radial play	Max. 0.02 (450g load)				Max. 0.02 (450g load)				mm
Shaft axial play	Max. 0.08 (450g load)				Max. 0.08 (450g load)				mm
Max radial force	7.5 (20mm from flange)				22 (20mm from flange)				kg
Max axial force	1.5				6				kg
Weight	0.7	0.9	1.2	1.8	2.1	2.7	4.2	5.8	kg

1.3.1 Basic modes/functions in the QuickStep motor

The QuickStep motor offers the following functions:

Mode	Description
Passive	The motor will be in a completely passive state but communication is active and internal registers can be setup. Motor shaft can be turned by hand.
Velocity	The motor velocity can be controlled using MacTalk software or by setting register 5(V_SOLL) using serial or program commands.
Position	The motor position can be controlled using MacTalk or by setting register 3(P_SOLL) using serial or program commands.
Gear	The motor position and velocity can be controlled by pulse and direction or encoder signals at the inputs "IN1" and "IN2". The gear ratio can be set to a large ratio by using register14 (GEAR1) and register 15 (GEAR2).

1.4 Step Motor Controller SMC75

Step Motor Controller SMC75 is a mini-step driver with fixed 1600 pulses/rev., which has been designed for driving step motors with phase currents of up to 3 Amp/phase (RMS).


The Controller SMC75 is available in 2 different versions for various applications. It is built into the QuickStep Integrated Step Motors, but for OEM and low-cost applications it can be delivered as a PCB or in its own housing with M12 connectors. For easy mounting and service, the version with M12 connectors is recommended. A version with cable glands can be used for high volume and low cost applications.

	Order no.	PCB	BOX	CANopen	IO	RS485	M12	Cable Glands
	SMC75A1	X			8	1		
	SMC75A1AC	X		X	8	1		
	SMC75A1M3		X		4	2	X	
	SMC75A1M5		X		8	1	X	
	SMC75A1M6		X	X	8	1	X	
	SMC75A1W0		X		8	1		X

Other combinations and features are also possible for OEM use. See "MIS23x: M12 connections" on page 13. for further information.

The "box" version which is built into a black aluminium casing provides a very robust construction that is insensitive to mechanical vibration and electrical noise.

The advantage of using a ministepp driver instead of a conventional full-step or half-step driver is that mechanical resonance problems are significantly minimised. Resonance most often occurs at slow motor speeds and results either in loss of motor torque or the appearance of significant harmonics. The principle of the ministepp technique is to drive the motor using a sinusoidal current in the interval between 2 physical full steps. This reduces the step velocity between each step and thus damps any resonance significantly.




Both 2-phase and 4-phase step motors can be connected to the Controller, which utilises the "Bipolar Chopper" principle of operation, thus giving optimum motor performance.


1.5 SMC75 Controller connections

1.5.1 SMC75 Connector overview

The connections to the various connectors of the SMC75 PCB board is shown below. Note that GND and P- are connected together internally.



The figure below shows the generation 2 connector for future or special purposes. Please contact JVL for further information.




1.5


SMC75 Controller connections

1.5.2 MIS23x: M12 connections

M12 connectors



Example of SMC75 controller connections.




5- pole connector	
Pin no.	Colour
1	Brown
2	White
3	Blue
4	Black
5	Grey

8-pole connector	
Pin no.	Colour
1	White
2	Brown
3	Green
4	Yellow
5	Grey
6	Pink
7	Blue
8	Red

Colour code for standard cables

1.5

SMC75 Controller connections




Versions with positioning and speed control

Quick Step M12 Connector overview	CANopen/Device-Net Male 8pin	RS485/5V serial Female 5pin	IO1-4 Female 8pin	IO5-8 Female 8pin	Power Male 5pin	Function
#MIS23xAzM2N075				X	X	RS485, 4IO
MIS23xAzM3N075		X		X	X	2xRS485, 4IO
#MIS23xAzM4N075			X	X	X	RS485, 8IO
MIS23xAzM5N075		X	X	X	X	2xRS485, 8IO
MIS23xAzM6N075	X		X	X	X	CANopen, RS485, 8IO
MIS23xAzM7N075	X		X	X	X	DeviceNet, RS485, 8IO
M12 Pin 1	CAN_SHLD	B+ (RS485)	IO1	IO5	P+ (12-48VDC)	
M12 Pin 2	CAN_V+	A- (RS485)	IO2	IO6	P+ (12-48VDC)	
M12 Pin 3	CAN_GND	B+ (RS485)	IO3	IO7	P-	
M12 Pin 4	CAN_H	A- (RS485)	GND IO-	GND IO-	CVI+ (12-28VDC)	
M12 Pin 5	CAN_L	GND	B+ (RS485)	Not used	P-	
M12 Pin 6	-	-	A- (RS485)	Not used	-	
M12 Pin 7	-	-	IO4	IO8	-	
M12 Pin 8	-	-	CVO+ (Out)	CVO+ (Out)	-	
M12 connector solder terminals	W11008-M12F5SS1	W11008-M12M5SS1	W11008-M12M8SS1	W11008-M12M8SS1	W11008-M12F5SS1	
M12 cables 5m.	W11006-M12F5S05R	W11000-M12M5T05N	W11000-M12M8T05N	W11000-M12M8T05N	W11000-M12F5T05N	

#: Only >50pcs order. x=: 1~1Nm, 2~1.6Nm, 3~2.5Nm.

z=: 1~6.35mm shaft, 3~10.0mm shaft (only if x=3)



NB: for actual connections, see drawing SMC75 Controller connections, page 12.

2.1

Power Supply SMC75

2.1.1 General Aspects of Power Supply

Powering of the Controller is relatively simple.

To ensure that powering of the Controller is as simple as possible, only a driver and control voltage are connected to the Controller. Internal supply circuitry ensures the correct supply voltages for the driver, control circuits, etc.

The motor can be operated with the same power supply if using 12 – 28VDC for both Driver and control voltage

2.1.2 Power Supply (P+)

The Driver section requires a supply voltage in the range 12-48VDC nominal. It is strongly recommended to use a voltage as high as possible since it will give the best torque performance of the motor at high speeds.

For optimum performance, it is recommended that a capacitance of minimum 1000 μ F is connected to the power supply. It should be mounted as close as possible to the motor. Similarly, it is recommended that 0.75mm cable is used to connect the power supply to the Controller. If the Controller supply voltage falls below 10V, the internal reset circuitry will reset the driver. Provision should therefore be made to ensure that the supply voltage is always maintained at a minimum of 12V, even in the event of a mains voltage drop. The Controller is protected against incorrect polarity connection but not over-voltage.

2.1.3 Control Voltage (CVI)

The control voltage should be in the range 12-28VDC and is used to supply the microprocessor circuit and the user output driver.

This input is used as supply to the microprocessor, encoder and output driver. To ensure that position and parameters are maintained after an emergency stop, the control voltage should be maintained under the emergency stop.

2.1.4 Power Supply Grounding

It is recommended that the housing is connected to ground or common 0 VDC. The overall earthing of the system must be done at a central point close to the power supply.

2.1.5 Dimensioning power supply and fuse

The power supply must be dimensioned according to the actual motor size.

The size of the pre-fuse also depends on the actual model of the MIS motor.

2.1 Power Supply SMC75


Use the following table to select the power supply and fuse ratings.

Desired voltage	MIS231		MIS232		MIS234	
	Supply rating	Fuse size	Supply rating	Fuse size	Supply rating	Fuse size
-						
12VDC	20W	T4A	40W	T6.3A	60W	T10A
24VDC	40W	T4A	80W	T6.3A	160W	T10A
48VDC	80W	T4A	160W	T6.3A	320W	T10A
Recommended power supply	PSU24-075 PSU48-240 PSU40-4		PSU24-240 PSU48-240 PSU40-4		PSU24-240 PSU48-240 PSU40-4	

See also the appendix which shows the standard power supplies that JVL offers.

2.1.6 General power supply description

The supply voltage can be chosen in the range 12VDC to 48VDC. However the maximum torque is based on 48VDC. A lower voltage will decrease the speed/torque performance, and in general it is not recommended to run the motor at more than 300RPM if for example 24VDC is used as supply.




2.1

Power Supply SMC75

2.1.7 Select Your Power Supply

We recommend the use of 48VDC or the highest possible voltage to supply the motor. As seen in the chart below, it is clear that the torque below 100 RPM is independent of supply voltage. But above 300-500 RPM, the torque at 24VDC is half compared to the torque at 48VDC.

Additionally, higher voltage gives better current and filter regulation and thereby better performance. If there is a tendency for motor resonance, a lower supply voltage can be a solution to the problem.




2.2

SMC75 Inputs

The SMC75 has 8 inputs/outputs that each can be set individually to input, output or analog input 0-5VDC via MacTalk or software commands. See Using MacTalk, page 43, for setup.

This means for example that it is possible to have 4 inputs, 3 outputs and one analog input.

Input/output functional diagram:




2.2.1 Inputs

- Inputs are TTL to 28VDC compliant.
- Over-current protection and thermal shut-down.
- 10 kOhm input resistance.
- No galvanic isolation.
- High speed Pulse/direction on Input 1 and Input 2 for gear mode.
- High speed incremental counter on Input 1 and Input 2.
- Positive and negative limit can be selected to any input 1 to 8.
- Zero search input can be selected to any input 1 to 8.
- Digital filter can be enabled for each input selectable from 0 to 100ms. If disabled, the response time is 100 μ s.
- Analog filter can be selected for all Analog inputs.

2.3

SMC75 User Inputs



NB: For actual connections, see SMC75 Controller connections, page 12.

2.3.1 General

The Controller is equipped with a total of 8 digital inputs. Each input can be used for a variety of purposes depending on the actual application. Each of the inputs can be detected from the actual program that has been downloaded to the Controller or via serial commands.

The Inputs are not optically isolated from other Controller circuitry. All of the Inputs have a common ground terminal, denoted *GND*. Each Input can operate with voltages in the range 5 to 30VDC. Note that the Inputs should normally be connected to a PNP output since a positive current must be applied for an input to be activated.

Note that CVO is available as CVI on the I/O connectors. This provides the facility that local sensors can be supplied directly from the controller.

2.3.2 Connection of NPN Output

If an Input is connected to an NPN output, a Pull-Up resistor must be connected between the Input and the + supply. See the illustration above.

The value of the resistance used depends on the supply voltage. The following resistances are recommended:

Supply Voltage	Recommended Resistance R
5-12VDC	1kOhm / 0.25W
12-18VDC	2.2kOhm / 0.25W
18-24VDC	3.3kOhm / 0.25W
24-30VDC	4.7kOhm / 0.25W

2.3

SMC75 User Inputs

2.3.3 End-of Travel Limit Inputs: General

Any of the 8 inputs can be used as limit inputs. The input can be set from MacTalk or via register `NL_Mask`, page 86 or `PL_Mask`, page 86.

Positive limit (PL)

Activation of the Positive limit (*PL*) Input will halt motor operation if the motor is moving in a positive direction. The motor can however operate in a negative direction even if the *PL* Input is activated.

Negative limit (NL)

Activation of the Negative limit (*NL*) Input will halt motor operation if the motor is moving in a negative direction. The motor can however operate in a positive direction even if the *NL* Input is activated.

A bit will be set in the Controller's warning register if either the *NL* or *PL* Inputs has been activated or are active. See Section 9.2.26, page 78.

2.3.4 Step Pulse and Direction Inputs


If gear mode is selected, then IO1 and IO2 can be used as Step Pulse and Direction Inputs. The Step Pulse Input (IO1) is used for applying pulse signals which make the motor move. One signal pulse corresponds to a single ministepped. The Direction Input (IO2) determines the direction of the motor movement. If logic "1" is applied to the Direction Input, the motor moves forward. If logic "0" is applied to the Input, the motor moves backwards.

The Step Pulse and Direction Inputs are not optically isolated from other Driver circuitry and must be driven either by a push-pull driver or a PNP (source) driver. The Inputs can handle voltages in the range 0 to 30 V, which makes the controller well suited for industrial applications, for example in PLC systems.

It is recommended that shielded cable is always used for connection to the Step Pulse and Direction Inputs.

Both inputs must be controlled from a "Source-driver". This means that they share a common ground — see above illustration.

The Driver executes the step on the leading flank of the Step Input pulse — see above illustration. If gear mode is selected, then IO1 and IO2 can be used as step pulse and Direction Inputs or encoder inputs



2.3

SMC75 User Inputs

2.3.5 Home Input

Any of the 8 inputs can be used as Home input for the zero search function. A zero-search occurs when the Controller receives the seek zero search command by changing Mode_Reg (Section 9.2.2, page 71)

The Home Input can be set from MacTalk or via register Home_Mask (Section 9.2.63, page 86)

It is possible to see when a zero-search is finished by reading a bit in Status bits (Section 9.2.20, page 77)

2.3.6 Digital inputs

All of the eight I/O signals can be used as digital inputs. The sampled and possibly filtered value of each input is stored in the Input's register (register 18). Unlike the analog inputs, there is only one value for each digital input, so it must be configured to be either unfiltered or filtered.


Unfiltered (high-speed) digital inputs are sampled every 100 μ S (micro-seconds).

Filtered digital inputs are sampled every milli-second, and the filter value can be set in the range 1 to 100 mS, so the filtered input must be sampled to have the same logical value for that number of samples in a row. Once an input has changed state after passing the filtering, it will again take the same number of samples of the opposite logical level to change it back. For example, if the filter is set to 5 mS and the start value is 0 (zero), the input will remain at zero until three samples in succession have been read as 1 (one). If the signal immediately drops down to 0 again, it will take three samples of zero in succession before the register bit gets set to zero.

Note that filtering of the digital inputs does load the micro-controller, so if filtering of the digital inputs is not needed, ALL the inputs can be selected as high-speed to reduce the load.

2.4

SMC75 Analogue Inputs



NB: For actual connections, see SMC75 Controller connections, page 12.

2.4.1 General

The 0-5V Analogue Inputs are used for example when the Controller is operated as a stand-alone unit. In this kind of application it can be an advantage to use a potentiometer, joystick or other device for adjusting speed, position, acceleration, etc.


In these modes of operation, the motor is controlled to produce a velocity or position, etc., which is determined by, and proportional to, the voltage applied to the Analogue Input.

The Analogue Inputs share a common internal supply with the GND and P- terminal and are not optically isolated from all other inputs and outputs. The Analogue Inputs are protected against voltage overload up to 30V peak and have a built-in filter which removes input signal noise. See Analog input filters, page 25.

Always use shielded cable to connect the source used to control an Analogue Input since the motor, etc., can easily interfere with the analogue signal and cause instability.

The Controller is equipped with 8 analog-to-digital converters (ADC) which convert the detected analogue signal level. The ADCs have a resolution of 10bit.

In order to use the Analogue Inputs as 0-20 mA inputs, a 250 Ω , 1% resistor must be connected between IO 1-8 and GND.



2.4

SMC75 Analogue Inputs

2.4.2 Analog input filters

The SMC75-based products, like the MIS motors have 8 general-purpose I/Os, that can be used as both digital inputs, digital outputs and analog inputs. When an I/O is configured to be an input, it simultaneously has both a digital value (high or low) and an analog value in the range 0.00 to 5.00 Volts. Input voltages higher than 5.0 Volts will be internally limited and read as 5.00 Volts.

The inputs use a resolution of 10 bits, which means that in the raw motor units a value of 5.00 Volts reads out as the value 1023. This gives a resolution of $5.00/1023 = 4.8876$ mV per count.

The eight values from the analog inputs are maintained by the SMC75 firmware in the registers 89...96 as raw, unfiltered values with the fastest possible update frequency, and additionally in the registers 81...88 as filtered values. The firmware does not use any of the values for dedicated functions. It is always up to the program in the motor to read and use the values.

The analog filtered values are typically used to suppress general noise or to define how quickly the input value is allowed to change, or in some cases to limit the input voltage range. A typical example is an analog input that is connected to a manually controlled potentiometer, so an operator can regulate the speed of the machine by turning a knob. In many environments, this setup is subject to noise, which could make the motor run unevenly, and cause too sharp accelerations or decelerations when the knob is turned.

The filter functions supported in the SMC75 firmware always use three different steps.

Confidence check

First the raw input value is compared to two Confidence limits: Confidence Min and Confidence Max. If the new value is either smaller than the Confidence Min limit or larger than the Confidence Max limit, it is simply discarded (not used at all), and the value in its associated register is unchanged. This is done to eliminate noise spikes. Confidence limits can only be used if not all of the measurement range is used. Values of 0 for Confidence Min and 1023 for Confidence Max will effectively disable the confidence limits.

Slope limitation

After a new sample has passed the Confidence limit checks, its value is compared with the last filtered value in its associated register. If the difference between the old and the new value is larger than the Max Slope Limit, the new value is modified to be exactly the old value plus or minus the Max Slope Limit. This limits the speed of change on the signal. Since the samples come at fixed intervals of 10 mS, it is easy to determine the number of Volts per millisecond. A value of 1023 will effectively disable slope limitation.

Filtering

After a new sample has both passed the confidence limits checks and has been validated with respect to the slope limitation, it is combined with the last filtered value by taking a part of the new sample and a part of the old filtered value, adding them together and writing the result back to the final destination register – one of the registers 81...88. For instance a filter value of 14 would take 14/64 of the new sample plus 50/64 of the old value. A filter of 64 would simply copy the new sample to the rule, thus disabling the filtering. This completes the filtering of the analog inputs.

2.4

SMC75 Analogue Inputs

Confidence alarms

If either of the Confidence Min or Confidence Max limits is used, it may be possible that no new samples are accepted, which means that the filtered value will never change even though there is a change in the input voltage. For instance, if the Confidence Min limit is set to 2.0 V, and the actual input voltage is 1.50 V, the filtered value may continue to read out 0.00 V (or the last value it had before exceeding the confidence limits).

To help troubleshooting in cases like this, each input has a status bit that is set if at least half of the new samples during the last second lie outside either confidence limit. It is not possible to see which of the confidence limits is violated. The status bits are updated once per second.

Slope alarms

If the Max Slope limit is used (by setting its value lower than 1023), it may be possible that many samples have their value limited. This is not necessarily an error in itself, but can be a sign of a fault causing a noisy signal, or it can be a sign that the Max Slope limit is set too low, which can have implications if the analogue voltage is used to control the motor speed, torque, etc.

To help troubleshooting in cases like this, each input has a status bit that is set if at least half of the new samples during the last second were limited by the Max Slope setting. The status bits are updated once per second.

Example of analog input filter operation:

Note that even though the examples use units rather than Volts, decimal values are used, since the motor uses a much higher resolution internally to store the units.

Also note that as long as the slope limitation is in effect, the result will keep a constant slope even when using a filter. When the slope limitation is no longer in effect, the filter will cause the value to approach the final result more slowly as it approaches the result.

Confidence Min = 0, Confidence Max = 500, Max Slope = 10, Filter = 8, Old filtered value = 0.

Sample 1 = 100 Confidence OK, slope limit to 0 + 10 = 10,
result = $100 \cdot (8/64) + 0 \cdot (56/64) = 1.25$ units.

Sample 2 = 100 Confidence OK, slope limit to 1.25 + 10 = 11.25,
result = $100 \cdot (8/64) + 1.25 \cdot (56/64) = 2.5$ units.

Sample 3 = 100 Confidence OK, slope limit to 2.5 + 10 = 12.5,
result = $100 \cdot (8/64) + 2.5 \cdot (56/64) = 3.75$ units.

Sample 4 = 800 Confidence error, keep old value, result = **3.75** units.

...and so on until the result gets ~ 95.0 units...

Sample 78 = 100 Confidence OK, no slope limitation needed,
result = $100 \cdot (8/64) + 95 \cdot (56/64) = 95.625$ units.

Sample 79 = 100 Confidence OK, no slope limitation needed,
result = $100 \cdot (8/64) + 95.625 \cdot (56/64) \sim 96.171875$ units.

Sample 80 = 100 Confidence OK, no slope limitation needed,
result = $100 \cdot (8/64) + 96.171875 \cdot (56/64) \sim 96.65$ units.

Sample 81 = 100 Confidence OK, no slope limitation needed,
result = $100 \cdot (8/64) + 96.65 \cdot (56/64) \sim 97.07$ units.

2.4

SMC75 Analogue Inputs

Sample 82 = 100 Confidence OK, no slope limitation needed,
result = $100*(8/64)+97.07*(56/64) \sim = 97.44$ units.

Sample 83 = 100 Confidence OK, no slope limitation needed,
result = $100*(8/64)+97.44*(56/64) \sim = 97.76$ units.

..98.04, 98.28, 98.49, 98.68, 98.85, 99.00, 99.12, 99.23, 99.33, 99.41, 99.48, 99.55,
99.60, 99.65, 99.70, 99.74, 99.77, 99.80, 99.82, 99.84, 99.86, 99.88, 99.90, 99.91, 99.92,
99.93, 99.94, 99.95, 99.95, 99.96, 99.96, 99.97, 99.97, 99.98, 99.98, 99.98, 99.98, 99.99,
99.99, 99.99,100.0


2.5

SMC75 User Outputs

The SMC75 has 8 inputs/outputs that each can be set individually to input, output or analog input 0-5V via MacTalk or software commands.


This means that it for example is possible to have 4 inputs, 3 outputs and one analog input.

Input/output functional diagram:




- Outputs are Source (PNP) outputs and 5-28VDC compliant
- No galvanic isolation
- Short-circuit to ground protected that shuts down all outputs and sets Error bit in software
- In Position and Error signal can be selected to be on any outputs 1 to 8
- Optional Encoder outputs
- 75 to 350 mA output current that depends on number of outputs activated and on duty cycle. (See diagram)
- Internal ground clamp diodes

Allowable output current as a function of duty cycle



2.5

SMC75 User Outputs



NB: For actual connections, see SMC75 Controller connections, page 12.

2.5.1 General

The Controller is equipped with a total of 8 digital outputs. Each output can be used for a variety of purposes depending on the Controller's basic mode of operation. The Outputs are not optically isolated from other Controller circuitry. The output circuitry is powered from the internal power supply CVI. The output circuitry operates with voltages in the range 5-28VDC. Each output can supply a continuous current up to 350mA. The Outputs are all source drivers, i.e. if a given Output is activated, contact is made between the control voltage (CVI) and the respective output terminal. See above illustration.

2.5.2 Overload of User Outputs

All of the Outputs are short-circuit protected, which means that the program and the motor is stopped and the output is automatically disconnected in the event of a short circuit. The Output will first function normally again when the short-circuit has been removed.

Note: Do not connect a voltage greater than 30VDC to the CVI terminal as the output circuitry may be seriously damaged and the unit will require factory repair.

If one or more outputs are short circuited, MacTalk will show Error "Output Driver" and Bit2 will be set in Err_Bits Section 9.2.25, page 78.

2.6

SMC75 Special Outputs

2.6.1 Error Output

Error output can be selected as one of the 8 outputs. This selection is done in MacTalk or by setting a bit in register Error_Mask, *Section 9.2.67*, page 87

The Driver's Error Output enables a PLC or other equipment in a motion control system to verify that the Driver is functioning correctly.

Under normal operation, the Error Output has a status of logic "1", but if the Driver is short-circuited or the temperature exceeds 85 degrees Centigrade, the Output is switched to logic "0".

2.6.2 In Position Output

In Position Output can be selected as one of the 8 outputs.

This selection is done in MacTalk or by setting a bit in register I37 (bit 0-7) InPos_Mask, *Section 9.2.66*, page 87.

When the motor is running, the output will be inactive. When the motor is at stand-still, the output will be active.

2.6.3 In Physical Position Output


In physical position can be selected as one of the 8 outputs.

This selection is done in MacTalk or by setting a bit in register I37 (bit 8 – 15) InPos_Mask, *Section 9.2.66*, page 87.

This signal is used together with MIS motors with an internal or external encoder for positioning.

This signal can be selected to be continuously updated and will then indicate if the motor is inside the "In Position Window" all the time.

If continuous update of the "In Physical Position" is not selected and the autocorrection is used, this signal is changed after a move and when a check has been made of the position after the "settling time between retries" if the motor is inside the "In Position Window".



See also Auto Correction, page 32.

2.6

SMC75 Special Outputs

2.6.4 Pulse/Direction Outputs

Any number of the outputs can be configured to follow the pulse and direction signals used internally in the motor. This can be used for accurate synchronization of two or more motors.

See the register description for registers 108 and 109 in PulseDirMask, page 82 and PulseDirMod, page 83

2.6.5 Encoder Outputs (only from version 2.0)

If the motor is equipped with a built-in encoder, it is possible to obtain the incremental signal and the index pulse out on the user outputs. Please note that the voltage typically is 24VDC PNP. Therefore a resistor to ground should be connected.

A 2 channel encoder with 256 pulses/revolution will give a total of 1024 pulses/revolution.

Output	Encoder designation
06	A
07	B
08	Index

AutoCorrection is used in motors with a built-in encoder only. It is only used in position mode to re-try a movement if the decoder position is too far from the target after the pulse generator has stopped moving the motor – this will happen for instance if the movement was physically blocked, the torque of the motor was insufficient, or a bad value for start velocity or acceleration were used. It might also be used to handle occasional mechanical oscillations.

The AutoCorrection system will first wait (unconditionally) for a certain time to allow the initial movement to settle mechanically before testing for the target position. It will then attempt a normal movement, using the same values for velocities and acceleration as the movement that failed. It will continue until the encoder position is within the target window, or the selected number of retries has expired.

Note that AutoCorrection will only start after the value of the P_SOLL register is changed. In other words, changing P_SOLL (not just writing the same value again) will reload the maximum number of retries and set the Auto Correction Active status bit. The Auto Correction Active status bit will remain set until either the position is within the target window or the max number of retries has been exhausted.


Also note that if the motor is used to control other motors by sending out the pulse and direction signals on digital outputs, any extra movements caused by AutoCorrection will send out additional steps to the other motors.

Registers affected:

- Register 33, IN_POSITION_WINDOW, specifies how many steps from the target position the encoder must report before AutoCorrection is attempted.
- Register 34, IN_POSITION_COUNT, specifies the maximum number of retries. A value of 0 (zero) effectively disables AutoCorrection.
- Register 110, SETTLING_TIME, specifies the number of milli-seconds to wait after a movement before testing the encoder position against IN_POSITION_WINDOW. In the present firmware versions, SETTLING_TIME will be used in AutoCorrection mode only.
- Register 25, STATUSBITS, will still set bit 4 after the pulse generator has output all the pulses to reach the target position (a theoretical In-Position). In AutoCorrection mode, bit 2 will be set to reflect if the internal encoder position is within +/- IN_POSITION_WINDOW steps from the target position P_SOLL (a physical In-Position). Also bit 1 will be set when AutoCorrection is active. Higher layer software can use this bit to detect when AutoCorrection has either completed or given up.
- Register 124, SetupBits, bit 1 can be set to have the firmware maintain the InPhysical Position bit 1 in register 25 all the time, also during a movement. If this bit is not set, the InPhysicalPosition bit will only be maintained after the motor has stopped moving.
- Register 137, INPOS_Mask, is used to select the outputs to reflect the status of the two bits InPosition (bit 4 in the STATUSBITS register) and InPhysical Position (bit 2 in the STATUSBITS register). The 8 lowest bits will select the mask for InPosition and the 8 highest bits will select the mask for InPhysicalPosition. Any combination of bits can be set to have zero, one or more outputs reflect each of the two InPosition bits. The MacTalk program only supports setting a single output for each bit, however, since this is the normal case.

2.8

SMC75 Connection of motor



2.8.1

Cabling

For SMC75 controllers that supply a phase current in the range 0 to 3 A, it is recommended that 0.5mm² cable (minimum) is used to connect the motor to the controller. (0.75mm² is recommended.)

Motor cable lengths should not exceed 10 metres because of impedance loss. It is possible to use longer cables but motor performance will decrease.

Cables should be securely connected since a poor connection can cause heating and destruction of the connector. Similarly, tinned conductors should be avoided.

Important!

To minimise spurious noise emission from the motor cables and to fulfil CE requirements, shielded cable must be used.


If shielded cable is not used, other electronic equipment in the vicinity may be adversely affected.

The removable connector must never be removed while a voltage is connected as this will significantly reduce the lifetime of the connector. Note also that the connector's lifetime is reduced by repeated connecting/disconnecting since the contact resistance of the pins is increased.

Note that P- is connected to the chassis and functions as the main ground on the Controller.

See also Motor Connections *Section 12.4*, page 163, which describes how various models of motor should be connected to the Controller.

2.8 SMC75 Connection of motor



2.8.2 Connection of Step Motor

Various types of step motor are available:

1. 2-phase Bipolar (4 connectors)
2. 4-phase Bipolar/Unipolar (8 connectors)
3. 4-phase Unipolar (6 connectors).

Note that Type 3 motors indicated above (Unipolar motors) produce 40% less torque. This motor type can be used with success but is not recommended if a 4 or 8 wire motor is available instead. This section will not describe the unipolar type further.

2-phase or 4-phase motors can be connected to the Controllers as follows:

2-phase Motors (4 wires).

This type of motor can be directly connected to the Controller's motor terminals. The Controller current adjustment must not exceed the manufacturer's specified rated current for the motor.

4-phase Motors (8 wires).

This type of motor can be connected to the Driver in one of the following two ways:

1. Serial connection of phases.
2. Parallel connection of phases.

Selection of serial or parallel connection of the motor phases is typically determined by the speed requirements of the actual system.

If slow speeds are required (typically less than 1 kHz), the motor phases can be connected in serial. For operation at higher speeds (greater than 1 kHz), the motor phases can be connected in parallel.

2.8 SMC75 Connection of motor

2.8.3 Serial Connection

Using serial connection of the phases, a motor provides the same performance (up to 1kHz) as parallel connection, but using only approximately half the current. This can influence the selection of Controller model and enables a Controller rated for a lower motor current to be used. See illustration on previous page.

If the phases of a 4-phase step motor are connected in series, the motor's rated phase current should be divided by 1.41. For example, if the rated current is 4.2A, the maximum setting of the Controller phase current must not exceed 3 A when the motor phases are connected in series.

2.8.4 Parallel Connection

With parallel connection of motor phases, a motor will provide better performance at frequencies greater than 1kHz compared to serially connected phases, but requires approximately twice the current. This can influence the choice of Controller since it is necessary to select a Controller that can supply twice the current used for serial phase connection. See illustration on previous page.

When the phases of a 4-phase motor are connected in parallel, the specified rated current of the motor must be multiplied by a factor of 1.41. For example, if the rated current is 2.0A, the maximum setting of the Controller phase current must not exceed 2.83A when the phases are connected in parallel.

It should be noted that the lower the self-induction of the motor the better, since this influences the torque at high speeds. The torque is proportional to the current supplied to the motor.

The applied voltage is regulated by the Controller so that the phase current is adjusted to the selected value. In practice this means that if a motor with a large self-inductance (e.g. 100mH) is used, the Controller cannot supply the required phase current at high speeds (high rotational frequencies) since the output voltage is limited.

2.9

Handling noise in cables

2.9.1 About noise problems

The MIS family of motors eliminates the traditional problems with noise from long motor cables that emit noise and feedback cables that are sensitive to noise from external sources.

However, it is still necessary to be aware of noise problems with communications cables and the 8 general-purpose inputs and outputs.

Whenever a digital signal changes level quickly, a noise spike is generated, and is transferred to the other wires in the same cable, and to a lesser degree to wires in other cables located close to the cable with the switching signal. A typical example is when a digital output from the MIS motor changes from low to high to drive a relay. If this digital output signal is transmitted in a multi-wire cable together with the RS-485 signals, there is a high risk that the RS-485 signal will be affected to the extent that the communication will fail, and require software retries.

If communication is used during operation, and operation includes either digital input signals or digital output signals, some precautions must be taken to avoid noise problems. The following sections describe a number of measures which can be taken to solve noise problems. In most installations, no special measures will be required, but if noise problems are experienced – and/or must be avoided – it is highly recommended the instructions below are followed.

2.9.2 Use short cables

The shorter a cable is, the less noise problems it will induce. Be sure to keep the cables as short as possible. Instead of curling up the cables, cut them off at the minimum required length.

2.9.3 Use separate cables

Avoid running digital signals in the same multi-wire cables as RS-485 communication signals.

On some models of the MIS motors, the same connector contains both RS-485 signals and I/O signals – typically the I/Os 1-4.

In many applications, far from all inputs and outputs are used. If only up to four I/Os are required, consider using only I/Os 5-8 which are typically available via another connector on the motor.

2.9.4 Use filters

If more than 4 I/Os are needed, consider using I/Os 1-4 for inputs and I/Os 5-8 for outputs. It is normally possible to install a hardware filter on the digital input signals before they enter the cable. With such a (good) filter, noise on the RS-485 signals will not be a problem.

It is also possible to use filters on the outputs, but it is more difficult. It can be done by using short cables from the motor to the filters, and then using longer cables from the filters to the output targets. It may be easier to use a short cable from the motor to a splitter box, and then split the I/Os in one cable and the RS-485 signals in another cable.

2.9.5 Use termination (resistors) on the RS-485 signals

RS-485 is typically used to connect a single master PC or PLC to one or more motors in a chain. Both ends of the chain must have a 120 Ohms termination resistor connected between the A- and B+ signals. There is typically a terminating resistor in the master PC or PLC, but there is no termination inside the motors. Therefore an external resistor must be connected at the end of the cable out of the last motor in the chain. If the last motor has no connection cable, a connector with a resistor soldered between the A- and B+ pins should be used.

2.9 Handling noise in cables

As an alternative, a connector with a short cable can be used with the resistor soldered between the two wires carrying A- and B+.


Use individually shielded cables.

In some installations, it will be necessary to have RS-485 signals in the same multi-wire cables as fast-switching digital signals. In addition to keeping cable lengths to a minimum and using termination resistors, high-quality cables, where each wire is shielded from the other wires in the cable, should be used. This is typically done using a metal foil wrapped around each wire. These types of cables are more expensive, but the overall cost and noise immunity requirements may justify the solution instead of splitting cables.

2.9.6 Use simple shielding

Using cables with only a single shield shared by all the signal wires will also improve noise problems to some degree, but will not guarantee completely stable operation for mixed signal cables. If a cable carries only RS-485 or only digital I/O, this simple and inexpensive form of shielding is recommended.

2.10 Quick Start (SMC75A1MxAA)



2.10.1 Getting started with the SMC75A1MxAA and MacTalk

1. Connect the cables and Power supply as shown above. Use RS485-M12-1-5-5 cable if the PC has an RS485 interface, or use the converter RS485-USB-ATC-820 if the PC has a USB interface.
2. Switch on the SMC75.
3. Start MacTalk and wait 5 seconds until it automatically is connected to the motor. If “no connection” occurs, check the serial cables and the Mactalk set-up. The Baud rate should be 19200 and the correct com port selected.
4. When a connection has been established, key in values of “running current” and “standby current” under “Driver Parameters”. Remember to press “Enter” after each parameter is keyed in. Actual motor values can be seen to the left of the input field.
5. Set “Startup mode” to select “Position” to enable the motor driver. There should now be current in the motor phases. Depending on the standby current, the motor shaft will be fixed. Some current regulation noise should be heard from the motor.
6. The motor and I/O status can be seen to the left under “Status”.
7. At “Motion Parameter”, key in 1600 counts at “Position”. The motor will now turn one revolution at the speed specified by “Max Velocity”.

3

Serial Interface

3.1.1 Serial Interfaces

The Controller has 2 serial interfaces:

- RS485 (A and B) balanced for up to 32 units in multi-axis applications and MODBUS communication. (Standard)
- CANbus -CANopen DS-301/DSP-402,
- DeviceNet under development

CANbus and RS485 can be used at the same time.

4


RS485 Interface

4.1.1 RS485 - General description when using a QuickStep motor

The RS485 interface offers more noise immune communication compared to the RS232 interface. Up to 32 motors can be connected to the same interface bus.

When connecting the RS485 interface to a central controller, the following rules must be followed:

- 1 Use twisted pair cable.
- 2 Use shielded cable.
- 3 Make sure that the GND is also connected.
- 4 Ensure that all units have a proper connection to safety ground (earth) in order to refer to the same potential.
- 5 The last unit in each end of the network must be terminated with a 120 Ohm resistor between A and B.
- 6 Ensure that the supply lines are made individually in order to reduce the voltage drop between the motors.
- 7 Central Controller RS485 interface:
If available, it is strongly recommended a type with optical isolation is used.



Setup save/open
The complete setup can be either saved or reloaded from a file using these buttons

System control
Use these buttons to save data permanently, reset the motor etc.

Error Handling
Use these fields to define error limits for the position range etc.

Motor status
This field shows the actual motor load, position and speed etc.

Run status
Shows what the status of the motor is. The Bus voltage for the motor and the temperature of the SMC75 is also shown

Inputs
The status of the digital inputs are shown here and the analogue value

Outputs
The status of the outputs are shown here and can be activated by the cursor

Errors
If a fatal error occurs, information will be displayed here.

Warnings
Here different warnings are shown

Help Line
Left area: If parameters entered are outside their normal values, errors are shown here.
Right area: Here it is possible to see if a motor is connected, the type, version and serial no.

Startup mode
The basic functionality of the QuickStep motor is setup in this field.

Profile Data
All the main parameters for controlling the motor behaviour are setup in this field.

Driver Parameters
These fields are used to define standby and running current.

Gear Factor
The gear ratio can be entered here

Motion Parameters
The distance the motor has to run is entered here

Zero Search
All the parameters regarding the position zero search can be specified here.

Autocorrection
The parameters used to get the correct position, if it is a motor with encoder

Communication
The actual address of the motor can be entered here

TT2145GB

5.1 Using the MacTalk software

5.1.1 MacTalk introduction

The MacTalk software is the main interface for setting up the MIS motor for a specific application.

The program offers the following features:

- Selection of operating mode of the MIS motor.
- Changing main parameters such as speed, motor current, zero search type, etc.
- Monitoring in real time the actual motor parameters, such as supply voltage, input status, etc.
- Changing protection limits such as position limits.
- Saving all current parameters to disc.
- Restoring all parameters from disc.
- Saving all parameters permanently in the motor.
- Updating the motor firmware or MacTalk software from the internet or a file.

The main window of the program changes according to the selected mode, thus only showing the relevant parameters for operation in the selected mode.

The following pages describe the actual window for each mode and how the parameters affect MIS motor operation.

5.1 Using the MacTalk software

5.1.2 Toolbar description

The toolbar at the top of MacTalk contains the most commonly used features.



Open

Opens a setup file from disc and downloads the setup to the motor. If no motor is connected, the setup is shown in MacTalk and can be edited and saved to disc again.

Save

Saves the actual setup from the motor to a file. If no motor is connected, the actual off-line settings (including module setups and program) are saved.

Save in flash

The complete actual setup in the basic motor will be saved permanently in the flash memory. If the motor is powered down or reset, the saved setup will be used.

Reset position

Resets the position counter to 0. The content of the position counter can be monitored in the right side of the main screen as "Actual position".

Clear errors

Clears all the errors (if any). Please note that if an error is still present, the motor will remain in the actual error state.

Reset motor

Reset the motor. Same as performing a power off / on operation.

Filter Setup

For specifying the filter setup of the analogue inputs.

MacTalk Address

Only if more than one motor is connected to the same interface. The address specified in this field will determine which motor is communicated with.

5.1.3 Saving or opening a setup file to/from disc

The complete motor setup can be saved to disc or opened from disc and transferred to the motor. The setup files can be saved anywhere on the hard disc or a floppy disc. Saving and opening a file over a network is also possible.


The setup files use the extension .MAC. By default, the setup files are saved in the same directory in which MacTalk itself is also installed. Other directories can be selected.

From file to motor

Use *Open* to select a file containing the desired motor setup. When opening the file - the setup will be sent to the motor. Remember to use the *Save in flash* button if the setup must be permanently saved in the motor.

From motor to file

Use *Save* or *Save as* to save the actual motor setup as a setup file. Make sure that the motor is on-line with MacTalk; otherwise only the MacTalk default setup is saved.



5.1 Using the MacTalk software

5.1.4 Main Screen

a) This field shows the register values in the controller

b) Here it is possible to key in new values. After pressing enter the value will be transferred to the motor and thereafter be read again from the controller and be shown at point a. Because of digitalizing of the keyed in value, the returned value in a) can be different from the value in b).

c) By pressing the unit field it is possible to change between internal unit in the controller and the unit shown to the user.
 E.g. If user unit for current is ARMS and the internal unit is 5.87mA (300ARMS correspond to 511 units.) Not all registers have different internal and user unit. Speed for example is always specified in RPM.

TT2182GB

5.1.5 IO Screen

Active level can be chosen to high or low on inputs

Dedicated Inputs
 Selection for Inputs HM, NKL and PL
 An external encoder can also be selected here and defined as either quadrature or pulse/direction type.
 Selection if it shall be Inputs or Outputs

Dedicated Outputs
 Selection for outputs "In position", "In Physical Position", "Error" output. It can also be selected if the pulses generated shall be used internally, externally or both and which output should be used for pulse and direction signals

Input filters
 Here the filter for the digital inputs can be selected.

Selection if IO's shall use filters

Filter time constant can be adjusted here. The same value is used for all inputs if filter inputs are enabled.

Selection of Inputs for HM, NL and PL

Selection of output for In-Position and Errors

Status of the inputs *)


Status of the outputs

TT2183GB

*) The analogue value of certain inputs can be read. Click at the input lamp and the analogue value will be shown. The upper value is the actual value and the lower value the filtered value.

5.1 Using the MacTalk software

5.1.6 Register Screen



These registers can be used with FastMac commands. For example, the motor can run to position P2 using velocity V2, acceleration/deceleration A2, running current T2, using only a one byte command.

These values are not updated automatically. To update, place the cursor at the specific register value to the left of the box for new values, and click. Otherwise they only update at motor reset or power up.

5.1 Using the MacTalk software

5.1.7 Advanced Screen

If it is desired to run the motor in the opposite direction it can be done by marking "Invert motor direction"

When this field is marked the motor runs to the AP (Actual position) from the encoder position when the motor goes from passive to position mode

Remove the mark in this field and the motor will start the program at start-up

Here it is possible to select different ways of running a turntable and define number of steps

It is possible to have a certain number of motors doing the same by giving them the same group id.

TT2184GB

5.1.8 Test Screen



This screen is used for adjusting the Zero search sensor to the correct position when using the index pulse of an encoder. The index pulse should be in the green area. If not, the sensor has to be adjusted.

5.1 Using the MacTalk software

5.1.9 Scope Function


The Scope function is an excellent and necessary function for testing a new application or finding errors in an existing system.

The Setup has to be selected to set up the Scope function correctly before use. Most registers in SMC75 can be selected for viewing, different trigger functions can be selected, saving and loading scope pictures is possible, etc.



6 Adjustment of motor phase current


The current supplied to each of the step motor's phases can be adjusted for standby and running currents by changing the values of standby and running currents under "Driver parameters".



The Driver automatically switches between the two currents by detecting the presence of step-pulses. If a rising edge is detected at the step-clock, the "Move current" is selected. If no rising edge is detected during the period specified by "Standby time" at the step-clock input, the current is automatically switched back to "Standby current".

Values for the two currents are typically adjusted so that the Operating Current is significantly higher than the Standby Current, since the motor must be supplied with more power to drive its load during acceleration and constant operation than when it is stationary.

Note that the maximum Standby Current normally will be set to 50% or lower of the maximum current for the actual driver type. The only overriding consideration that must be made in the adjustment of motor phase currents is that the thermal output of the motor must not exceed the maximum operating temperature of the step motor.



	MIS231	MIS232	MIS234	Unit
Standby Current	0-3000	0-3000	0-3000	mA
Running Current	0-3000	0-3000	0-3000	mA
Torque	0-1.1	0-1.6	0-2.9	Nm

If a MIS232 motor is used and the current is set to 3000 mA, the motor will be able to deliver a torque of 1.6 Nm at low speed. If the current is set to 1000 mA, the motor will be able to deliver 0.53Nm.

See Run_Current, page 73 for information about Running Current and Standby_Current, page 74 for information about Standby Current.

The QuickStep motor offers the following modes of operation:


- Passive :** The motor will be in a completely passive state but communication is active and internal registers can be set up.
- Velocity :** The motor velocity can be controlled using MacTalk software or by setting register 5 (V_SOLL) using serial or program commands.
- Position :** The motor position can be controlled using MacTalk software or by setting register 3 (P_SOLL) using serial or program commands.
- Gear :** The motor position and velocity can be controlled by pulse and direction or encoder signals at IN1 and IN2.
The gear ratio can be set to a large ratio using register 14 (GEAR1) and register 15 (GEAR2).
- Zero search type 1 and type2:**
Searches for sensor to define a zero position (Reference point).

7.1

Passive Mode

7.1.1 Passive Mode

After power up, the controller will start up in passive mode. This means that it is possible to communicate and read/write to/from registers, but no current is supplied to the motor. It should thus be possible to turn the motor shaft as no voltage is connected to the motor. If there is encoder feed-back, the encoder counter will always register the correct position.



The screenshot displays a configuration window for a motor controller. It features a 'Startup mode' section with four radio buttons: 'Passive' (selected), 'Velocity', 'Position', and 'Gear'. A 'Change actual mode' checkbox is checked. Below this are three sections: 'Profile data' with 'Max velocity' (250 RPM), 'Start velocity' (100 RPM), and 'Acceleration' (1250 RPM/S); 'Driver parameters' with 'Running Current' (3.00 A RMS), 'Standby Current' (0.75 A RMS), and 'Standby time' (500 ms). Each parameter is accompanied by a numeric input field and a unit label.

Section	Parameter	Value	Unit
Startup mode	Startup mode	Passive	
		Velocity	
		Position	
Profile data	Max velocity	250	RPM
	Start velocity	100	RPM
	Acceleration	1250	RPM/S
Driver parameters	Running Current	3.00	A RMS
	Standby Current	0.75	A RMS
	Standby time	500	ms

7.2

Velocity Mode

7.2.1 Velocity Mode

In this mode, the QuickStep motor controls the motor velocity via the Max Velocity setting. This mode is typically used for simple tasks or for applications in which an overall unit, such as a PC-board or PLC, controls velocity and positioning.

The screenshot displays a configuration window for the Velocity Mode. It is organized into several sections:


- Startup mode:** A group box containing four radio buttons: Passive, Velocity, Position, and Gear. To the right of this group is a checked checkbox labeled "Change actual mode".
- Profile data:** A section with three parameters, each with a numeric input field and a unit label:
 - Max velocity: 250 RPM
 - Start velocity: 100 RPM
 - Acceleration: 1250 RPM/S
- Driver parameters:** A section with three parameters, each with a numeric input field and a unit label:
 - Running Current: 3.00 A RMS
 - Standby Current: 0.75 A RMS
 - Standby time: 500 ms

7.3

Positioning Mode

7.3.1 Positioning Mode

In this mode, the QuickStep motor positions the motor via commands sent over the serial interface. Various operating parameters can be changed continuously while the motor is running. This mode of operation is used primarily in systems where the Controller is permanently connected to a PC/PLC via the interface. This mode is also well suited for setting up and testing systems. The mode is also used when programming is done.



The screenshot displays the configuration interface for the QuickStep motor in Positioning Mode. It is organized into several sections:

- Startup mode:** Includes radio buttons for Passive, Velocity, Position (selected), and Gear. A checked checkbox labeled "Change actual mode" is also present.
- Profile data:** Contains three parameters with spinners and units:
 - Max velocity: 250 RPM
 - Start velocity: 100 RPM
 - Acceleration: 1250 RPM/S
- Driver parameters:** Contains three parameters with spinners and units:
 - Running Current: 3.00 A RMS
 - Standby Current: 0.75 A RMS
 - Standby time: 500 ms
- Motion parameters:** Contains one parameter with a spinner and unit:
 - Position: 0 Counts

7.4

Gear Mode

7.4.1 Gear Mode

In this mode, the QuickStep motor functions as in a step motor driver. The motor moves one step each time a voltage pulse is applied to the step-pulse input. Velocity, acceleration and deceleration are determined by the external frequency, but can be limited and controlled by the QuickStep motor. In addition, the QuickStep motor also provides a facility for electronic gearing at a keyed-in ratio.

Start velocity is not used in this mode.

The digital input filter is not used in this mode at input 1 and 2.

The screenshot shows a software configuration window for the QuickStep motor in Gear Mode. The window is divided into several sections:

- Startup mode:** Radio buttons for Passive, Velocity, Position, and Gear (selected). A checked checkbox labeled "Change actual mode" is present.
- Profile data:** Three spinners with labels: Max velocity (250 RPM), Start velocity (100 RPM), and Acceleration (1250 RPM/S).
- Driver parameters:** Three spinners with labels: Running Current (3.00 A RMS), Standby Current (0.75 A RMS), and Standby time (500 ms).
- Gear factor:** Two spinners with labels: Input (0 Pulses) and Output (0 Pulses).
- Motion parameters:** One spinner with label: Position (0 Counts).

Example:

The motor has a resolution of 1600 pulses/rev. and the encoder 500 pulses/rev.

If one revolution of the encoder should result in one motor revolution, the Input must be set to 500 and the Output to 1600.


If the motor must run 5 revolutions because there is a gear with a reduction of 5:1, the output must be set to $5 \times 1600 = 8000$ instead.

7.5

Zero search modes

7.5.1 Mechanical zero search modes

In all positioning systems, there is a requirement to be able to find a mechanical zero position after the system is powered up or at specific times during operation. For this purpose the MIS motor offers 2 different Zero search modes which can be selected from the MacTalk main window or by sending a command via one of the serial interfaces.



The menu offers 3 options:

- Disabled** (default) The Zero search is disabled.
- Power up: Sensor type 1** Similar to "Sensor type 1" but the Zero search will automatically be started after power up.
- Power up: Sensor type 2** Similar to "Sensor type 2" but the Zero search will automatically be started after power up.

The following sections explain in detail the functionality of the 2 fundamental Zero search modes.

7.5.2 Starting a Zero search


If the Zero search mode is set to *Disabled*, no Zero search is done at any time unless written in a program.

If one of the 2 modes *Power up: Sensor type 1* or *Sensor type 2* is selected, the respective Zero search mode will be executed every time the MIS motor is powered up if no program is started up. If a program has been made and is running, the Zero search command must be executed within the program to execute a Zero search.

The MIS motor's zero search facility is very flexible. The inputs for reference and limit switches must be set up correctly before use. The active levels must also be set up correctly.

7.5 Zero search modes


7.5.3 I/O Set Up



Important information: Each of the 8 pins can be defined as inputs or outputs. The active digital input level for each input is also defined in the above screen. Furthermore, it is possible to set up a filter for each input to avoid noise interfering with the program. The inputs for Home, Negative Limit and Positive Limit and outputs for In Position and Error are also selected here.

If an external encoder is used, it must be enabled here

7.5.4 Advanced



There are several ways to perform a Zero search:


- Start from both sides of the reference sensor in a system with limit switches without having position limit problems.
- to go to the opposite side of the sensor and use this position as zero position.
- use a position limit as reference position. In this case the zero search position must be different from 0 or the motor enters passive mode.
- ignore the reference switch input and use the actual position or index pulse as zero position before using the zero search position.

7.5

Zero search modes

7.5.5 "Sensor type 1" Zero search


Sensor type 1 zero search is carried out according to the following illustration.



The Zero sensor must be connected to a user input
 For connection information, see SMC75 User Inputs, page 21

7.5.6 "Sensor type 2" Zero search

Sensor type 2 zero search is carried out according to the following illustration.



The Zero sensor must be connected to a user input. For connection information, see SMC75 User Inputs, page 21.

7.5 Zero search modes

7.5.7 Making a Zero point offset

Common for all the zero search modes, it is possible to optionally define the zero-point as a value other than zero (position 0).

When is it useful to use the zero point offset?


- If it is required that the position interval under normal operation is always “nice” positive values from 0 to x instead of a mixture of negative and positive values. This can happen if the zero point sensor is placed a long distance away from the normal positioning interval or inside the normal positioning interval.
- If an automatic move to an initial position is desired after a power-up zero search.

The offset value must be specified in the “Zero search position” field.

The complete zero search will be performed in the following order.

1. The zero search is started either automatically (power up) or initiated by a command from the serial interface.
2. The basic zero search is completed and the position counter is set to the value specified in the “Zero search position” field.
3. If the zero search position value is different from position 0, the motor will now move to position 0.
4. The zero search is now complete and the motor will switch to normal operation, i.e. the mode selected in the “Startup mode” field in the main window.


The illustration below shows the complete zero-search cycle.




Ensure several tests are made to ensure the white dot is located in the acceptable interval each time.

7.5 Zero search modes

Example: Zero search velocity = -128 rpm
Zero search position = -10000 counts




7.5.8 Zero search with index pulse



If the MIS motor is equipped with an encoder, it is also possible to use the index pulse of the encoder. This gives a much more precise zero position than just running for a sensor. The accuracy of the sensor signal depends on how far the sensor is located away from the measuring item and on the velocity.

The index pulse can be used with or without the sensor. This must be defined on the advanced tab. If the MIS motor is set to use the index pulse, the MIS motor always runs to the sensor first and then index pulse.

The sensor must be placed at the right position. This can be done using MacTalk. Select the type of sensor movement to be used in the main tab screen. In the advanced tab, choose not to start the program automatically after reset. Then select Save in Flash. Go to the Test tab and press "Start Zero Search". The motor now rotates at the zero search velocity towards the sensor, and when this has been found the motor continues to the index pulse. The circle at the Test tab indicates the location of the index pulse according to the sensor. The index pulse must be in the green area. If the index pulse is in the red area, the sensor must be moved slightly and the procedure repeated.



The MIS motor contains 5 fundamental parameters which are used for protection related purposes. They all have effect regardless of which mode of operation the motor is set to use.

Follow error

(Only for MIS with internal encoder)

Follow error is the difference between the target position and the encoder position. The target position is the position generated. Default is 0. (Function disabled).

Position limit min. and max.

Same as physical limit switches but implemented in software. Default is 0 meaning that the feature is disabled. If one parameter is different from 0, both values are activated.

Error acceleration

If a fatal error occurs, it can be convenient to use a controlled deceleration instead of a sudden stop. If the inertia in the system is high and the mechanical parts are weak, a sudden stop can cause damage and unintended behaviour. Use this parameter to define the deceleration used during a fatal error. Default is 0, meaning that the feature is disabled.

Min. bus voltage

This is the level of P+ at which the motor goes into error state "low bus voltage".





9.1 Introduction and register overview

All of the motor registers can be accessed either through the RS485 interface or over CANopen.

When accessing registers over CANopen, they are mapped to object indexes 2012 and 2014 (hex) with the sub-index equal to the register number 1...255. Use index 2012 for the 32-bit registers and index 2014 for the 16-bit registers.

For example to access register 3, P_SOLL, use index 2012, subindex 3. To access register 5, V_SOLL, use index 2014, subindex 5. This is described in more detail in CANopen Introduction, page 121.

All of the registers can be accessed over CANopen with the same Read/Write access restrictions as when using the RS485 interface.

Some registers are tagged as R for Read-only. There are different reasons for this, such as protecting the serial number from being changed or indicating that the value in registers, such as Analog Inputs, will never be read by the motor but always overwritten using the latest sampled values.

In the following sections and examples, positions, velocity and acceleration are based on a 200 step motor running with 1/8 steps.

9.1.1 Register Overview.

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
1	PROG_VERSION	16bit	R	-	*	Major*16+ Minor+16384	"Status bar"
2	Mode_Reg	16bit	R/W	0,1,2,3, 13,14,15	0	-	Current Mode
3	P_SOLL	32bit	R/W	$(-2^{31})-(2^{31}-1)$	0	steps	Position
5	V_SOLL	16bit	R/W	-1023-1023	250	RPM	Max velocity
6	A_SOLL	16bit	R/W	1-65535	131	9.54 RPM/s ²	Acceleration
7	RUN_CURRENT	16bit		0-511	511	5.87mA	Running Current
8	STANDBY_TIME	16bit	R/W	1-65535	500	ms	Standby Time
9	STANDBY_CURRENT	16bit	R/W	0-511	128	5.87 mA	Standby Current
10	P_IST	32bit	R/W	$(-2^{31})-(2^{31}-1)$	-	Steps	Actual Position
12	V_IST	16bit	R	0-1023	-	RPM	Actual Velocity
13	V_START	16bit	R/W	1-1023	100	RPM	Start Velocity
14	GEAR1	16bit	R/W	$(-2^{15})-(2^{15}-1)$	1600	Steps	Output
15	GEAR2	16bit	R/W	$(-2^{15})-(2^{15}-1)$	2000	Counts	Input
16	ENCODER_POS	32bit	R/W	$(-2^{31})-(2^{31}-1)$	-	Steps	Encoder position
18	INPUTS	16bit	R	-	-	Special	Inputs
19	OUTPUTS	16bit	R/W	-	0	Special	Outputs
20	FLWERR	32bit	R	$(-2^{31})-(2^{31}-1)$	-	Steps	Follow Error
22	FLWERRMAX	32bit	R/W	$(-2^{31})-(2^{31}-1)$	0	Steps	Follow Error Max
24	COMMAND	16bit	R/W	0-127, 256, 257	0	-	N/A
25	STATUSBITS	16bit	R	-	-	Special	Run Status
26	TEMP	16bit	R		-2.27 uses offset		Temperature
27	Reserved	-	-	-	-	-	
28	MIN_P_IST	32bit	R/W	$(-2^{31})-(2^{31}-1)$	0	Steps	Position Limit Min
30	MAX_P_IST	32bit	R/W	$(-2^{31})-(2^{31}-1)$	0	Steps	Position Limit Max
32	ACC_EMERG	16bit	R/W	1-65535	10000	9.54 RPM/s ²	Error Acceleration

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
33	IN_POSITION_WINDOW	16bit-	R/W	0-65535	5	Steps	
34	IN_POSITION_COUNT	16bit-	R/W	0-65535	0	Counts	
35	ERR_BITS	16bit	R/W		0	Special	Errors
36	WARN_BITS	16bit	R/W		0	Special	Warnings
37	STARTMODE	16bit	R/W	-	0	-	Startup Mode
38	P_HOME	32bit	R/W	$(-2^{31})-(2^{31}-1)$	0	Steps	Zero Search Position
40	V_HOME	16bit	R/W	-1023-1023	-50	RPM	Zero Search Velocity
41	Reserved	-	-	-	-	-	
42	HOMEMODE	16bit	R/W	0,13,14	0	-	Zero Search Mode
43-48	Reserved	-	-	-	-	-	
49-64	Pn	32bit	R/W	$(-2^{31})-(2^{31}-1)$	0	Steps	Position n (Pn)
65-72	Vn	16bit	R/W	0-1023	250	RPM	Velocity n (Vn)
73-76	An	16bit	R/W	1-65535	131	9.54 RPM/s ²	Acceleration n (An)
77-80	Tn	16bit	R/W	0-511	511	5.87 mA	Current n (Tn)
81-88	AnalogFiltered	16bit	R	0-1023	0	4.888mV	N/A
89-96	AnalogInput	16bit	R	0-1023	-	4.888 mV	N/A
97	BUSVOL	16bit	R	0-1023	-	109 mV	Bus Voltage
98	MIN_BUSVOL	16bit	R/W	0-1023	15	109 mV	Min Bus Voltage
99	ENCODER_TYPE	16bit	R	0-10	-	-	"Tooltip on motor"
100	AFZUP_WriteBits	16bit	R/W	-	0	Special	N/A handled on the Filter Setup screen
101	AFZUP_Read Index	16bit	R/W	0, 1-8, 32768-32775	0	Special	N/A handled on the Filter Setup screen
102	AFZUP Conf Min	16bit	R/W	0-1022	0	4.888 mV	Confidence Min
103	AFZUP_Conf Max	16bit	R/W	1-1023	1023	4.888 mV	Confidence Max
104	AFZUP_Max Slope	16bit	R/W	2-1023	1023	4.888 mV	Max Slope
105	AFZUP_Filter	16bit	R/W	1-64	64	64 th of new sample	Filter (on the Filter setup screen)
106	FilterStatus	16bit	R	0-65535	0		N/A (shown graphically)
107	Reserved	-	-	-	-	-	
108	PulseDirMask	16bit	R/W	0-65535	0	Bitmask	Pulse signal Direction signal
109	PulseDirMode	16bit	R/W	0-2	0	-	Pulse/Direction mode
110	SettlingTime	16bit	R/W	0-32676	0	ms	Settling time between retries
111	Reserved	-	-	-	-	-	
112-115	SAMPLE1-4	16bit	R/W	-	0	-	N/A
116	REC_CNT	16bit	R/W	-	0	-	N/A
117	S_TIME	16bit	R/W	-	1	ms	N/A
118	S_CONTROL	16bit	R/W	-	0	-	NA
119	BUF_SIZE	16bit	R	-	-	-	N/A
120	INDEX_OFFSET	16bit	R	0-1599	-	Steps	Tests-
122	HOME_BITS	16bit	R/W	-	0	Special	Advanced-Zero Search
123	Reserved	16bit	R/W	-	-	-	N/A

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
124	SETUP_BITS	16bit	R/W	-	0	Special	Don't start program after power up. Invert motor direction. External Encoder Enable DSP 402 Support Auto encoder synchronize
125	IOSETUP	16bit	R/W	-	0	Special	Inputs/Outputs
126	TURNTABLE_MODE	16bit	R/W	-	0	Special	Turn Table -Mode
127	TURNTABLE_SIZE	32bit	R/W	-	0	Steps	Turn Table - Size
129	NL_MASK	16bit	R/W	-	0	IO Mask	Dedicated Inputs Negative Limit Input
130	PL_MASK	16bit	R/W	-	0	IO Mask	Dedicated Inputs - Positive Limit Input
131	Reserved	16bit	R/W	-	0		
132	HOME_MASK	16bit	R/W	-	0	IO Mask	Dedicated inputs. Home Input
133-134	Reserved	-	-	-	-	-	
135	INPUT_FILTER_MASK	16bit	R/W	-	0	IO Mask	IOx digital input filter enabled
136	INPUT_FILTER_CNT	16bit	R/W	-	5	ms	Input filter time
137	INPOS_MASK	16bit	R/W	-	0	IO MASK	Dedicated Outputs - In Position
138	ERROR_MASK	16bit	R/W	-	0	IO Mask	Dedicated Outputs - Error
139-143	Reserved	-	-	-	-	-	
144	P_NEW	32bit	R/W	$(-2^{31})-(2^{31}-1)$	0	Counts	N/A
146	BAUD_RATE	16bit	R/W	0-5	1	-	Baud Rate
147	TX_DELAY	16bit	R/W	0-255	15	Bits	Transmit Delay
148	GROUP_ID	16bit	R/W	0-255		-	Group ID
149	GROUP_SEQ	16bit	R	0-255	-	-	N/A
150	MY_ADDR	16bit	R/W	0-254		-	Motor Address
151	MOTORTYPE	16bit	R	64-xx		-	"Status Bar"
152	SERIAL-NUMBER	32bit	R	-	-	-	"Status Bar"
154	CHECKSUM	32bit	R	0-65535	-		
156	HARDWARE_REV	16bit	R	0-65535	-	Major*16+ Minor+16384	"Tooltip on Motor"
157	MAX_VOLTAGE	16bit	R	0-100	*	Volt	"Tooltip on Motor"
158	AVAILABLE_IO	16bit	R	-	-	IO MASK	N/A
159	BOOTLOADER_VER	16bit	R	0-65535	-	Major*16+ Minor+16384	"Tooltip on Motor"
160	NOTSAVED	16bit	R/W	0-65535	0	-	N/A
161-164	Reserved						
165	OPTION_BITS	16bit	R	0-65535	-	-	"Tooltip on motor"
166	FBUS_NODE ID	16bit	R/W	0-255	5	-	Fieldbus - Node ID
167	FBUS_BAUD	16bit	R/W	0-8	2	-	Fieldbus - Baud Rate
168	Reserved	16bit	-	-	-	-	

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
169	Reserved	16bit	-	-	-	-	
170	EXT_ENCODER	32bit	R/W	$(-2^{31})-(2^{31}-1)$	-	Counts	External Encoder
172	EXT_ENCODER_VEL	16bit	R	$(-2^{15})-(2^{15}-1)$	-	Counts 16ms	External Encoder Velocity

The following parameters are only available when the CanOpen option is installed and only used for DSP-402							
Reg	Name	Size	Access	Range	Default	Unit	Description
180	ControlWord	16bit	R/W	0-65535	0	-	Object 6040 subindex 0
181	StatusWord	16bit	R	0-65535	0	-	Object 6041 subindex 0
182	ModeOfOperation	16bit	R/W	0-255	0	-	Object 6060 subindex 0
183	ModeOfOperationDisplay	16bit	R	0-255	0	-	Object 6061 subindex 0
184	TargetPosition	32bit	R/W	$(-2^{31})-(2^{31}-1)$	0	-	Object 607A subindex 0
186	ActualPosition	32bit	R	$(-2^{31})-(2^{31}-1)$	0	-	Object 6064 subindex 0
188	TargetVelocity	32bit	R/W	$(-2^{31})-(2^{31}-1)$	0	-	Object 60FF subindex 0
190	ActualVelocity	32bit	R	$(-2^{31})-(2^{31}-1)$	0	-	Object 606C subindex 0
192	DigitalOutputs	16bit	R/W	0-65535	0	-	Object 60FE subindex 1 (Low 16bit)
194	DigitalInput	16bit	R	0-65535	0	-	Object 60FD subindex 1 (Low 16bit)

9.2

Register Descriptions

9.2.1 Prog_Vers

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
1	PROG_VERSION	16bit	R	-	*	Major*16+ Minor+16384	"Status bar"

Description: The firmware version. The Bit 14 is set to indicate that the type is SMC75. Bit 0-3 is the minor version and bit 4-7 is the major version.

Example: The firmware version 1.7 will have the value 0x4017 (16407)

9.2.2 Mode_Reg

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
2	Mode_Reg	16bit	R/W	0,1,2,3,11, 13,14,15	0	-	Current Mode

Description: Controls the operating mode of the motor. The following modes can be selected:

- 0: Passive
- 1: Velocity mode
- 2: Position mode
- 3: Gear mode
- 13: Zero search type 1
- 14: Zero search type 2
- 15: Safe mode

Passive mode (0)

In this mode, the motor current is turned off and the motor will not react to any position/velocity commands.

Velocity mode (1)

When the motor is in velocity mode, the controller accelerates the motor to the velocity in V_SOLL. V_SOLL can be changed at any time and the move will decelerate/accelerate accordingly.

It is permissible to change A_SOLL and V_START during a movement, but the changes will first take effect after the motor has stopped. Please note that if the motor needs to change direction, it will decelerate and stop, and the new A_SOLL and V_START will be activated.

Position mode (2)

When the motor is in position mode, the controller will always try to move until P_IST = P_SOLL.

The movement will follow the profile specified by V_SOLL, A_SOLL and V_START. P_SOLL can be changed at any time and the motor will move accordingly.

V_SOLL can also be changed during a movement.

It is permissible to change A_SOLL and V_START during a movement, but the changes will first take effect after the motor has stopped. Please note that if the motor needs to change direction, it will decelerate and stop, and the new A_SOLL and V_START will be active.

9.2

Register Descriptions

Gear mode (3)

The GEAR mode works as position mode, but has an additional feature. The input on the external encoder is multiplied with GEAR1/GEAR2 and added to P_SOLL. Any remainder of the result is saved and used next time the external encoder changes.

The result is that this mode can be used as an electronic gear.

When using gear mode, it is not recommend to set V_START below 10 rpm. This can gives problems at low speeds, because the motor will lag behind when doing the first step. It will then accelerate in order to catch up.

NOTE: Time from the first input pulse to the first step is typically 30-60 μ s if not on standby. 72-102 μ s if on standby.

Zero search type 1 (13)

When the operation mode is set to 13, the controller will start the search for the zero point. See "Sensor type 1" Zero search, page 60 for details.

Zero search type 2 (14)

When the operation mode is set to 15, the controller will start the search for the zero point. See "Sensor type 2" Zero search, page 60 for details.

Safe mode (15)

This mode is similar to passive mode, but also allows the "save in flash" and "reset" commands. Safe mode cannot be entered/exited directly; this must be done using the serial commands ENTER/EXIT SAFEMODE.

Example:

Writing MODE_REG=2 will set the motor in position mode. When P_SOLL is changed, the motor will move to this position with the specified max velocity (V_SOLL) and acceleration (A_SOLL).

Writing MODE_REG=13 will start a zero search for a sensor. When the search is completed, the MODE_REG will automatically be changed to the mode specified in START_MODE.

9.2.3 P_Soll

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
3	P_SOLL	32bit	R/W	$(-2^{31})-(2^{31}-1)$	0	Steps	Position

Description: The desired position. When in position mode, the motor will move to this position. This value can be changed at any time. The maximum possible position difference is 231-1. If relative movement is used, the P_SOLL will just wrap at 231-1 and the motor will move correctly. Please note that the turntable function changes the behaviour of P_SOLL. See Turntable_Mode, page 85.

Example: If P_SOLL = -800 and then P_SOLL is set to 800, the motor moves one revolution forward.
If P_IST = 231-100 (2147483548) and P_SOLL is set to -231 + 100 (2147483548), the motor will move 200 steps in the positive direction.

9.2 Register Descriptions

9.2.4 V_SOLL

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
5	V_SOLL	16bit	R/W	-1023-1023	250	RPM	Max velocity

Description: The maximum velocity allowed. When in velocity mode, the motor will run constantly at this velocity. Specify a negative velocity to invert the direction. This value can be changed at any time.

Example: V_SOLL = 250, will limit the velocity to 250 RPM.

9.2.5 A_SOLL

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
6	A_SOLL	16bit	R/W	1-65535	131	9.54 RPM/s ²	Acceleration

Description: The acceleration/deceleration ramp to use. If this value is changed during at movement, it will first be active when the motor stops or changes direction.

Example: A_SOLL = 105, will set the acceleration to 1000 RPM/s.

9.2.6 Run_Current

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
7	RUN_CURRENT	16bit	R/W	0-511	511	5.87mA	Running Current

Description: This register sets the running current for the motor. 511 is the maximum possible current, corresponding to 3A RMS. The running current is active when the motor is running and after it stops until the specified standby time has elapsed.
See Standby Time, page 73.
When the RUN_CURRENT is changed, the new motor current will be set instantly.

Example: RUN_CURRENT = 100, will set the running current to 0.59A RMS.

9.2.7 Standby_Time

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
8	STANDBY_TIME	16bit	R/W	1-65535	500	ms	Standby Time

Description: This register sets the standby time. This time is the time from the last step has been performed until the current changes from running to standby. When a new request for a move is received the current changes from standby to running with no delay.

Example: STANDBY_TIME = 200, will result in the controller switching to the standby current after 200ms.

9.2 Register Descriptions

9.2.8 Standby_Current

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
9	STANDBY_CURRENT	16bit	R/W	0-511	128	5.87 mA	Standby Current

Description: This register set the standby current for the motor. 511 is the maximum possible value, corresponding to 3A RMS. The standby current is active when the motor has stopped and the specified Standby time has elapsed. See Standby_Time, page 73. When the STANDBY_CURRENT is changed, the new motor current will be set instantly.

Example: STANDBY_CURRENT = 50, will set the running current to 0.29A RMS.

9.2.9 P_Ist

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
10	P_IST	32bit	R/W	$(-2^{31})-(2^{31}-1)$	-	Steps	Actual Position

Description: This register shows the actual position of the motor. This is updated each time the motor makes a step. If P_IST is changed when in position mode or gear mode, the motor will move until $P_IST = P_SOLL$. When P_IST reaches $2^{31}-1$, it will wrap around to -2^{31} . Please note that the turntable function changes the behaviour of P_IST. See Turntable_Mode, page 85.

Example: P_IST = 1000, P_SOLL = 1000. P_IST is set to 500. The motor will move 500 steps forward and P_IST will again be 1000.

9.2.10 V_Ist

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
12	V_IST	16bit	R	0-1023	-	RPM	Actual Velocity

Description: This register shows the actual velocity of the motor. The velocity is positive when running in a positive direction and negative when running in a negative direction.

Example: If V_SOLL = 400 and a movement of -10000 steps is done, V_IST will be -400 during the move and when the move is complete V_IST will be 0.

9.2

Register Descriptions

9.2.11 V_Start

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
13	V_START	16bit	R/W	$\pm 1-1023$	100	RPM	Start Velocity

Description: The start velocity. The motor will start the acceleration at this velocity. It will also stop the deceleration at this velocity. If $|V_SOLL|$ is lower than V_START the motor will not accelerate at all, but start to run at V_SOLL instantly. The motor will actually start the movement with an internal $V_START = V_SOLL$.

If V_START is changed during a movement, it will first be active when the motor stops or changes direction. This also means that if V_SOLL is changed to a value below V_START , while the motor is in motion, the motor will decelerate to V_START and run at that velocity.

Example: $V_START = 100$, $V_SOLL = 200$, $MODE_REG = 1$. The motor will accelerate from 100 RPM to 200 RPM.

V_SOLL is now changed to 50. The motor will decelerate to 100 RPM and continue at 100 RPM.

V_SOLL is now changed to -50 RPM. The motor will stop and start at -50 RPM.

9.2.12 GEAR1

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
14	GEAR1	16bit	R/W	$(-2^{15})-(2^{15}-1)$	1600	Steps	Output

Description: When the gear mode is active, the input from the external encoder is multiplied by GEAR1 and divided by GEAR2.

Example: $GEAR1 = 1600$, $GEAR2 = 2000$. If 2000 steps are applied to the input, the motor will turn 1 revolution.

If one step is applied, the motor will not move (but the remainder will be 0.8)

If another step is applied, the motor will move 1 step (and the remainder will be 0.6).

If another step is applied, the motor will move 1 step (and the remainder will be 0.4)

And so on.

9.2.13 GEAR2

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
15	GEAR2	16bit	R/W	$(-2^{15})-(2^{15}-1)$	2000	Counts	Input

Description: The denominator of the gear factor. See GEAR1 for details.

9.2.14 Encoder_Pos

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
16	ENCODER_POS	32bit	R/W	$(-2^{31})-(2^{31}-1)$	-	Steps	Encoder position

Description: If the internal encoder option is installed, this register shows the position feedback from the encoder.

This value is initialized to zero at power-up and modified by the firmware when a zero search is performed.

The value can be used internally by the AutoCorrection system to retry a movement in position and gear modes.

9.2 Register Descriptions

9.2.15 Inputs

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
18	INPUTS	16bit	R	-	-	Special	Inputs

Description: This register shows the status of the digital inputs. Bit 0-7 shows whether IO 1-8 is active or inactive. The active level can be set using IOSETUP. See losetup, page 85. Bits 8-15 are not used and will always be 0. The inputs can be filtered or unfiltered. See Input_Filter_Mask, page 87.

Note that all of the inputs have a digital state and an analog value at the same time. This register shows their digital state only. Note that the digital inputs can be filtered by setting bits in register 135 (Input_Filter_Mask, page 87).

Bit	7	6	5	4	3	2	1	0
Function	IO8	IO7	IO6	IO5	IO4	IO3	IO2	IO1

9.2.16 Outputs

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
19	OUTPUTS	16bit	R/W	-	0	Special	Outputs

Description: This register shows the status of the outputs. Bit 0-7 shows whether IO 1-8 is active or inactive. The active level can be set using IOSETUP. See losetup, page 85. Please note that the output driver for each output also has to be enabled. This is also done using IOSETUP. The register can be changed in order to change the status of the outputs.

9.2.17 Flwerr

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
20	FLWERR	32bit	R	$(-2^{31})-(2^{31}-1)$	-	Steps	Follow Error

Description: When the encoder option is installed, this register shows the encoder deviation from the calculated position (P_IST).

9.2.18 Flwerrmax

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
22	FLWERRMAX	32bit	R/W	$(-2^{31})-(2^{31}-1)$	0	Steps	Follow Error Max

Description: The maximum allowed value in FLWERR before an error is triggered. If FLWERRMAX = 0, the error is disabled. See register 35 (Err_Bits, page 78) for a description of the error bit.

9.2.19 Command

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
24	COMMAND	16bit	R/W	0-127, 256, 257	0	-	N/A

Description: Used to issue commands to the motor. 0-128 are the normal FastMac commands. The values 128-255 are reserved. Command 256 will activate a new baud rate on the serial ports, and command 257 will synchronize the internal encoder position to the actual motor position.

9.2

Register Descriptions

9.2.20 Statusbits

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
25	STATUSBITS	16bit	R	-	-	Special	Run Status

Description: Status bits:
Bit 0: Reserved
Bit 1: AutoCorrection Active
Bit 2: In Physical Position
Bit 3: At velocity
Bit 4: In position
Bit 5: Accelerating
Bit 6: Decelerating
Bit 7: Zero search done
Bit 8-15: Reserved
Actual run status bits for the motor.

9.2.21 Temp

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
26	TEMP	16bit	R	0...127	-	-2.27 - uses offset	Temperature

Description: Temperature measured inside the motor electronics.
The approximate temperature in degrees Celsius is calculated from the value in this register using the formula: $T_c = 2.27 * \text{Value}$.

9.2.22 Min_P_Ist

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
28	MIN_P_IST	32bit	R/W	$(-2^{31})-(2^{31}-1)$	0	Steps	Position Limit Min

Description: Position limit for movement in the negative direction. The motor can be configured to stop automatically when it reaches this position.

9.2.23 Max_P_Ist

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
30	MAX_P_IST	32bit	R/W	$(-2^{31})-(2^{31}-1)$	0	Steps	Position Limit Max

Description: Position limit for movement in the positive direction. The motor can be configured to stop automatically when it reaches this position.

9.2.24 Acc_Emerg

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
32	ACC_EMERG	16bit	R/W	1-65535	10000	9.54 RPM/s ²	Error Acceleration

Description: The motor will use this acceleration during an emergency stop.

9.2 Register Descriptions

9.2.25 Err_Bits

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
35	ERR_BITS	16bit	R/W		0	Special	Errors

Description: Error bits:

Bit 0: General error. Will always be set together with one of the other bits.

Bit 1: Follow error

Bit 2: Output driver error. Bit is set if one of the outputs is short circuited.

Bit 3: position Limit error

Bit 4: Low bus voltage error

Bit 5: Over voltage error

Bit 6: Temperature too high (90°C)

Bit 7: Internal error (Self diagnostics failed)

If any of these bits are set, the motor is in a state of error, and will not move until all the errors have been cleared. Some of the errors can be cleared by writing zero to this register. Other errors will require hardware fixes or intervention, such as allowing the motor cool down or adjusting the power supply voltage.

9.2.26 Warn_Bits

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
36	WARN_BITS	16bit	R/W		0	Special	Warnings

Description: Warning bits:

Bit 0: Positive limit active. This bit will be set as long as the positive limit is active.

Bit 1: Negative limit active. This bit will be set as long as the negative limit is active.

Bit 2: Positive limit has been active

Bit 3: Negative limit has been active

Bit 4: Low bus voltage

Bit 5: reserved

Bit 6: Temperature has been above 80°C

These bits provide information on both the actual state and remembered state of the end position limits, the supply voltage and the temperature. These are used for diagnostic purposes as well as handling position limit stops, also after the motor may have left the end position mechanically.

9.2.27 Startmode

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
37	STARTMODE	16bit	R/W	-	0	-	Startup Mode

Description: The motor will switch to this mode after power up. This is also the mode that is used when a zero search has been completed. See Mode_Reg, page 71 for a list of possible modes.

9.2.28 P_Home

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
38	P_HOME	32bit	R/W	$(-2^{31})-(2^{31}-1)$	0	Steps	Zero Search Position

Description: The zero point found is offset with this value.

9.2

Register Descriptions

9.2.29 V_Home

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
40	V_HOME	16bit	R/W	-1023-1023	-50	RPM	Zero Search Velocity

Description: The velocity used during zero search. Set a negative velocity to search in the negative direction.

9.2.30 Homemode

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
42	HOMEMODE	16bit	R/W	0,13,14	0	-	Zero Search Mode

Description: Selects the zero search that should start on power up.
A value of 13 will use sensor type 1, while a value of 14 will use sensor type 2.

9.2.31 Pn

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
49-64	Pn	32bit	R/W	$(-2^{31})-(2^{31}-1)$	0	Steps	Position n (Pn)

Description: These eight general-purpose position registers are referred to as P1 ... P8 and can be used to make absolute or relative movements in several different ways, either from the user program or via the serial interfaces. See also the sections on FastMac commands, and the P_NEW register description (P_New, page 88).

9.2.32 Vn

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
65-72	Vn	16bit	R/W	0-1023	250	RPM	Velocity n (Vn)

Description: These eight general-purpose Velocity registers are referred to as V1...V8 and can be used to change the velocity in several different ways, either from the user program or via the serial interfaces. See also the sections on FastMac commands.

9.2.33 An

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
73-76	An	16bit	R/W	1-65535	131	9.54 RPM/s ²	Acceleration n (An)

Description: These four general-purpose Acceleration registers are referred to as A1... A4 and can be used to change the acceleration in several different ways, either from the user program or via the serial interfaces. See also the sections on FastMac commands.

9.2

Register Descriptions

9.2.34 Tn

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
77-80	Tn	16bit	R/W	0-511	511	5.87 mA	Current n (Tn)

Description: These four general-purpose Torque registers are referred to as T1...T4 and can be used to change the velocity in several different ways, either from the user program or via the serial interfaces. See also the sections on FastMac commands. They select the current in the motor windings used during movement.

9.2.35 AnalogFiltered

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
81-88	AnalogFiltered	16bit	R	0-1023	0	4.888mV	N/A

Description: These eight registers hold the software-filtered analog value of each of the eight I/Os: IO-1 to IO-8. Their values are updated every ten milliseconds. See the AFZUP_xx registers 100-106 for the filter parameters. Important: Also read the section on Analog filters in this manual.
To use the unfiltered values of the inputs for faster updates, but with no noise immunity, use registers 89-96 instead (AnalogIn, page 80).
An input voltage of 5.00 Volts corresponds to a register value of 1023.

9.2.36 AnalogIn

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
89-96	AnalogInput	16bit	R	0-1023	-	4.888 mV	N/A

Description: These eight registers hold the unfiltered analog value of each of the eight I/Os: IO-1 to IO-8. Their values are updated approximately every 182 micro-seconds.
To use the filtered values of the inputs for better noise immunity, use registers 81-88 instead (AnalogFiltered, page 80).
An input voltage of 5.00 Volts corresponds to a register value of 1023.

9.2.37 Busvol

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
97	BUSVOL	16bit	R	0-1023	-	109 mV	Bus Voltage

Description: The supply voltage inside the motor is continually measured and stored in this register. This value is the basis for the warnings and errors of Low Bus Voltage and Over Voltage.

9.2.38 Min_Busvol

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
98	MIN_BUSVOL	16bit	R/W	0-1023	15	109 mV	Min Bus Voltage

Description: Trigger point for under-voltage

9.2.39 Encoder_Type

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
99	ENCODER_TYPE	16bit	R	0-10	-	-	"Tooltip on motor"

9.2

Register Descriptions

9.2.40 Afzup_WriteBits

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
100	AFZUP_WriteBits	16bit	R/W	-	0	Special	N/A handled on the Filter Setup screen

Description: When changing values for the analog input filter parameters, this register is used in combination with registers 102-106. First, all of the registers 102-106 must be loaded with the values to be used for one or more analog input filters. Then the lower eight bits in this register are set to select which inputs the parameters in registers 102-106 should control. The firmware will detect this and copy the parameter values from registers 102-106 to internal storage. Once this has been completed, the firmware sets bit 15 in this register to show that registers 102-106 are free to receive new values for programming the remaining inputs with other filter parameters. To use the same filtering for all analog inputs, this register can be loaded with 255 (hex FF).

9.2.41 Afzup_ReadIndex

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
101	AFZUP_Read Index	16bit	R/W	0, 1-8, 32768-32775	0	Special	N/A handled on the Filter Setup screen

Description: This register makes it possible to read back the analog input filter parameters for one analog input at a time. To select a new input, write a value of 1 to 8 to this register and wait for bit 15 to be set high. When bit 15 has been set by the firmware, the registers 102-106 have been loaded with the filter parameters currently used by that analog input.

9.2.42 Afzup_ConfMin

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
102	AFZUP Conf Min	16bit	R/W	0-1022	0	4.888 mV	Confidence Min

Description: The minimum confidence limits for analog inputs are set and read back using this register in combination with the read and write 'command' registers 100 and 101. If a new raw sample value is less than the value in this register, it is simply discarded and the filtered input value in registers 81-88 will not change. A value of zero in this register will effectively disable the minimum confidence check.

9.2.43 Afzup_ConfMax

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
103	AFZUP_Conf Max	16bit	R/W	1-1023	1023	4.888 mV	Confidence Max

Description: The maximum confidence limits for analog inputs are set and read back using this register in combination with the read and write 'command' registers 100 and 101. If a new raw sample value is larger than the value in this register, it is simply discarded and the filtered input value in registers 81-88 will not change. A value of 1023 in this register will effectively disable the maximum confidence check.

9.2 Register Descriptions

9.2.44 Afzup_MaxSlope

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
104	AFZUP_Max Slope	16bit	R/W	2-1023	1023	4.888 mV	Max Slope

Description: The maximum slopes per sample for analog inputs are set and read back using this register in combination with the read and write 'command' registers 100 and 101. If a new raw sample value on an analog input lies farther from the previous filtered value in registers 81-88, the new sample will be modified to lie at most MaxSlope units from the filtered value. This is used to suppress noise and limit acceleration. Note that the value is optionally filtered after being slope limited, in which case the effective slope limitation will be divided by the filter ratio. A value of 1023 will effectively disable slope limitation.

9.2.45 Afzup_Filter

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
105	AFZUP_Filter	16bit	R/W	1-64	64	64 th of new sample	Filter (on the Filter setup screen)

Description: The final filtering of new samples on the analog inputs can be selected using this register in combination with the read and write 'command' registers 100 and 101. The final filtered value results from taking Filter/64 of the new sample plus (64-Filter)/64 of the old value and storing the result in registers 81-88. A value of 64 effectively disables this filtering, so the new sample simply replaces the old value.

9.2.46 FilterStatus

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
106	FilterStatus	16bit	R	0-65535	0		N/A (shown graphically)

Description: This register contains status bits for the analog input filters. The lowest eight bits hold confidence errors for each of the eight inputs, while the highest eight bits hold the status of their slope errors. The filter status is updated each second. The confidence error bit will be set if more than half of the samples within the last second fell outside either of the confidence limits. The slope errors will be set if more than half of the samples within the last second were slope limited.

9.2.47 PulseDirMask

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
108	PulseDirMask	16bit	R/W	0-65535	0	Bitmask	Pulse signal Direction signal

Description: The pulse and direction signals used to control the motor directly attached to the SMC75 board can also be optionally output to digital outputs and used to control other stepper motors. The value in this register selects one of three operating modes: Mode 0 in which the pulse/direction signals are used only internally to control the motor attached directly to the SMC75 board. Mode 1 in which the signals are not used internally but output to the digital outputs selected in register 109. Mode 2 where the signals are used both internally and sent out on the digital outputs. See register 109 (PulseDirMod, page 83) for more information.

9.2

Register Descriptions

9.2.48 PulseDirMod

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
109	PulseDirMode	16bit	R/W	0-2	0	-	Pulse/Direction mode

Description: When enabled by register 108, this register defines which of the eight digital outputs are used to transmit the pulse and direction signals. The lowest eight bits select which outputs will carry the pulse signal, while the highest eight bits select the outputs that carry the direction signal. More than one output can be selected for each type of signal, but the MacTalk program supports only one output for each signal. The outputs selected here must be manually configured to operate as outputs using register 125 (losetup, page 85).

9.2.49 SettlingTime

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
110	SettlingTime	16bit	R/W	0-32676	0	ms	Settling time between retries

Description: When the internal encoder option is installed and register 34, InPositionCount, is non-zero so AutoCorrection is enabled, the value in this register defines how many milliseconds to wait after each movement attempt before testing whether the encoder position is within the target window as defined in register 33. This waiting time is often necessary to allow mechanical oscillations to die out.

9.2.50 Sample 1-4

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
112-115	SAMPLE1-4	16bit	R/W	-	0	-	N/A

Description: Up to four registers can be set up to be sampled into buffers for diagnostic purposes. These registers define which registers are sampled. All of the registers 1-255 can be sampled. A value of zero in any of these four registers will cause the corresponding sample buffer to contain zeroes. See registers 116-119 for more information on the sampling system. Most users will use MacTalk to handle sampling.

9.2.51 Rec_Cnt

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
116	REC_CNT	16bit	R/W	-	0	-	N/A

Description: This value specifies the number of samples to take for each of the sampled registers selected in registers 112-115. This value must never be set larger than the value in the read-only register 119. Sampling will stop automatically after the specified number of samples has been taken.

9.2

Register Descriptions

9.2.52 S_Time

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
117	S_TIME	16bit	R/W	-	1	-	N/A

Description: This value selects the time in milliseconds between samples of the registers selected in registers 112-115.

9.2.53 S_Control

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
118	S_CONTROL	16bit	R/W	-	0	-	NA

Description: This value controls the sample system. It can assume three different values:
A value of zero is set by the firmware after all sampling has completed.
A value of one will initialize the sample system.
A value of two will start a new sample sequence and set this register to zero at completion.
The sampled values are read back using the command hex 53 SMC75_READSAMPLE.

9.2.54 Buf_Size

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
119	BUF_SIZE	16bit	R	-	-	-	N/A

Description: This read-only register contains the maximum length of the sample buffers used to sample the registers selected in registers 112-115. Register 116 should never be set to a value higher than the value in this register.

9.2.55 Index_Offset

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
120	INDEX_OFFSET	16bit	R	0-1599	-	Steps	Tests-

Description: This register can be selected to receive the absolute value of the internal encoder where the Zero search/home position was found during homing. This is selected by bit 0, Use Index, in register 122. It requires that the internal encoder option is installed.

9.2.56 Home_Bits

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
122	HOME_BITS	16bit	R/W	-	0	Special	Advanced-Zero Search

Description: Bit 0: Search for index
Bit 1: Change direction on limit.
Bit 2: Search for opposite side of sensor
Bit 3: Use Limit switch as sensor
Bit 4: Ignore switch (Used for searching only for index)
Contains configuration bits, that define how Zero search/homing should be carried out.

9.2 Register Descriptions

9.2.57 Setup_Bits

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
124	SETUP_BITS	16bit	R/W	-	0	Special	Don't start program after power up. Invert motor direction. External Encoder Enable DSP 402 Support Auto encoder synchronize

Description: Bit 0: Invert direction.
 Bit 1: Don't start program after power up.
 Bit 3,2: Select encoder input type. 0 = Disabled, 1 = Quadrature, 2 = Pulse/direction
 Bit 4: Enable DSP 402 support
 Bit 5: Synchronize to encoder after passive
 These individual bits are used to control various functions in the firmware.

9.2.58 Iosetup

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
125	IOSETUP	16bit	R/W	-	0	Special	Inputs/Outputs

Description: This register controls the eight IOs: IO-1 to IO-8. These pins can be used either in input mode as combined digital and analog inputs or used in output mode as digital outputs. The lowest eight bits in this register can be used to individually invert the active level of the digital inputs. The highest eight bits are used to select the corresponding pin as an output.

9.2.59 Turntable_Mode

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
126	TURNTABLE_MODE	16bit	R/W	-	0	Special	Turn Table -Mode

Description: In turntable mode, the motor controls the revolution of a turntable that has the number of positions specified in register 127, TurntableSize. This means the same position will be reached after rotating this number of steps in either direction.
 This register selects one of three modes that define how the motor should move to a new position when the P_SOLL register is changed.

If the value of this register is zero, the motor will not operate in turntable mode.

In mode 1, the motor will always move to a new position by turning in a positive direction. So to move one step backwards, it must instead move TurntableSize-1 steps forward.

In mode 2, the motor will always move to a new position by turning in a negative direction.

In mode 3, the motor will move in the direction that takes the smallest number of steps to reach the new position.

Note that the motor will not move at all if the new position in register P_SOLL is either negative or larger than the value of register 127, TurntableSize.

9.2

Register Descriptions

9.2.60 Turntable_Size

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
127	TURNTABLE_SIZE	32bit	R/W	-	0	Steps	Turn Table - Size

Description: If turntable mode is selected in register 126, the number of steps needed for a full revolution of the turntable is set in this register. Note that the register P_SOLL must always have a value between zero and the value in this register minus one. Negative values are not allowed for P_SOLL or TurntableSize.

9.2.61 NL_Mask

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
129	NL_MASK	16bit	R/W	-	0	IO Mask	Dedicated Inputs Negative Limit Input

Description: Selects which one of the eight IO pins to use for the dedicated function of Negative Position Limit.
Exactly one bit must be set, and the IO pin must be configured in register 125 as an input.

Example: If input 7 is to be used for the Negative Input Limit, write $2^6 = 64$ to this register.

9.2.62 PL_Mask

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
130	PL_MASK	16bit	R/W	-	0	IO Mask	Dedicated Inputs - Positive Limit Input

Description: Selects which one of the eight IO pins to use for the dedicated function of Positive Position Limit.
Exactly one bit must be set, and the IO pin must be configured in register 125 as an input.

Example: If input 8 is to be used for the Positive Input Limit, write $2^7 = 128$ to this register.

9.2.63 Home_Mask

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
132	HOME_MASK	16bit	R/W	-	0	IO Mask	Dedicated inputs. Home Input

Description: Selects which one of the eight IO pins to use for the dedicated function of Home Input.
Exactly one bit must be set, and the IO pin must be configured in register 125 as an input.

Example: If input 2 is to be used for the Home Input, write $2^1 = 2$ to this register.

9.2

Register Descriptions

9.2.64 Input_Filter_Mask

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
135	INPUT_FILTER_MASK	16bit	R/W	-	0	IO Mask	IOx digital input filter enabled

Description: This register controls filtering of each of the eight IO pins that are used as digital inputs. If the bit corresponding to the input number is set in this register, the input value will be filtered to a new logical level is only accepted after that level has been measured on the hardware pin for the number of milliseconds specified in register 136. If the bit is not set, the input will be updated directly from the hardware value every 100 microseconds. Please read the section on Digital Input filters in this manual.

9.2.65 Input_Filter_Cnt

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
136	INPUT_FILTER_CNT	16bit	R/W	-	5	ms	Input filter time

Description: The filtering of all of the eight digital inputs is controlled by the value in this register together with register 135. The input must be sampled at the same value for the specified number of milliseconds in this register to be accepted as the new filtered value. See also the section on Digital Input Filters in this manual.

9.2.66 Inpos_Mask

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
137	INPOS_MASK	16bit	R/W	-	0	IO MASK	Dedicated Outputs - In Position

Description: Selects which one of the eight IO pins to use for the dedicated function of In Position Output.

Exactly one bit must be set, and the IO pin must be configured in register 125 as an output.

The In Position output will then be set after a movement has completed.

Example: If output 1 is to be used for the In Position Output, write 20 = 1 to this register.

9.2.67 Error_Mask

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
138	ERROR_MASK	16bit	R/W	-	0	IO Mask	Dedicated Outputs - Error

Description: Selects which one of the eight IO pins to use for the dedicated function of Error Output. Exactly one bit must be set, and the IO pin must be configured in register 125 as an output.

The Error Output will set be set when any error is set.

See register 35 (Err_Bits, page 78) for more information on errors.

Example: If output 3 is to be used for the Error Output, write 22 = 4 to this register.

9.2

Register Descriptions

9.2.68 P_New

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
144	P_NEW	32bit	R/W	$(-2^{31})-(2^{31}-1)$	0	Counts	N/A

Description: This register can be used to change both of the registers P_SOLL and P_IST in one operation. This can be used to correct or offset the current position without performing a movement. The register value can be copied to P_IST and P_SOLL using FastMac command 23, or it can be added with sign to both of these registers using FastMac command 24.

9.2.69 Baud_Rate

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
146	BAUD_RATE	16bit	R/W	0-5	1	-	Baud Rate

Description: The baud rate on the serial port.

- 0 : 9600 baud
- 1 : 19200 baud (default)
- 2 : 38400 baud
- 3 : 57600 baud
- 4 : 115200 baud
- 5 : 230400 baud
- 6 : 460800 baud
- 7 : 921600 baud

The firmware will automatically update the baud rate after this value is changed over the serial interface (RS485) once the motor has finished transmitting all data bytes that are queued.

9.2.70 Tx_Delay

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
147	TX_DELAY	16bit	R/W	1-255	15	Bits	Transmit Delay

Description: The time to wait before the response is transmitted. The unit corresponds to the time of one bit at the current baud rate.

Many PLCs and communications processors require a minimum delay after they have sent a command to the motor before they are able to receive the response.

9.2.71 Group_Id

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
148	GROUP_ID	16bit	R/W	0-255	-	-	Group Id

Description: The group ID of the motor. The motor will accept data from a group write command only if the group ID number in the command matches this number. The idea is that several motors can have the same group ID so they can be updated with new register values in parallel to save transmission time.

9.2 Register Descriptions

9.2.72 Group_Seq

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
149	GROUP_SEQ	16bit	R	0-255	-	-	N/A

Description: The last received group write sequence.

9.2.73 My_Addr

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
150	MY_ADDR	16bit	R/W	0-254		-	Motor Address

Description: The motor address. Data communicated over the serial interface will only be accepted if the address byte in the command is either equal to this value or has the value 255, which means broadcast to all motors.

9.2.74 Motortype

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
151	MOTORTYPE	16bit	R	64-xx		-	"Status Bar"

Description: The motor type.
64: SMC75
65: MIS231
66: MIS232
67: MIS234
This value is read-only and is programmed into the motor during manufacturing.

9.2.75 Serial_Number

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
152	SERIAL-NUMBER	32bit	R	-	-	-	"Status Bar"

Description: The serial number of the motor.
This value is read-only and is programmed into the motor during manufacturing.

9.2.76 Checksum

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
154	CHECKSUM	32bit	R	0-65535	-		

Description: Firmware checksum.
This value is read-only and is programmed into the motor during firmware update.

9.2

Register Descriptions

9.2.77 Hardware_Rev

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
156	HARDWARE_REV	16bit	R	0-65535	-	Major*16+ Minor +16384	"Tooltip on Motor"

Description: The revision of the hardware. This value is read-only and is programmed into the motor during manufacturing.

9.2.78 Max_Voltage

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
157	MAX_VOLTAGE	16bit	R	0-100	*	Volt	"Tooltip on Motor"

Description: The maximum allowed voltage on the bus. If the bus voltage exceeds this value, the motor will enter an error state. This value is read-only and is programmed into the motor during manufacturing. It reflects the rating of the hardware components. Supplying a higher voltage can damage the electronics components permanently. If in doubt, it is strongly recommended to first supply 24 Volts and connect the motor to MacTalk. In MacTalk this value can be read by holding the mouse cursor over the image of the motor in the lower right of the main window.

9.2.79 Available_IO

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
158	AVAILABLE_IO	16bit	R	-	-	IO MASK	N/A

Description: Defines what IO that are available on the connector. This value is read-only and is programmed into the motor during manufacturing. Service personnel may ask for this value to identify the type of connector board mounted on the motor. The values are not documented here.

9.2.80 Bootloader_Ver

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
159	BOOTLOADER_VER	16bit	R	0-65535	-	Major*16+ Minor +16384	"Tooltip on Motor"

Description: The version of the boot-loader. This value is read-only and is programmed into the motor during manufacturing

9.2.81 Notsaved

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
160	NOTSAVED	16bit	R/W	0-65535	0	-	N/A

Description: This register is not used internally, but will always be 0 after power on. Please note that MacTalk uses this register

9.2

Register Descriptions

9.2.82 Option_Bits

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
165	OPTION_BITS	16bit	R	0-65535	-	-	"Tooltip on motor"

Description: This register contains information about what options are available. Bit 0-7 defines the options available in the hardware (or licensed). Bit 8-15 defines the options available in the firmware.

Bit 0,8 : CanOpen fieldbus
Bit 1,9 : DeviceNet fieldbus

9.2.83 Fbus_Node Id

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
166	FBUS_NODE ID	16bit	R/W	0-255	5	-	Fieldbus - Node ID

Description: The node id on the fieldbus interface.

9.2.84 Fbus_Baud

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
167	FBUS_BAUD	16bit	R/W	0-8	2	-	Fildbus - Baud Rate

Description: The baudrate used on the fieldbus interface.

0 : 1000 kbit/s
1 : 800 kbit/s (unsupported)
2 : 500 kbit/s
3 : 250 kbit/s
4 : 125 kbit/s
5 : 100 kbit/s
6 : 50 kbit/s
7 : 20 kbit/s
8 : 10 kbit/s

9.2.85 Ext_Encoder

Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
170	EXT_ENCODER	32bit	R/W	$(-2^{31})-(2^{31}-1)$	-	Counts	External Encoder

Description: This register counts the encoder input on IN1 + IN2. The type of input is selected using SETUP_BITS bit 2+3.

9.2.86 Ext_Encoder_Vel


Reg	Name	Size	Access	Range	Default	Unit	MacTalk name
172	EXT_ENCODER_VEL	16bit	R	$(-2^{15})-(2^{15}-1)$	-	Counts 16ms	External Encoder Velocity

Description: This register is updated with the velocity of the external encoder input. The velocity is measured every 16ms.

10.1 Getting started with programming

When using the SMC75, almost any kind of program can be created using a set of user friendly icons.

Make the required choice on the Programming tab.



After making one of these 2 choices, the program window will be opened.

10.2

Programming Main window

The main window for creating a new program or editing a program is shown below:


Programming menu
Main menu for creating a new program, Verifying program size and other basic details for the SMC75 Controller..


Transfer & Start
Will transfer the complete program and start it. Use *Stop* or *Pause* to stop it.


Stop
Use this button if the program must be stopped.


Program lines
Each Button represent a program line. By pushing the button a command can be entered at the program line.


SMC75 Status texts
The message *Program not transferred* means that there is a difference between the program seen on the screen and the actual program in the module. This can happen if the program have been edited but not transferred. *Status: Running (or Stopped)* refers to the program in the module.














TT2189GB

10.3

Programming menu

The menu found at the top of the main window gives access to the following options:

New program — Described elsewhere in this chapter
 Program setup — Upload the program from the module to MacTalk
 Upload program — Upload the program from the module to MacTalk
 Program information
 Print program
 Clear program

Program + Source
 Shows the memory usage if the program (compiled) + source program and remarks is downloaded into the module.
Program + Source - REM
 Same as above but without remarks.
Program only
 Same as above but without source program and remarks.

Checksum
 Shows the checksum of the complete program downloaded into the module. The checksum is unique and can be used to verify whether the program in the module matches the original program or not.
Lines
 The number of program lines used in the source program (MacTalk)
Mode
 Specify the program type actually used.

Skip initialization (advanced)
 Bypasses internal initialization routines after powerup. (Only for very special use).

Program + Source + Remarks
 Default. Choosing this will transfer everything down into the module memory. This can be an advantage if remarks and source program must be uploaded to MacTalk later.
Program + Source
 Same as above but without remarks.
Program only
 Only the compiled program is transferred.

Program information
 Size:
 Program + Source + REM: 25 B
 Program + Source: 25 B
 Program only: 19 B
 General information:
 Checksum: 600
 Lines: 1
 Program type: Absolute and relative

Setup
 Settings:
 Skip initialization [advanced]
 Transfer settings:
 Program + Source + Remark:
 Program + Source
 Program only

TT2173GB

10.4

How to build a program

When choosing New program in the Programming menu or entering MacTalk for the first time, programming can be started. Press the button at line 1 and a tool box will pop up.

1
Press the first button to create the first program line. The "Select command" box will pop up.

2
Choose the desired command. In this example it is desired to wait for an input to be activated before further program execution.

3
Choose to wait until input 5 is high and press OK

4
The command is inserted at the previous selected program line

TT0983GB

Continued

10.4


How to build a program

5

Press the second button to create the second program line


6

Choose the movement type needed. Relative: Move x counts forward with reference to the actual position. Absolute: Move to the x position with reference to the zero search position.



7

The relative move command just entered is converted into a program line.




8

Multiple program lines are entered by the user forming the last part of the program.

9

Now the program is finished. Press the "Transfer & Start" button. Now the program will be transferred and stored permanently in the module. The program will be executed immediately



TT0984GB

Continued

10.4

How to build a program

⑩



Now the program is running continuously. The actual program line which is executed is shown by the small red arrow.

⑪

By choosing the "Pause" button, the program is paused. After it is paused, it is possible to single step through each program line which can be a useful feature to debug the program since the action in each line can be closely observed.

⑫

When the program is finished, it can be saved on the harddisc or floppy disc. Please be aware that when saving the program it is the complete program including the overall setup of the motor such as servofilter, I/O setup etc. Everything is stored in a file with the extension .MAC. Later it can be opened and restored in the motor.



TT0985GB

10.5 General programming hints

When programming and saving programs the following hints may be useful to ensure that the program behaves as expected.

1. When transferring the program to the module, it is saved permanently in memory and the program will be executed each time the motor is switched on.
2. Before beginning to program, ensure that the basic parameters for controlling acceleration, torque, safety limits, etc. are set to proper values. When saving the program on the hard-disk or to floppy disc, all of these basic parameter settings will be saved together with the program as a complete motor setup package.
3. A program line can be edited by double-clicking on the command text.
4. When the cursor is placed on top of the command icon, an edit menu will be shown by right-clicking.

10.6 Command toolbox description

The toolbox used for programming covers 14 different command types.

The basic idea of the commands is to provide easy access to the most common functions of the motor. Some functions may seem to be missing at first glance, but the buttons “Set register in the QuickStep motor” or “Wait for a register value before continuing” give direct access to 50 registers in the basic QuickStep motor, such as the gear ratio or the actual torque register.

In total, this gives a very powerful programming tool since >95% of a typical program can be built using the simple command icons, while the remaining 5% is typically achieved by accessing the basic motor registers directly.

The following gives a short description of all 14 command icons.

The image shows a 'Select command' dialog box with 14 callout boxes pointing to specific icons. The callouts describe the following functions:


- Use: Initiates any motor movement relative or absolute.
- Use: Unconditional jump from one program line to another.
- Use: Inserts a delay in the program specified in milliseconds.
- Use: Write a value to almost any register in the basic MAC/MIS motor.
- Use: Wait until a certain register in the basic MAC/MIS motor reaches a certain value.
- Use: Initiates a zero search to a sensor.
- Use: Send a FastMac command to the motor. FastMac commands can be used to send complex instructions very quickly.
- Use: When a remark/Comment must be inserted in the program.
- Use: Set the motor in the desired mode such as position- or velocity mode.
- Use: Set a certain state at one or multiple digital outputs.
- Use: Conditional jump from one program line to another. Input dependent.
- Use: Wait for a certain state at one or multiple digital inputs.
- Use: Conditional jump from one program line to another. Register dependent.
- Use: Save the actual motor position to an intermediate register.
- Use: Preset the position counter to a certain value.
- Use: Performs a calculation using constants and register values, and stores the result in a motor register.
- Use: Conditional Jump according to a comparison between the values of two registers.
- Use: Sends a command in binary format, that enables various non-standard operations.

10.7 Graphic programming command reference

10.7.1 Enter your own remarks

Icon:	
Dialog:	
Function:	Inserts a remark/comment in the source code. The program line will not do anything, but can make the source code easier to read. This can be very important if other programmers have to review or work on the code, or if the program is only worked on infrequently.

10.7.2 Set operation mode


Icon:	
Dialog:	
Function:	Sets the operating mode of the motor. When the program encounters a program line with this command, the motor's operating mode will be set to the specified mode. This allows you to use different operating modes in different parts of the program. For a detailed description of the individual operating modes, refer to section 1.3.1., Basic modes/functions in the QuickStep motor, page 10.

10.7.3 Move operations

Icon:	
Function:	The Move command is very flexible, with five different operating modes. Each mode is described in its own section below.


10.7 Graphic programming command reference

10.7.4 Move (Relative)

Icon:	
Dialog:	
Function:	<p>Performs a movement relative to the current position. The distance moved is measured in encoder counts, and can either be entered directly or taken from three registers in the user memory area. For further information on using these memory registers, refer to the sections on the 'Save position' and 'Set position' commands.</p> <p>Note that if you specify a velocity, motor register no. 5 (V_SOLL) will be overwritten with this velocity value. Also, if you specify an acceleration, motor register no. 6 (A_SOLL) will be overwritten with the acceleration value specified. Register no. 49 (PI) is always overwritten by this command.</p> <p>If the 'Wait for in position' option is checked, the program will wait until the motor has finished the movement, before proceeding to the next program line. If this option is not checked, the program will start the movement, then immediately start executing the next command. The motor will finish the movement on its own, unless given other instructions by the program.</p>


10.7 Graphic programming command reference

10.7.5 Move (Relative + velocity change at a distance)

Icon:	
Dialog:	
Function:	<p>Performs a relative movement, and changes velocity at a specified distance before reaching the new position. The distances are measured in encoder counts and can either be entered directly, or taken from three memory registers in the RxP module. For further information on using these memory registers, refer to the sections on the 'Save position' and 'Set position' commands.</p> <p>Note that motor register no. 5 (V_SOLL) will always be overwritten with the value specified in the 'New velocity' field. Also, if you specify an acceleration, motor register no. 6 (A_SOLL) will be overwritten with the acceleration value specified. Register no. 49 (PI) is always overwritten by this command.</p> <p>This command always waits until the movement is finished, before proceeding to the next line in the program.</p>


10.7 Graphic programming command reference

10.7.6 Move (Relative + set outputs)

Icon:	
Dialog:	
Function:	<p>Performs a movement relative to the current position, and sets one or more outputs when the operation is completed. The distance moved is given in encoder counts and can either be entered directly, or can be taken from one of three memory registers in the user memory area. For further information on using these memory registers, refer to the sections on the 'Save position' and 'Set position' commands.</p> <p>Note that if you specify a velocity, motor register no. 5 (V_SOLL) will be overwritten with this velocity value. Also, if you specify an acceleration, motor register no. 6 (A_SOLL) will be overwritten with the acceleration value specified. Register no. 49 (PI) is always overwritten by this command.</p> <p>This command always waits until the movement is finished, before proceeding to the next line in the program.</p>


10.7 Graphic programming command reference

10.7.7 Move (Absolute)

Icon:	
Dialog:	
Function:	<p>Moves to an absolute, non-relative position. The position is given in encoder counts and can either be entered directly, or can be taken from one of three memory registers in the user memory area. For further information on using these memory registers, refer to the sections on the 'Save position' and 'Set position' commands.</p> <p>Note that if you specify a velocity, motor register no. 5 (V_SOLL) will be overwritten with this velocity value. Also, if you specify an acceleration, motor register no. 6 (A_SOLL) will be overwritten with the acceleration value specified.</p> <p>If the 'Wait for in position' option is checked, the program will wait until the motor has finished the movement before proceeding to the next program line. If this option is not checked, the program will start the movement, then immediately start executing the next command. The motor will finish the movement on its own, unless given other instructions by the program.</p>


10.7 Graphic programming command reference

10.7.8 Move (Sensor)

Icon:	
Dialog:	
Function:	<p>Performs a movement in the direction specified until an input condition is satisfied. The motor then moves the distance specified before stopping. The motor will not move farther than the Safety distance specified, regardless of whether the input condition is satisfied. The distances are measured in encoder counts and can either be entered directly, or taken from three memory registers in the user memory area. For further information on using these memory registers, refer to the sections on the 'Save position' and 'Set position' commands.</p> <p>Note that if you specify a velocity, motor register no. 5 (V_SOLL) will be overwritten with this velocity value. Also, if you specify an acceleration, motor register no. 6 (A_SOLL) will be overwritten with the acceleration value specified. Register no. 49 (PI) is always overwritten by this command.</p> <p>This command always waits until the movement is finished before proceeding to the next line in the program.</p>

10.7 Graphic programming command reference

10.7.9 Set outputs


Icon:	
Dialog:	
Function:	<p>Sets one or more outputs. When setting a single output, you can set it to high, low, or you can specify the length (in milliseconds) of a pulse to send out on that output. When setting multiple outputs, you can specify whether to set each output high, low, or leave it in its current state.</p>

10.7 Graphic programming command reference

10.7.10 Unconditional jump


Icon:	
Dialog:	None. After selecting this command, the mouse cursor changes. The next program line that you click on will become the destination for the jump.
Function:	Jumps to another line in the program.

10.7.11 Conditional jump (single input)

Icon:	
Dialog:	
Function:	<p>Tests for an input condition before either jumping to another line in the program or moving on to the next line in the program. If the condition is met, the command jumps to the specified program line. If the condition is not met, the program proceeds to execute the next line in the program.</p> <p>When 'Input type' is set to 'Single', the command can test a single input for one of four possible conditions: the input is low, the input is high, the input has transitioned to low (Falling Edge), or the input has transitioned to high (Rising Edge). If transitions are tested for, the transition must have taken place during the last 30 microseconds.</p> <p>After pressing the OK button, the dialog will disappear, and the mouse cursor will change. The next program line that you click on will then become the destination of the jump command.</p>

10.7 Graphic programming command reference

10.7.12 Conditional jump (multiple inputs)


Icon:	
Dialog:	
Function:	<p>Tests for an input condition before either jumping to another line in the program or moving on to the next line in the program. If the condition is met, the command jumps to the specified program line. If the condition is not met, the program proceeds to execute the next line in the program.</p> <p>When 'Input type' is set to 'Multiple', multiple inputs can be tested for being either high or low. The 'Operand' setting determines whether one or all of the inputs must meet their test criterion. If set to 'And', all inputs must match their test settings. If set to 'Or', only one input need match its test setting. Inputs that are set to 'Don't care' are not tested.</p> <p>After pressing the OK button, the dialog will disappear, and the mouse cursor will change. The next program line that you click on will then become the destination of the jump command.</p>

10.7 Graphic programming command reference

10.7.13 Wait for (x) ms before continuing


Icon:	
Dialog:	
Function:	<p>Causes the program to pause for a number of milliseconds before continuing. The maximum pause that can be specified is 65535 milliseconds. The minimum pause that can be specified is 0 milliseconds.</p> <p>Note that this command overwrites Timer 1 in the RxP module's memory.</p>

10.7.14 Wait for an input combination before continuing (single input)

Icon:	
Dialog:	
Function:	<p>Waits for a specified input condition to occur. The next line in the program will not be executed until the input condition has been met.</p> <p>If 'Input type' is set to 'Single', the command will wait for one of four things to happen on the specified input: that the input tests as high, that the input tests as low, that the input transitions from high to low (Falling Edge), or that the input transitions from low to high (Rising Edge). The input is tested with 30 microsecond intervals.</p>

10.7 Graphic programming command reference

10.7.15 Wait for an input combination before continuing (multiple inputs)

Icon:	
Dialog:	
Function:	<p>Waits for a specified input condition to occur. The next line in the program will not be executed until the input condition has been met.</p> <p>If 'Input type' is set to 'Multiple', multiple inputs can be tested for being either high or low. The 'Operand' setting determines whether one or all of the inputs must meet their test criterion. If set to 'And', all inputs must match their test settings. If set to 'Or', only one input need match its test setting. Inputs that are set to 'Don't care' are not tested. The inputs are tested with 30 microsecond intervals.</p>

10.7 Graphic programming command reference

10.7.16 Set a register in the MIS motor


Icon:	
Dialog:	 <p>The dialog box titled "Set register" has a blue title bar with a close button. It contains two rows of controls. The first row has a label "Reg. No.:" followed by a dropdown menu showing "3 - Requested position" and an "OK" button. The second row has a label "Value:" followed by a text input field containing "0", a dropdown menu showing "Revs.", and a "Cancel" button.</p>
Function:	<p>Sets a register in the motor to a specified value. The register is selected from a list of known, user-accessible registers. The value can either be entered as native motor units or it can be entered as generic engineering units.</p> <p>The dialog above provides an example: register no. 3 (P_SOLL, or Requested position, depending on your preference) can either be set to an integer number of encoder counts, or it can be set to a non-integer number of revolutions.</p>

10.7.17 Jump according to a register in the MAC motor

Icon:	
Dialog:	 <p>The dialog box titled "Register condition" has a blue title bar with a close button. It contains three rows of controls. The first row has a label "Reg. No.:" followed by a dropdown menu showing "10 - Actual position" and an "OK" button. The second row has a label "Operator" followed by a dropdown menu showing "= (Equal)" and a "Cancel" button. The third row has a label "Value:" followed by a text input field containing "0", a dropdown menu showing "Revs.", and a "Cancel" button.</p>
Function:	<p>Tests a register in the motor against a specified value before either jumping to another line in the program or moving on to the next line in the program. If the condition is met, the command jumps to the specified program line. If the condition is not met, the program proceeds to execute the next line in the program. The value can either be entered as native motor units, or it can be entered as generic engineering units.</p> <p>The dialog above provides an example: register no. 10 (P_IST, or Actual position, depending on your preference) must be equal to 0 revolutions if the jump is to be executed. The position that the register is tested against can be specified as an integer number of encoder counts or can be specified as a non-integer number of revolutions.</p> <p>After pressing the OK button, the dialog will disappear and the mouse cursor will change. The next program line that you click on will then become the destination of the jump command.</p>

10.7 Graphic programming command reference

10.7.18 Wait for a register value before continuing


Icon:	
Dialog:	
Function:	<p>Tests a register in the motor against a specified value and waits until the specified condition is met. The value can either be entered as native motor units or can be entered as generic engineering units.</p> <p>The dialog above provides an example: register no. 10 (P_IST, or Actual position, depending on your preference) must be less than 0 revolutions, before the program will continue. The position that the register is tested against can be specified as an integer number of encoder counts, or can be specified as a non-integer number of revolutions.</p>

10.7.19 Save position


Icon:	
Dialog:	
Function:	<p>Saves the current position from register no. 10 (P_IST) to one of three locations in the user memory area. The saved position(s) can then be used whenever a position or distance is needed in a move command.</p>

10.7 Graphic programming command reference

10.7.20 Set position


Icon:	
Dialog:	
Function:	Sets the current position stored in register no. 10 (P_IST) to one of three position values stored in the user memory area. This is the reverse of the 'Save position' command.

10.7.21 Zero search

Icon:	
Dialog:	
Function:	Initiates a zero search. The program waits until the zero search has completed before proceeding to the next command. For a detailed description of how to set up a zero search, refer to Zero search modes, page 58


10.7 Graphic programming command reference

10.7.22 Send FastMAC command (change mode and activate register)


Icon:	
Dialog:	
Function:	<p>FastMAC commands are also sometimes referred to as FlexMAC commands. The advantage of these commands is a very low communication overhead. FastMAC/FlexMAC commands are described in detail in section 4.5.7 of the MAC user manual, JVL publication no. LB0047-20GB. However, a brief summary is in order.</p> <p>If 'Mode' is set to 'Passive', 'Velocity', or 'Position', the motor will switch to that mode. Also, one of the passive motor registers will be activated, in the sense that its value will be written to the corresponding active motor register, which actually controls motor behaviour. In the example above, the value in register no. 65 (VI) will be written to register no. 5 (V_SOLL). Move operations will then take place at that velocity.</p>

10.7 Graphic programming command reference

10.7.23 Send FastMAC command (macro command)


Icon:	
Dialog:	
Function:	<p>If 'Mode' is set to 'Command', the motor does not necessarily change mode but it can be commanded to carry out a series of predetermined operations. Describing all of the FastMAC commands is beyond the scope of this section but for example, using a single command it is possible to activate four different sets of registers, each controlling position, velocity, acceleration, torque, load factor, and in-position window. For further details, refer to section 4.5.7 of the MAC user manual.</p>

10.7.24 Binary command

Icon:	
Dialog:	
Function:	<p>MacTalk SMC75 programs are sent to the motor in a compact, binary format, which is then interpreted by the SMC75's firmware. The existing set of graphic commands covers most situations, but when special needs arise, anything that can be done with SMC75 programs can be done with a binary command. If special needs arise that are not covered by the other commands, contact JVL for assistance.</p>


10.7 Graphic programming command reference

10.7.25 Calculator (basic)

Icon:	
Dialog:	
Function:	<p>Performs a calculation using register values, constants, and the four basic arithmetic operations: +, -, * and /. The result is stored in a register. Arithmetic operations take place in the order that they are specified. Operands/arguments can be either integer constants or registers. The caption of the dialog box shows the resulting expression in traditional infix format. It is continuously updated as you type in the expression.</p> <p>Note that if you write a value to a register using this command, that value is always measured in native motor units. Conversion from generic engineering units is only supported for the commands 'Set a register in the MAC motor', 'Jump according to a register in the MAC motor', and 'Wait for a register value before continuing'.</p>


10.7 Graphic programming command reference

10.7.26 Calculator (options)

Icon:	
Dialog:	
Function:	<p>The options tab contains various settings that affect the operation of the Calculator command. 'Calculation precision' is currently preset to 32-bit precision and cannot be changed. This is not an error, and should not be reported.</p> <p>'Register listing and naming' provides an alternative method of entering data into the dialog by selecting 'Simple list with short firmware names'. Instead of selecting, for example, '3 – Requested position' to access register no. 3, you can simply type 'P_SOLL'. If you wish to enter a constant, you simply enter the digits – the dialog will not mistake the constant for a register number.</p> <p>If you are in doubt about a register name, look at the expression in the caption of the dialog box. A recognized register name will appear in the expression. An unrecognized register name will appear as a zero. You can switch between the two methods of data entry at any time.</p>

10.7 Graphic programming command reference

10.7.27 Jump according to a comparison

Icon:	
Dialog:	
Function:	<p>Compares two registers with each other before either jumping to another line in the program or moving on to the next line in the program. If the condition is met, the command jumps to the specified program line. If the condition is not met, the program proceeds to execute the next line in the program.</p> <p>Any two registers can be compared with each other but the command does not do anything beyond comparing the registers numerical values measured in native motor units. To ensure that comparisons are meaningful, it is preferable to compare registers that hold the same type of information in the same binary format.</p> <p>In the example above, two position registers are compared. Both hold position information, both are 32-bit wide, and both measure position in encoder counts. Such a comparison will always yield meaningful, predictable results.</p> <p>For other types of registers, see the relevant register sections.</p>

This chapter deals with JVL's Step motor controller SMC75, which is used with the MIS231, MIS232 and MIS234 motors on a CANopen network.

The chapter covers the following main topics:

- General introduction: a section with general information about CANopen. See section 11.1.1 to section 11.1.5.
- Setting up the Baud-rate, node-id and termination of the CAN bus. Covers also the wiring of the CAN bus. See section 11.2.1 to section 11.2.6.
- Using CanOpenExplorer.
See section 11.3.1 to section 11.3.3.
- Survey of Communication specific objects and manufacturer specific objects in the DS301 standard. Communication objects consist of the general information about the settings in the module, while the Manufacturer specific objects consist of the settings of input/output and the motor parameters. This section also covers the settings of the transmit and receive PDOs in the module. See section 11.4.1 to section 11.4.6.
- Survey of objects which are used in the DSP-402 standard. See section 11.5.1 to section 11.5.7.
- Section with more detailed explanations of the CANopen theory, particularly DS-301.
See section 11.6.1 to section 11.6.7.

11.1 General information about CANopen

11.1.1 Introduction

A CanOpen option is available for the SMC75. When this option is installed, the SMC75 includes a CANopen slave. Through the CANopen slave, all the registers of the SMC75 can be accessed. The SMC75 implements an object dictionary that follows the CiA DS-301 standard.

The SMC75 contains a number of statically mapped PDOs that can be used to access the most common registers.

It also supports the DSP-402 (motion profile) standard, and the motor can be controlled using this as well.

The SMC75 Controller is designed to be used on a CANbus, CANopen DS-301 and CANopen DSP-402. Do not use the module together with CANKingdom or DeviceNet.

11.1.2 CiA membership

CiA (CAN in Automation) is a non-profit society. The object of the society is to promote CAN (Controller-Area-Network) and to provide a path for future developments of the CAN protocol. CiA specifications cover physical layer definitions as well as application layer and device profile descriptions.

In order to receive the CAN standard, is it necessary to obtain CiA membership. The membership fee depends on a company's number of employees. Membership runs from January 1st until December 31st and is renewed automatically unless cancelled in writing by the end of a calendar year. Companies applying for membership after July 1st pay 50% of annual membership.

A PDF application form can be downloaded from <http://www.can-cia.org/cia/application.html>.


Note: Once you have received a license from CIA, standards will be sent on a CD and are downloadable via member login. All of the CiA specifications can be ordered from the following URL:

www.can-cia.org/downloads/ciaspecifications/

11.1.3 CANopen network

The CAN bus is a serial bus with multi-master capabilities where different products from different manufacturers can communicate with each other. These include, for example, devices such as PLCs, motors, sensors and actuators. Some message types have higher priority and are sent first, for time-critical applications. New devices can easily be integrated on an existing bus, without the need to reconfigure the entire network. The devices are connected through a 2-wire bus cable with ground, and data is transmitted serially.

11.1 General information about CANopen



11.1.4 CANopen, general information

CANopen is a CAN-based, higher-level protocol. The purpose of CANopen is to give an understandable and unique behaviour on the CAN network. The CAN network is the hardware level of the system, and CANopen is the software level. CANopen is based on the communication profile described in CiA DS-301, and specifies all of the basic communication mechanisms.

CiA DS-301 contains message types on the lowest software level. The DSP-402 CANopen standard defines the device profile and the functional behaviour for servo drive controllers, frequency inverters and stepper motors. The DSP-402 constitutes a higher software level, and it uses the DS-301 communication, but makes the device independent of the manufacturer. Not all JVL functionality is available.

The CANbus with real-time capabilities works in accordance with the ISO 11898 standard. The major performance features and characteristic of the CAN protocol are described below:

Message-oriented protocol:

The CAN protocol does not exchange data by addressing the recipient of the message, but rather marks each transmitted message with a message identifier. All nodes in the network check the identifier when they receive a message to see whether it is relevant for them. Messages can therefore, be accepted by none, one, several or all participants.

Prioritisation of messages:

As the identifier in a message also determines its priority for accessing the bus, it is possible to specify a correspondingly rapid bus access for messages according to their importance. Especially important messages can thus gain access to the bus without a prolonged wait-time, regardless of the loading on the bus at any instant.

This characteristic means that important messages are transmitted with high priority even in exceptional situations, thereby ensuring proper functioning of a system even during phases of restricted transmission capacity.

11.1 General information about CANopen

Multi-Master capability:

Bus access rights are not issued by a mean-level control unit (bus master) per network. Instead, each network node can start to send a message with equal rights as soon as the bus has become free. If several participants access the bus at the same time, an arbitration process allocates each participant the bus access right in line with the priority of the message they want to send at that particular moment. Each participant can therefore communicate directly with every other participant. As the transmission of a message can be initiated by the message source itself, then in the case of event-controlled transmission of messages, the bus is only occupied when a new message is on-hand.

No-loss bus arbitration:


As the bus is accessed at random under the CAN protocol, it is possible that several participants try to occupy the bus at the same time. In other random bus access routines, this causes the destruction of suppressed messages. In order to solve such a bus access conflict, a repeated occupation of the bus is required using an appropriate triggering strategy. The CAN protocol therefore deploys a routine to ensure that the message with the highest priority at any given time is sent without any destruction of message contents.

Short block length:

The maximum data length of a CAN message is limited to 8 bytes. This data length is usually sufficient to transmit the information occurring in the lowest field area in a CAN message.

11.1.5 Header

A CAN message transmits the communications object and a variety of management and control information. The management and control information bits are used to ensure error-free data transmission, and are automatically removed from the received message and inserted before a message is sent. A simplified CANopen message could be as in the figure below:



The two bit fields “Header” and “Data” form the simplified CANopen message. The 11-bit Header is also designated as the identifier or as the COB-ID (Communication Object identifier).

11.1 General information about CANopen

JVL uses the 11-bit format type CAN A, but not the 29-bit format type CAN B.

The COB-ID carries out two tasks for the controller communications object.

- Bus arbitration: Specification of transmission priorities.
- Identification of communications objects.

The COB-ID comprises two sections:

- Function code, 4 bits in size (0...15)
- Node address (Node ID), 7 bits in size (0...127).

The function code classifies the communications objects, and controls the transmission priorities. Objects with a small function code are transmitted with high priority. For example, in the case of simultaneous bus access an object with the function code "1" is sent before an object with the function code "3".

Node address:

Every device is configured before network operation with a unique 7-bit long node address between 1 and 127. The device address "0" is reserved for broadcast transmissions, in which messages are sent simultaneously to all devices.

PDO, SDO, EMCY, NMT and heartbeat use the header frame for communication on the CANopen bus.

11.2 Connection and setup of the CAN bus

11.2.1 Connecting the SMC75 Controller to the CAN bus

Before you connect the Controller SMC75 to the CAN-bus, the Baud-rate, the Node-ID and the termination must be selected.

On the serial bus it is possible to set a transmission speed (Baud-rate) of max. 1000 Kbit/s and a min. of 10 Kbit/s. The Baud-rate depends on the cable length, and the wire cross-section. The table below gives some recommendations for networks with less than 64 nodes. Recommended bus cable cross-sections are according to CIA.

:

Bus Distance (m)	Cross-section (mm ²)	Terminator (Ohms)	Baud-rate (Kbit/s)
25	0.25-0.34	120	1000
100	0.34-0.6	150-300	500
250	0.34-0.6	150-300	250
500	0.5-0.6	150-300	125
500	0.5-0.6	150-300	100
1000	0.75-0.8	150-300	50

The bus wires may be routed in parallel, twisted and/or shielded, depending on EMC requirements. The layout of the wiring should be as close as possible to a single line structure in order to minimize reflections. The cable stubs for connection of the bus node must be as short as possible, especially at high bit rates. The cable shielding in the housing must have a large contact area. For a drop cable, a wire cross-section of 0.25 to 0.34 mm² would be an appropriate choice in many cases.

For bus lengths greater than 1 km, a bridge or repeater device is recommended. Galvanic isolation between the bus nodes is optional.

11.2.2 Necessary accessories for SMC75 Controller:

The EDS file for the SMC75 is available for download at JVL's web-site, <http://www.jvl.dk>, under the downloads menu, Field bus Interface Specifications Files. EDS means Electronic Data Sheet. This file contains the information about SMC75 settings that are required to configure the setup and program in the master. The SMC75 is a slave module on the CAN-bus. The master can, for example, be a PLC or a PC.

If you are using a PLC as master, then make sure it is provided with a CANopen communications module, and that the correct programming tools are available. For support of the PLC master, the PLC vendor is recommended.

If you are using a PC as master, JVL provides some tools that can help when installing and using the SMC75 Controller.

11.2 Connection and setup of the CAN bus

The latest firmware for the SMC75 is available at JVL's web-site under the menu downloads/firmware. In the site's programs menu, the software CanOpen Explorer is also available, but note that this is not a free-ware program. Please contact your JVL representative for further information.

CanOpen Explorer can be used to load the EDS file and operate with the motor. The CanOpenExplorer software must use a special dongle for communication with the PC. For further information about the dongle, see An overall method for communication test, page I 30. The PC must be provided with a CANopen communications module.

11.2.3 EDS (Electronic data Sheet)

In order to give the user of CANopen more support, the device description is available in a standardised way, and gives the opportunity to create standardised tools for configuration of CANopen devices, designing networks with CANopen devices, and managing project information on different platforms. The EDS file are ASCII-coded.

11.2.4 Setting the node id and baud rate

The node id is set using MacTalk. It is located in register I 62. The baud rate is also set using MacTalk and is located in register I 63.

11.2 Connection and setup of the CAN bus

11.2.5 Bus termination


In order to guarantee correct operation of the CAN bus, bus terminating resistors must be provided at both ends of the bus cable.

CAN bus connectors:

The SMC75 does not use 9-pin D-sub connectors and none of the cables JVL supplies are provided with a 9-pin D-sub connector, but the PIN configuration is also shown in the table below.

Signal	Description	SMC75	D-sub
-	Reserved		Pin 1
CAN_L	CAN_L bus line (Low)	Pin 5	Pin 2
CAN_GND	CAN Ground	Pin 3	Pin 3
-	Reserved		Pin 4
(CAN_SHLD)	Optional CAN Shield	Pin 1	Pin 5
(GND)	Optional CAN Ground		Pin 6
CAN_H	CAN_H bus line (High)	Pin 4	Pin 7
-	Reserved (error line)		Pin 8
CAN_V+	Optional CAN ext. + supply	Pin 2	Pin 9

The figure below shows the 9-pin D-sub and 5-pin style connectors.



11.2 Connection and setup of the CAN bus

11.2.6 SMC75 connectors, rear plate layout

The MIS motors offer IP67 protection and M12 connectors which make them ideal for automation applications where no additional protection is desired. The M12 connectors offer solid mechanical protection and are easy to unplug.

The connector layout:

“PWR” - Power input. M12 - 5-pin male connector					
Signal name	Description	Pin no.	JVL Cable W11000M12 F5A05N	Isolation group	
P+	Main supply +12-48VDC. Connect with pin 2 *	1	Brown	1	
P+	Main supply +12-48VDC. Connect with pin 1 *	2	White	1	
P-	Main supply ground. Connect with pin 5 *	3	Blue	1	
CV	Control voltage +12-28VDC.	4	Black	1	
P-	Main supply ground. Connect with pin 3 *	5	Grey	1	
* Note: P+ and P- are each available at 2 terminals. Ensure that both terminals are connected in order to split the supply current in 2 terminals and thereby avoid an overload of the connector.					
“BUS1” - CAN-open interface. M12 - 5-pin male connector					
Signal name	Description	Pin no.	Cable: user supplied	Isolation group	
CAN_SHLD	Shield for the CAN interface - internally connected to the motor housing	1	-	2	
CAN_V+	Reserved for future purpose - do not connect	2	-	2	
CAN_GND	CAN interface ground	3	-	2	
CAN_H	CAN interface. Positive signal line	4	-	2	
CAN_L	CAN interface. Negative signal line	5	-	2	
“BUS2” - CANopen interface. M12 - 5-pin female connector					
Signal name	Description	Pin no.	Cable: user supplied	Isolation group	
CAN_SHLD	Shield for the CAN interface - internally connected to the motor housing	1	-	2	
CAN_V+	Reserved for future purpose - do not connect	2	-	2	
CAN_GND	CAN interface ground	3	-	2	
CAN_H	CAN interface. Positive signal line	4	-	2	
CAN_L	CAN interface. Negative signal line	5	-	2	
“IO” - I/Os and RS485 interface. M12 - 8-pin female connector.					
Signal name	Description	Pin no.	JVL Cable W11000-M12 M8A05N	Isolation group	
IO1	IO5	I/O terminal 1	1	White	3
IO2	IO6	I/O terminal 2	2	Brown	3
IO3	IO7	IO terminal 3	3	Green	3
GNDIO	GNDIO	Ground for I/O	4	Yellow	3
B+	Tx	RS485 (5V serial)	5	Grey	3
A-	Rx	RS485 (5V serial)	6	Pink	3
IO4	IO8	I/O terminal	7	Blue	3
CVO	CVO	Out	8	Red	3
Cable Screen					
Some standard cables with M12 connector offer a screen around the cable. This screen on some cables is fitted to the outer metal at the M12 connector. When fitted to the SMC75 controller, this means that the screen will have contact with the complete motor housing and thereby also the power ground (main ground).					

11.3 Using CanOpenExplorer

11.3.1 The CanOpenExplorer program

The CanOpenExplorer is a program that was developed for internal use only, especially in production, but the program offers features that are very convenient and which make it very easy to start up the MIS motor when this is supplied with an SMC75 CANopen Controller module.

The program can write and send SDOs, PDOs, SYNC and heartbeat messages, and also can read EDS files.

11.3.2 An overall method for communication test

Depending on the type of master and software solution available, the following components must be available:

PLC: PLC with a CANopen module and software that can communicate with this module.

The CANopen module must be connected to a CAN bus, as shown in section 11.2.6. To set up the master, download the EDS file from the JVL web site (see section 11.2.2). This file contains all register set-up data for the SMC75 Controller. For details of the node-ID and the Baud-rate, see section 11.2.4. The power supply must be connected to the motor as shown in section 11.2.6.

PC: PC with a CAN adaptor and software that can communicate with this module, or if the CanOpen Explorer software is used, the PCAN-USB Dongle from Peak-system that is connected to a USB port on the PC. The Peak systems web site address is <http://www.peak-system.com>. This includes a list of distributors. To set up the master, download the EDS file from the JVL web-page, see section 11.2.2. This file contains all register set-up data for the SMC75. For details of the node-ID and the Baud-rate, see section 11.2.4. The power supply must be connected to the motor as shown in section 11.2.6.


If CanOpenExplorer is used, see the following method for testing the motor communication:

- Install CanOpenExplorer
- Connect the motor to the USB port via the Dongle.
- Connect power supply, see section section 11.2.6 or section 2.
- Run the CanOpenExplorer program on the PC.

- 1: Select the correct node ID in the slave using MacTalk. See section 11.2.4.
- 2: Select the EDS file. For all the MIS motors this file is SMC75.eds.
- 3: Load the EDS file by pressing load.


11.3

Using CanOpenExplorer



4: Select here on the + the manufacturer specific register.


5: Select thereafter the object 0x2012. Object 0x2012 contains the motor parameters.




11.3

Using CanOpenExplorer

6: Point to the sub register 0x02, which is the register that determines in which mode the motor will operate.



Press W on the keyboard. The following screen appears:



- 7: Type 02 in the window, and press OK.
- 8: Click on the sub register 0x05, which is the register to choose the velocity the motor will use. Press W on the keyboard, type 100 in the window, and press OK. The value 100 is in RPM.
- 9: Click on the sub register 0x03, which is the register to choose the distance the motor will run. Press W on the keyboard, type 20000 in the window, and type OK. The value 20000 is in Steps

11.3

Using CanOpenExplorer

Now the motor shaft will rotate slowly, until the motor has counted 20000 Encoder pulses. If you want to stop the motor, then click on sub register 0x02 and write 0 in the window, and the motor will switch to passive mode. If using other software, the test could be described as, (using object 2012h):

Sub-register	Name	Width	Unit	Operation	Value
02h	Mode_Reg	16 bit		Set up the motor in position mode	02h
05h	V_SOLL	16 bit	RPM	Sets up the desired velocity	100h
03h	P_SOLL	32 bit	Steps	The motor rotates the desired numbers of encoder pulses	20000
02h	Mode_Reg	16 bit		Sets the motor to passive mode	00h
Returning the motor with higher velocity					
02h	Mode_Reg	16 bit		Set up the motor in position mode	02h
05h	V_SOLL	16 bit	RPM	Sets up the desired velocity	200h
03h	P_SOLL	32 bit	Steps	The motor rotates the desired numbers of Steps	-20000
02h	Mode_Reg	16 bit		Sets the motor in passive mode	00h

11.3.3 How to use CanOpenexplorer

After startup, the name and details of the HW-interface, such as PCAN_USB should appear upper left.

When you turn on a motor/CAN node after having started CanOpenexplorer, the Data Window (large centre right), will contain a message with the number 0x7xx, where xx is the node ID. For example: 0x704 will indicate node 4. Set the Node ID field top centre to that value (4).

Ensure that the correct EDS_file is loaded. The program loads a hard-coded default file - either smc75.eds or mac00-fc.eds. It is also possible to load another EDS file by writing the file name in the "EDS file" field, top centre, and pressing the load button. Note that the EDS view (large centre left panel) will add the new file at the bottom but will not clear any existing file(s) that are loaded.

Normal operation will be to select an object in the EDS view pane, and press either R for read or W for write. Pressing R should read the value (successful if no error pops up). Pressing W for write will pop up a small window in which the present value is displayed in both decimal and hex. It is then possible to write a new value either in decimal or hex using a 0x prefix, such as 0x185 to enable the first TPDO on node 5 (by clearing the high bit). If the "Add to list" checkbox is checked, the object will be added to the user SDO list as a write SDO. Pressing A performs a read and adds it to the user SDO list pane (lower right) as a read SDO.

The SDOs in the user SDO pane can be rearranged by dragging them with the mouse. Double-clicking on a user SDO list will execute the operation, either reading or writing. The bus state can be changed using the NMT buttons, lower left, e.g. to Operational to enable PDOs.

11.3

Using CanOpenExplorer

The button Read User SDOs will read all of the “R” type objects in the user SDO list. This is useful for updating a large number of values in the EDS view.

The button Write User SDOs will write all of the “W” type objects in the user SDO list. This is useful for automated testing.

Entries can be deleted from the user SDO list by selecting them with the mouse and pressing the delete key.

The sync Time field (top right) sets the time in milliseconds for the SYNC messages to be sent out. SYNCs can be started and stopped using the buttons Enable Sync and the Stop button to the right.

The Guard Time field below the Sync Time field works like SYNC - just for the Guarding message.

The close button exits the program after saving the list of user SDOs, which will be automatically reloaded at the next program start.

11.4 Objects in the DS301 standard

11.4.1 DS301 specified Communications objects

The DS301 specified Communications objects are shown in the table below. To obtain the default value in CanOpenExplorer, press R on the keyboard, and the actual value will be shown.

Name	Index (hex)	Sub Index	Data Type	Read only	Default	Description
Device type	1000		UNSIGNED32	X	0x40192	Contains information about the device type. See note at top of next page. Mandatory.
Error Register	1001		UNSIGNED8	X		This is the mapping error register, and it is part of the emergency object. If any of the sub indices are high, an error has occurred. See also section 11.4.2. Mandatory
		0				Generic error. Mandatory
		1				Current
		2				Voltage
		3				Temperature
		4				Communication (Overrun)
		5				Device profile specific
		6				Reserved
	7	Manufacturer specific				
Reservation register	1004					Reservation of PDOs
		0		X		Reserved numbers of PDOs
		1		X		Reserved numbers of syncPDOs
		2		X		Reserved numbers of asyncPDOs
Manufacturer device name	1008		VISIBLE STRING	X	JVL A/S	
Manufacturer hardware version	1009		VISIBLE STRING	X		
Manufacturer software version	100A		VISIBLE STRING	X		Example: Version x.x

11.4 Objects in the DS301 standard

Name	Index (hex)	Sub Index	Data Type	Read only	Default	Description
Guard time	100C		UNSIGNED16			Informs about the Guard time in milliseconds. Is only mandatory if the module does not support heartbeat
Life time factor	100D		UNSIGNED8			Is the factor that guard time is multiplied with to give the life time for the node quarding protocol
Heartbeat time	1017		UNSIGNED8			If the Heartbeat timer is not 0, Heartbeat is used.
Identity object	1018		IDENTITY	X		Contain general information about the module
		0	1..4	X	4h	Number of entries. Mandatory
		1	UNSIGNED32	X	0x0117	Vendor ID, contains a unique value allocated to each manufacturer. 117h is JVLs vendor ID. Mandatory.
		2	UNSIGNED32	X	0x0200	Product Code, identifies a specific device version. SMC75 has the product code 200H
		3	UNSIGNED32	X		Revision number.
		4	UNSIGNED32	X		Serial number

Note regarding “device type” (index 1000):

The device type register is composed of 2 16-bit registers. One register describes which device profile the module supports, and the other states which type of motors the module supports, and possible I/O module. The default value 0192h denotes that the DSP402 Device profile is supported, and the value 0004h denotes that the SMC75 Controller supports stepper motors.

11.4.2 Emergency object

The EMCY (emergency) object is used to transfer an error message to the CANopen master, or also to another node which can process the error message. The reaction on the emergency object is not specified. An emergency object is transmitted only once per “error event”.

The SMC75 supports the EMC object (Emergency).

The following error codes can be generated:

Errorcode 1001h: Generic error - Motor error

Errorcode 1002h: Generic error - Position error

Errorcode 1003h: Generic error - Follow error

Errorcode 1004h: Generic error - Low

Transmit PDO25:

Use Transmit PDO25 in asynchronous mode to read the status of the error.

In the SMC75, no error control is enabled when the modules are started up because if there is any fault in the system, it is impossible to get in contact with the module. After the module has started up and there is communication between the master and the slave, turn on the required error control mechanism in the communication objects, see section 11.4.1.

11.4 Objects in the DS301 standard

11.4.3 Object dictionary

Name	Index (hex)	Sub Index	Type	Read only	Default	Description
Motor parameters	2012	0	Unsigned8	x	254	Subindex count
		n	Unsigned32			Access to the 32 bit motor register, n
Motor parameters	2014	0	Unsigned8	x	254	Subindex count
		n	Unsigned16			Access to the motor register n, but as 16bit

Writing to these objects in CANopenExplorer is done by pressing W on the keyboard when the register in folder Manufacturer is selected. Reading is done by pressing R.

Object 2012h – Motor parameters

With this object, all the registers of the MIS motor can be accessed. All the registers are accessed as 32 bit. When reading and writing to 16-bit registers, the values are automatically converted in the module.

Object 2014h – Motor parameters (16 bit)

Works as 2012h, but the parameters are accessed as 16-bit. If writing to a 32bit parameter, the 16-bit value will be treated as signed.

11.4.4 Enable and Disable PDOs

In the CANOpen profile, it is only possible to have four transmit and four receive PDOs enabled at the same time. In the SMC75 controller, all PDOs are disabled when the module is booted up. The user must choose which PDOs the application will use and enable these.

To enable or disable a PDO, it is necessary to write to the MSB (bit 31) in the PDO COB-ID entry in the PDO communication parameter Record. The COB-ID register is sub-index 1h, and the value range of this register is UNSIGNED32.

The PDOs are enabled when bit 31 is 0, and is disabled when bit 31 is 1.

11.4.5 Receive PDOs

The PDO 1-20 are reserved for use with DSP-402.
The following receive PDOs are available:

Receive PDO 21:

This PDO can be used to update the position, velocity and acceleration. The data in the PDO is written directly to the position register and if the motor is in position mode, it will start moving to that position.

11.4 Objects in the DS301 standard

The table below shows default values of the COB-ID:

PDO	Sub-index	Type	Description	Default	Access type
21	1	Receive	COB-ID	Nodeid+0x80000200	r/w
	1	Transmit	COB-ID	Nodeid+0x80000180	r/w
22	1	Receive	COB-ID	Nodeid+0x80000300	r/w
	1	Transmit	COB-ID	Nodeid+0x80000280	r/w
23	1	Receive	COB-ID	Nodeid+0x80000400	r/w
	1	Transmit	COB-ID	Nodeid+0x80000380	r/w
24	1	Receive	COB-ID	Nodeid+0x80000500	r/w
	1	Transmit	COB-ID	Nodeid+0x80000480	r/w
25	1	Transmit	COB-ID	Nodeid+0x80000480	r/w

Byte	0	1	2	3	4	5	6	7
Data	P_SOLL			V_SOLL		A_SOLL		
Object	2012h, sub 3			2014h, sub 5		2014h, sub 6		

Receive PDO 22:

With this PDO it is possible to update the running current and operating mode.

Byte	0	1	2	3	4	5	6	7
Data	RUN_CURRENT		MODE_REG					
Object	2014h, sub 7		2014h, sub 2					

Receive PDO 23:

This PDO can be used to issue a Motor command.

Byte	0	1	2	3	4	5	6	7
Data	Motor Command		Reserved	Reserved	Reserved	Res.	Res.	Res.
Object	2014h, sub 24							

Receive PDO 24:

This PDO updates the outputs.

Byte	0	1	2	3	4	5	6	7
Data	Output data		Reserved	Reserved	Reserved	Res.	Res.	Res.
Object	2014h, sub 19							

11.4 Objects in the DS301 standard

11.4.6 Transmit PDOs

The PDOs 1-20 are reserved for use with DSP-402.

All of the transmit PDOs support synchronous transmission. PDO 25 also supports asynchronous transmission.

Transmit PDO 21:

With this PDO the actual position can be read.

Byte	0	1	2	3	4	5	6	7
Data	P_IST				V_IST		Motor error	
Object	2012h, sub 10				2014h, sub 12		2014h, sub 35	

Transmit PDO 22:

With this PDO the actual velocity can be read.

Byte	0	1	2	3	4	5	6	7
Data	V_IST		Reserved	Reserved	Reserved	Res.	Res.	Res.
Object	2014h, sub 12							

Transmit PDO 23:

With this PDO the value of the analog inputs 1-4 can be read.

Byte	0	1	2	3	4	5	6	7
Data	ANALOG1		ANALOG2		ANALOG3		ANALOG4	
Object	2014h, sub 89		2014h, sub 90		2014h, sub 91		2014h, sub 92	

Transmit PDO 24:

With this PDO the value of the analog inputs 4-8 can be read.

Byte	0	1	2	3	4	5	6	7
Data	ANALOG5		ANALOG6		ANALOG7		ANALOG8	
Object	2014h, sub 93		2014h, sub 94		2014h, sub 95		2014h, sub 96	

11.4 Objects in the DS301 standard

Transmit PDO 25:

With this PDO the motor status, inputs and last error can be read.
This PDO also supports asynchronous transmission. If this PDO is in asynchronous mode, it will be transmitted every time the run status or inputs are changed.

Byte	0	1	2	3	4	5	6	7
Data	Inputs		Motor error		Res.	Res.	Res.	Res.
Object	2014h, sub 18		2014h, sub 35					

11.5 Objects used in the DSP-402 standard

11.5.1 DSP-402 Support

Introduction

The SMC75 supports the DSP-402 standard from CiA (<http://www.can-cia.com/>). Please refer to this standard for details of the functions.

The DSP-402 is only a standard proposal and might be changed in the future. JVL therefore reserves the right to change future firmware versions to conform to new versions of the standard.

Not all of the functionality described in DSP-402 is supported, but all mandatory functions are supported.

The following operation modes are supported:

- Profile position mode
- Velocity mode
- Homing mode

Preconditions

The start mode of the motor must be set to passive.

No power up zero searches must be selected.

When using the DSP-402 mode, manipulating parameters with object 2012h or 2014h can corrupt the behaviour of the DSP-402 functions. Also be aware that manipulating parameters in MacTalk should be avoided when using DSP-402.

11.5 Objects used in the DSP-402 standard

Supported objects

The following table gives the additional object dictionary defined for DSP-402 support.

Name	Index (hex)	Sub Index	Type	Read only	Default
Device data					
Motor_type	6402	0	UNSIGNED16	X	9
Motor_catalog_number	6403	0	VISIBLE_STRING	X	SMC75
Motor_manufacturer	6404	0	VISIBLE_STRING	X	JVL A/S
http_motor_catalog_address	6405	0	VISIBLE_STRING	X	www.jvl.dk
Supported_drive_modes	6502	0	UNSIGNED32	X	37
Drive_catalog_number	6503	0	VISIBLE_STRING	X	SMC75
Drive_manufacturer	6504	0	VISIBLE_STRING	X	JVL A/S
http_drive_catalog_address	6505	0	VISIBLE_STRING	X	www.jvl.dk
Digital I/O					
Digital_inputs	60FD	0	UNSIGNED32	X	
Digital_outputs	60FE	0	UNSIGNED8	X	
Digital_outputs_Physical_outputs	60FE	1	UNSIGNED32		
Digital_outputs_Bit_mask	60FE	2	UNSIGNED32		
Device Control					
Abort_connection_option_code	6007	0	INTEGER16		
Error_code	603F	0	UNSIGNED16		
Controlword	6040	0	UNSIGNED16		
Statusword	6041	0	UNSIGNED16	X	
Quick_stop_option_code	605A	0	INTEGER16		
Modes_of_operation	6060	0	INTEGER8		
Modes_of_operation_display	6061	0	INTEGER8	X	
Profile Position parameters					
Position_actual_value	6064	0	INTEGER32	X	
Target_position	607A	0	INTEGER32		
Software_position_limit	607D	0	UNSIGNED8	X	2
Software_position_limit_Min_position_limit	607D	1	INTEGER32		
Software_position_limit_Max_position_limit	607D	2	INTEGER32		
Max_motor_speed	6080	0	UNSIGNED32		
Profile_velocity	6081	0	UNSIGNED32		
Profile_acceleration	6083	0	UNSIGNED32		

11.5 Objects used in the DSP-402 standard

Name	Index (hex)	Sub Index	Type	Read only	Default
Quick_stop_deceleration	6085	0	UNSIGNED32		
Motion_profile_type	6086	0	INTEGER16		
Profile velocity mode					
Velocity_sensor_actual_value	6069	0	INTEGER32	X	
Velocity_demand_value	606B	0	INTEGER32	X	
Velocity_actual_value	606C	0	INTEGER32	X	
Velocity_window	606D	0	UNSIGNED16		
Velocity_window_time	606E	0	UNSIGNED16		
Target_velocity	60FF	0	INTEGER32		
Max_torque	6072	0	UNSIGNED16		
Homing mode					
Home_offset	607C	0	INTEGER32		
Homing_method	6098	0	INTEGER8		
Homing_speeds	6099	0	UNSIGNED8	X	2
Homing_speeds_Speed_during_search_for_switch	6099	1	UNSIGNED32		
Homing_speeds_Speed_during_search_for_zero	6099	2	UNSIGNED32		
Homing_acceleration	609A	0	UNSIGNED32		
Factors					
Position_notation_index	6089	0	INTEGER8		
Position_dimension_index	608A	0	UNSIGNED8		
Velocity_notation_index	608B	0	INTEGER8		
Velocity_dimension_index	608C	0	UNSIGNED8		
Acceleration_notation_index	608D	0	INTEGER8		
Acceleration_dimension_index	608E	0	UNSIGNED8		
Position_encoder_resolution	608F	0	UNSIGNED8	X	2
Position_encoder_resolution_Encoder_increments	608F	1	UNSIGNED32		
Position_encoder_resolution_Motor_revolutions	608F	2	UNSIGNED32		
Velocity_encoder_resolution	6090	0	UNSIGNED8	X	2
Velocity_encoder_resolution_Encoder_increments_per_second	6090	1	UNSIGNED32		
Velocity_encoder_resolution_Motor_revolutions_per_second	6090	2	UNSIGNED32		
Gear_ratio	6091	0	UNSIGNED8	X	2
Gear_ratio_Motor_revolutions	6091	1	UNSIGNED32		
Gear_ratio_Shaft_revolutions	6091	2	UNSIGNED32		
Feed_constant	6092	0	UNSIGNED8	X	2

11.5 Objects used in the DSP-402 standard

Name	Index (hex)	Sub Index	Type	Read only	Default
Feed_constant_Feed	6092	1	UNSIGNED32		
Feed_constant_Shaft_revolutions	6092	2	UNSIGNED32		
Position_factor	6093	0	UNSIGNED8	X	2
Position_factor_Numerator	6093	1	UNSIGNED32		
Position_factor_Feed_constant	6093	2	UNSIGNED32		
Velocity_encoder_factor	6094	0	UNSIGNED8	X	2
Velocity_encoder_factor_Numerator	6094	1	UNSIGNED32		
Velocity_encoder_factor_Divisor	6094	2	UNSIGNED32		
Acceleration_factor	6097	0	UNSIGNED8	X	2
Acceleration_factor_Numerator	6097	1	UNSIGNED32		
Acceleration_factor_Divisor	6097	2	UNSIGNED32		
Polarity	607E	0	UNSIGNED8		

11.5.2 Factors

Position factor

The position factor is the relation between the user unit and the internal position unit (steps).

The position factor is automatically calculated when the feed constant (Obj. 6092h) and gear ratio (Obj. 6091h) are set.

Example:

A MIS232 Motor with a 3.5:1 gear box is connected to a belt drive. The diameter of the drive wheel is 12.4 cm.

The unit of position is required to be in millimetres.

The perimeter of the drive wheel is 389.56mm (124mm*pi)

The parameters should be set as follows:

Object	Name	Value
6091 _h subindex 1	Gear ratio - Motor revolutions	35
6091 _h subindex 2	Gear ratio - Shaft revolutions	10
6092 _h subindex 1	Feed constant - Feed	38956
6092 _h subindex 2	Feed constant - Shaft revolutions	100

11.5 Objects used in the DSP-402 standard

Velocity encoder factor

This factor is used to convert the user unit into the internal unit (RPM).
The factor is adjusted with the object 6094h.

Example 1:

An MIS232 has 1600 counts/revolution.

We want the user unit of velocity to be in RPM. This is the same as the internal unit.

The parameters should be set as follows:

Object	Name	Value
6094 _h subindex 1	Velocity encoder factor - Numerator	1600
6094 _h subindex 2	Velocity encoder factor – Divisor	1600

Example 2:

We have an MIS232 that uses RPM as the internal velocity and the same belt drive as in the above Position factor example.

We want the user unit of velocity to be in mm/s.

The parameters should be set as follows:

Object	Name	Calculated value	Value
6094 _h subindex 1	Velocity encoder factor - Numerator	$(60 \cdot 3.5) / 389,56 = 0.53907$	53907
6094 _h subindex 2	Velocity encoder factor – Divisor	1	100000

Acceleration factor

This factor is used to convert the user unit into the internal unit (9.54 RPM/s).
The factor is adjusted with the object 6097h.

Example 1:

We have an MIS232 with 1600 counts/revolution.

We want the user unit of acceleration to be in RPM/s.

The parameters should be set as follows:

Object	Name	Value
6097 _h subindex 1	Acceleration encoder factor - Numerator	100
6097 _h subindex 2	Acceleration encoder factor – Divisor	954

11.5 Objects used in the DSP-402 standard

Example 2:

We have an MIS232 with 1600 counts/revolution and the same belt drive as in the above Position factor example.

We want the user unit of acceleration to be in mm/s².

The parameters should be set as follows:

Object	Name	Calculated value	Value
6097 _h subindex 1	Acceleration factor- Numerator	$(3,5 \cdot 60) / 389,56 = 0.53907$	53907
6097 _h subindex 2	Acceleration factor - Divisor	9.54	954000

11.5.3 Changing operation mode

Change of operation mode is only possible when the operation mode is not enabled.

There is one exception and that is when changing from homing mode to profile position mode. This is possible when the homing sequence is completed and can be done even though the operation mode is enabled.

11.5.4 Profile position mode

This mode can be used for positioning in which a move profile can be set up. The acceleration and maximum velocity can be programmed.

In this mode both absolute and relative movement is supported. This is selected using bit 6 (abs/rel) in the status word. It is also possible to select different movement modes. This is done with bit 5 (change set immediately) in the status word. When this bit is 0 and a move is in progress, the new set-point is accepted, but the new set-point and profile are not activated until the previous movement is finished. When this bit is 1, the new set-point is activated instantly and the motor will move to the new position with the new profile parameters.

11.5.5 Velocity mode

In this mode the motor runs at a selected velocity. A new velocity can be selected and the motor will then accelerate/decelerate to this velocity.

The maximum slippage error is not supported in this mode.

11.5.6 Homing mode

Using this mode, different homing sequences can be initiated. The standard homing modes from 1-34 are supported. Before starting the homing, the inputs must be configured properly using MacTalk or parameters 125, 129, 130, 132.

11.5 Objects used in the DSP-402 standard

11.5.7 Supported PDOs

Receive PDOs

PDO no.	Mapping object index	Mapping object name	Comment
1	6040 _h	Controlword	controls the state machine
2	6040 _h 6060 _h	Controlword Modes of operation	controls the state machine and modes of operation
3	6040 _h 607A _h	Controlword Target position	controls the state machine and the target position (pp)
4	6040 _h 60FF _h	Controlword Target velocity (pv)	controls the state machine and the target velocity (pv)
7	6040 _h 60FE _h	Controlword Digital outputs	controls the state machine and the digital outputs

Transmit PDOs

PDO no.	Mapping object index	Mapping object name	Event driven
1	6041h	Statusword	Yes
2	6041h 6061h	Statusword Modes of operation display	Yes
3	6041h 6064h	Statusword Position actual value	No
4	6041h 606Ch	Statusword Velocity actual value	No
7	6041h 60FDh	Statusword Digital inputs	Yes

11.6 More details of CANOpen Theory

11.6.1 CANopen DS-301 device profiles

Standardized devices in CANopen have their characteristics described in a device profile. For each device profile, particular data and parameters are strictly defined. Data and parameters are known as objects in CANopen. Objects perform all processes in CANopen; they can perform various tasks, either as communications objects or as device-specific objects where they are directly related to the device. A communication object can transport data to the bus control and establish connection, or supervise the network devices.

The application layer makes it possible to exchange meaningful real-time-data across the CAN network. The format of this data and its meaning must be known by the producer and the consumer(s). There are encoding rules that define the representation of values of data types and the CAN network transfer syntax for the representations. Values are represented as bit sequences. Bit sequences are transferred in sequences of octets (byte). For numerical data types, the encoding is with the lowest byte first.

Every object is described and classified in the object dictionary (or index) and is accessible via the network. Objects are addressed using a 16-bit index so that the object dictionary may contain a maximum of 65536 entries.

Index (Hex)	Object	Supported by MAC00-FC2/FC4
0000-	Not used	
0001-001F	Static data types	
0020-003F	Complex data types	
0040-005F	Manufacturer specific Data Types	
0060-0FFF	Reserved for further use	
1000-1FFF	Communication Profile area DS301	Yes
2000-5FFF	Manufacturer specific profile area	Yes
6000-9FFF	Standardised Device Profile area (DSP-402)	Yes
A000-FFFF	Reserved for further use	

Index 0001-001F:

Static data types contain type definitions for standard data types like boolean, integer, floating point, etc. These entries are included for reference only, they cannot be read or written.

Index 0020-003F:

Complex data types are predefined structures that are composed out of standard data types and are common to all devices.

Index 0040-005F:

Manufacturer-specific data types are also structures composed of standard data types but are specific to a particular device.

Index 1000-1FFF:

The communication Profile area contains the parameters for the communication profile on the CAN network. These entries are common to all devices.

Index 2000-5FFF:

The manufacturer-specific profile area, for truly manufacturer-specific functionality.

11.6 More details of CANOpen Theory

Index 6000-9FFF:

The standardised device profile area contains all data objects common to a class of devices that can be read or written via the network. The drives profile uses entries from 6000h to 9FFFh to describe the drive parameters and the drive functionality. Within this range, up to 8 devices can be described. In such a case, the devices are denominated Multi Device Modules. Multi Device Modules are composed of up to 8 device profile segments. Using this feature it is possible to build devices with multiple functionality. The different device profile entries are shifted with 800h.

A 16-bit index is used to address all entries within the object dictionary. In the case of a simple variable, this index references the value of the variable directly. In the case of records and arrays however, the index addresses the whole data structure. To allow individual elements of structures of data to be accessed via the network, a sub-index has been defined. For single object dictionary entries such as Unsigned8, Boolean, Integer32, the value of the sub-index is always zero. For complex object dictionary entries such as arrays or records with multiple data fields, the sub-index refers to fields within a data-structure pointed to by the main index. Index counting starts with one.


The DS-301 standard constitutes the application and the communications profile for a CANopen bus, and is the interface between the devices and the CAN bus. It defines the standard for common data and parameter exchange between other bus devices, and it controls and monitors the devices in the network. The table below lists some of the communications profile objects:

Data Transfer	Parameter Transfer	Special functions	
PDO			Process Data Objects
	SDO		Service Data Objects
		SYNC	Synchronisation
		EMCY	Emergency

The access from the CAN network is done through data objects PDO (Process Data Object) and SDO (Service Data Object).

11.6.2 Boot up telegram

After the initialization phase, a CANopen slave logs on with a boot up message. The node address of the slave is contained in this. This allows a CANopen master to know which slaves are connected to the network. The protocol uses the same identifier as the error control protocols. See the figure below:



One data byte is transmitted with value 0.

11.6 More details of CANOpen Theory

11.6.3 PDO (Process Data Object)

PDO: Performs real-time transfers, and the transfer of PDOs is performed without a protocol. PDOs are used in two ways: for data transmission and for data reception. PDOs can bundle all objects from the object data directory, and a PDO can handle max 8 bytes of data in the same PDO. The PDO can consist of multiple objects. Another PDO characteristic is that it does not reply when it is receiving data, in order to make data transfer fast. It has a high priority identifier.

PDO connections follow the Producer/Consumer model, whereby a normal PDO connection follows the Push model and an RTR connection the Pull model.


Objects are mapped in a PDO. This mapping is an agreement between the sender and receiver regarding which object is located at which position in the PDO. This means that the sender knows at which position in the PDO it should write data and the receiver knows where it should transfer the data to that is received.

The PDOs correspond to entries in the Device Object Dictionary and provide the interface to the application objects. Data type and mapping of application objects into a PDO are determined by a corresponding PDO mapping structure within the Device object Dictionary. The number and length of PDOs of a device are application specific and must be specified within the device profile

Write PDO service:

The Write PDO service is unacknowledged. A PDO producer sends its PDO to the PDO consumer. There can be 0 or more consumers in the network. For receive PDOs the SMC75 Controller is the consumer and for Transmit PDOs, the producer.


The following figure shows a Write PDO service:



11.6 More details of CANOpen Theory

Read PDO service:

The read PDO service is an acknowledged service. One of the several PDO consumers send an RTR message to the network. After it has received the RTR message, the PDO producer sends the requested PDO. This service is used for RTR queries. Using this service, an actual value can be interrogated independently of the selected cycle time. The following figure shows a read PDO service:



PDO identifier:

In the CAN-Open profile, it is only possible to have four transmit and four receive PDOs enabled at the same time. In the SMC75 controller, all PDOs are disabled when the module is booted up. The user must choose which PDOs the application will use and enable these.

The PDO configuration can be seen either in the EDS-file or in the CanOpen Explorer program, where the communication and the mapping parameters are shown.

There are two standard methods to map the PDOs in CANopen: static mapping and dynamic mapping. In static PDO mapping all PDOs are mapped in accordance with some fixed, non-modifiable setting in the relevant PDO. In dynamic PDO mapping, the setting of a PDO can be modified. It is also allowable to have a flexible combination of different process data during operation. The SMC75 controller uses only static mapping.

11.6.4 SDO (Service Data Objects)

SDO: can access all entries in the object directory but they are normally used in the initialization during the boot up procedure. Some SDOs characteristics are:


- Confirmed transfer of objects
- Data transfer/exchange is always non-synchronous
- Values greater than 4 bytes are transferred (Normal transfer)
- Values not more than 4 bytes are transferred (Expedited transfer)

Basically an SDO is transferred as a sequence of segments. Prior to transferring the segment, there is an initialization phase where client and server prepare themselves for transferring the segment. For SDOs, it is also possible to transfer a dataset of up to four bytes during the initialisation phase. This mechanism is called an expedited transfer.

Download SDO protocol:

The download SDO protocol is used to write the values of the object directory into the drive.

11.6 More details of CANOpen Theory



Upload SDO protocol:

The upload SDO protocol is used to read the values in the object directory of the drive.




Table for upload and download SDO protocol.

	CCS:	SCS:	n:	e:	s:	m:
Down-load	1: Initiate download request	3: Initiate download response	Only valid if e=1 and s=1 otherwise 0. If valid it indicates the number of bytes in d that do not contain data. Bytes [8-n,7] do not contain data	Transfer type: 0= normal transfer 1= expedited transfer	Size indicator: 0=data set size is not indicated 1=data set size is indicated	Multiplexer. It represents the index/sub-index of the data to be transfer by the SDO
Upload	2: Initiate upload request	2: Initiate upload response	Only valid if e=1 and s=1 otherwise 0. If valid it indicates the number of bytes in d that do not contain data. Bytes [8-n,7] do not contain data	Transfer type: 0= normal transfer 1= expedited transfer	Size indicator: 0=data set size is not indicated 1=data set size is indicated	Multiplexer. It represents the index/sub-index of the data to be transfer by the SDO

CCS: Client command specified.

SCS: Server commander specified.

11.6 More details of CANOpen Theory


Table for upload and download SDO protocol (continued)

	d:	X:	Reserved:
Download	<p>e=0, s=0: d is reserved for further use</p> <p>e=0, s=1: d contains the number of bytes to be downloaded. Byte 4 contains the lsb and byte 7 contains the msb</p> <p>e=1, s=1: d contains the data of length 4-n to be downloaded, the encoding depends on the type of the data referenced by index and sub-index.</p>	not used, always 0	Reserved for further use, always 0
Upload	<p>e=0, s=0: d is reserved for further use</p> <p>e=0, s=1: d contains the number of bytes to be uploaded. Byte 4 contains the lsb and byte 7 contains the msb</p> <p>e=1, s=1: d contains the data of length 4-n to be uploaded, the encoding depends on the type of the data referenced by index and sub-index.</p>	not used, always 0	Reserved for further use, always 0

Abort SDO transfer protocol:

SDO tasks which the SMC75 controller cannot process are responded to using an abort SDO protocol. If the module does not respond in the expected time, the CANOpen master also sends an abort SDO.

The following figure shows an abort SDO transfer protocol:



There are various abort codes in CANOpen. These are listed in the table below:


Abort code	Description
0503 0000h	Toggle bit not alternated
0504 0000h	SDO Protocol timed out
0504 0001h	Client/server command specified not valid or unknown
0504 0002h	Invalid block size (block mode only)
0504 0003h	Invalid sequence number (block mode only)
0504 0004h	CRC error (block mode only)
0504 0005h	Out of memory
0601 0000h	Unsupported access to an object
0601 0001h	Attempt to read a write-only object
0601 0002h	Attempt to write a read-only object
0602 0000h	Object does not exist in the object dictionary
0604 0041h	Object cannot be mapped to the PDO

11.6 More details of CANOpen Theory

Abort code	Description
0604 0042h	The number and length of the objects to be mapped would exceed PDO length
0604 0043h	General parameter incompatibility reason
0606 0000h	Access failed due to a hardware error
0607 0010h	Data type does not match, length of service parameter does not match
0607 0012h	Data type does not match, length of service parameter too high
0607 0013h	Data type does not match, length of service parameter too low
0609 0011h	Sub-index does not exist
0609 0030h	Value range of parameter exceeded (only for write access)
0609 0031h	Value of parameter written too high
0609 0032h	Value of parameter written too low
0609 0036h	Maximum value is less than minimum value
0800 0000h	General error
0800 0020h	Data cannot be transferred or stored to the application
0800 0021h	Data cannot be transferred or stored to the application because of local control
0800 0022h	Data cannot be transferred or stored to the application because of the present device state
0800 0023h	Object dictionary dynamic generation fails or no object dictionary is present (e.g. object dictionary is generated from file and generation fails because of a file error).

11.6.5 SYNC (Synchronisation Object)

A SYNC producer sends the synchronization object cyclically a broadcast telegram. The SYNC telegram defines the basic clock cycle of the network. The time interval of the SYNC telegram is set using the object Communication Cycle period (1006h). In order to obtain a precise (accurate) cycle between the SYNC signals, the SYNC telegram is sent with a high-priority identifier. This can be modified using the object (1005h). The SYNC transfer applies the producer/consumer push model and is non-confirmed.




The SYNC does not carry any data (L=0). The identifier of the SYNC object is located at object 1005h.

11.6 More details of CANOpen Theory

11.6.6 NMT (Network Management services)

The Network Management is structured according to nodes and follows a master-slave structure. NMT objects are used for executing NMT services. Through NMT services, nodes are initialised, started, monitored, reset or stopped. All nodes are regarded as NMT slaves. An NMT slave is uniquely identified in the network by its Node-ID. NMT requires that one device in the network fulfils the function of the NMT master. The NMT master controls the state of the NMT slaves. The state attribute is one of the values (Stopped, Pre-operational, Operational, Initialising). The module control services can be performed with a certain node or with all nodes simultaneously. The NMT master controls its own NMT state machine via local services which are implementation dependent. The Module Control Service, except Start Remote Node, can be initiated by the local application.

A general NMT protocol:



Where **CS** is the NMT command specified. The Node-ID of the NMT slave is assigned by the NMT master in the Node Connect protocol, or 0. If 0, the protocol addresses all NMT slaves.

CS =	Operation
1	Start Remote Node
2	Stop Remote Node
128	Enter Pre Operational
129	Reset Node
130	Reset Communication

Start Remote Node:

This is an instruction for transition from the Pre-Operational to Operational communications state. The drive can only send and receive process data when it is in the Operational state.

Stop Remote Node:

This is an instruction for transition from either Pre-Operational to stopped or from Operational to Stopped. In the stopped state, the nodes can only process NMT instructions.

Enter Pre Operational:

This is an instruction for transition from either Operational or Stopped state to Pre-Operational. In the Pre-Operational state, the node cannot process any PDOs. However, it can be parameterized or operated via SDO. This means set point can also be entered.

11.6 More details of CANOpen Theory

Reset Node:

This is an instruction for transition from the Operational, Pre-Operational or Stopped states to Initialization. After the Reset Node instruction, all objects (1000h-9FFFh) are re-set to the Voltage On stage.

Reset Communication:

This is an instruction for transition from Operational or Stopped to Initialization. After the Reset Communication instruction, all communication objects (1000h-1FFFh) are re-set to the initial state.

In the various communication states, nodes can only be accessed via CAN-Open using specific communication services. Further, the nodes in the various states only send specific telegrams. This is clearly shown in the following table:

	Initializing	Pre-Operational	Operational	Stopped
PDO			X	
SDO		X	X	
Synchronization Object		X	X	
Emergency Object		X	X	
Boot-Up Object	X			
Network Management object		X	X	X

11.6.7 Error Control Services

Two possibilities exist for performing Error Control:

- Node Guarding/Life Guarding
- Heartbeat

Node Guarding/Life Guarding

With Node Guarding, the CANopen master sends each slave an RTR telegram (Remote Transmit request) with the COB-ID 1792 (700h) + node-ID.

Using the same COB-ID, the slave responds with its communications state, i.e. either Pre-Operational, Operational or stopped.

The CANopen slave also monitors the incoming RTR telegram from the master.


The cycle of the incoming RTR telegrams is set using the Guard Time Object.

The number of RTR telegrams which can fail (at a maximum) before the slave initiates a Life Guarding event is defined using the Life time factor object.

The Node Life Time is calculated from the product of the Guard Time and Life Time Factor. This is the maximum time that the slave waits for an RTR telegram.

The figure below shows a Node Guarding/Life Guarding protocol.

11.6 More details of CANOpen Theory



Where s is the state of the NMT slave:


s	NMT state
4	Stopped
5	Operational
7	Pre-operational

t: is the toggle bit. It alternates between 2 consecutive responses from the NMT Slave. The value of the toggle-bit of the first response after the guarding protocol becomes active is 0. The Toggle Bit in the guarding protocol is only reset to 0 when the NMT message Reset Communication is passed (no other change of state resets the toggle bit). If a response is received with the same value of the toggle-bit as in the preceding response, then the new response is handled as if it was not received.

Heartbeat:

With the Heartbeat protocol, a Heartbeat Producer cyclically sends its communications state to the CAN bus. One or more Heartbeat Consumers receive the indication. The relationship between producer and consumer is configurable via the object dictionary. The Heartbeat Consumer guards the reception of the Heartbeat within the Heartbeat Consumer time. If the Heartbeat is not received within the Heartbeat Consumer Time, a Heartbeat Event will be generated.

11.6 More details of CANOpen Theory



Where r is reserved (always 0).
 s: is the state of the Heartbeat producer:

s	NMT state
0	Boot up
4	Stopped
5	Operational
7	Pre-operational

Only one communication monitoring service may be activated. This is either Node Guarding/Life Guarding or Heartbeat. If the Heartbeat Producer Time is configured on a device, the Heartbeat Protocol begins immediately. If a device starts with a value of the Heartbeat Producer Time different from 0, the Heartbeat Protocol starts with the state transition from Initialising to Pre-operational. In this case the Bootup Message is regarded as the first heartbeat message. If the Heartbeat producer time is not 0, the heartbeat protocol is used.

In the SMC75, none of the error control mechanisms is enabled when the modules are started up, because if there is any fault in the system it is impossible to contact the module. After the module has started up and there is communication between the master and the slave, activate the required error control mechanism in the object Dictionary. See section 11.4.1.

12.1

Velocity accuracy

When setting a velocity in V_SOLL, the motor will not run at that exact velocity. The exact velocity can be calculated with the following formula:

$$\text{resulting velocity} = \frac{93750 \pm 1.1\%}{\text{Round}\left(\frac{93750}{V_SOLL}\right)}$$

Note: The “Round” function rounds the number to the nearest integer.

Also note that the lowest possible velocity is 1.43 RPM and the highest is 1023 RPM.

12.2

Command timing

Each command has a certain execution time. The specified execution time in the following table is the maximum execution time if not using CANopen, serial communication and the motor is disabled. The actual execution may be faster.

Icon	Name	Execution time [µs]
	Remarks	0
	Set operation mode	60
	Move relative (no velocity, no acceleration) ¹	90
	Move relative+set velocity (no acceleration) ¹	150
	Move relative+set velocity+set acceleration ¹	210
	Move absolute (no velocity, no acceleration) ¹	60
	Move absolute+set velocity (no acceleration) ¹	120
	Move absolute+set velocity+set acceleration ¹	180
	Set single output (high/low)	30
	Set multiple outputs	30*number of outputs
	Unconditional jump	30
	Conditional jump (inputs)	60
	Set a register	60
	Conditional jump (register)	120
	Save position	60
	Set position	90
	Send fastMAC command	30
	Binary command	30

1) The time for all move commands is shown without waiting for in position

12.3 More about program timing

The firmware is structured so that one program instruction is executed for each pass of the main loop, which takes approximately 30 microseconds (μs) without CANopen, without serial communications and when the motor is not running. The Main Loop Time is termed MLT in the following text.

A single program line in MacTalk can generate more than one instruction. For example, assigning a constant value to a register uses two instructions: First load the value to the internal stack and then Store from the stack to the target register. The above table in section 12.2 reflects this operation.

The main loop time will vary depending on a number of factors: The motor velocity, the serial communications speed and load, whether CANopen is installed, and the CANopen communications speed and load.

Simply running the motor will load the motor up to 17% so the MLT becomes $\sim = 37 \mu s$ at full speed (1023 RPM).

Serial communications on the RS-485 line can load the motor up to 1% at 19.200 baud, which is insignificant, but at the maximum baud rate of 921.600 the communications can load the motor up to 45%, which would result in an MLT of $\sim 60 \mu s$.

When CANopen firmware is installed, the basic MLT will change from 30 to 90 μs with no communications.


When loading the CANbus with communications, the MLT can rise significantly. For example, when using seven transmit PDOs with an event timer value of 1 ms and a CANbus link speed of 500 kbits/s, the MLT can rise to 150-200 μs . Also using RS-485 communications at high baud rates can result in even longer MLT values. However, this scenario is very unlikely.

Note: In applications where program timing is critical, tests must be performed to ensure that timing is satisfactory when communication is running according to conditions used in production!


12.4

Motor Connections


Connection of JVL and MAE motors (parallel). Type MST23x/ MST34x and HY200-xxxx-xxx-x8




Connection of JVL and MAE 4 wire motors. Type MST17x and HY200-xxxx-xxx-x4



Connection of JVL and MAE motors (serial). Type MST23x/ MST34x and HY200-xxxx-xxx-x8




Connection of Zebotronics motor Type : SMxxx.x.xx.x (8 terminals)




Connection of MAE motor (unipol.) Type HY200-1xxx-xxxxx6

(Motor in unipolar model - 6 wires)



Connection of Zebotronics motor Type : SMxxx.x.xx.x (4 terminals)




TT005


12.4

Motor Connections


Connection of Vexta motor Type PH2xx.xxx



Connection of Phytron motor Type ZSx.xxx.x,x



Connection of Vexta stepper motor Type : PH2xx-xxx



TT0006

12.5

Serial communication

This section describes control of the SMC75 motor via the serial interface (RS232/RS485).

The communication is not made in ASCII values and it is thus not possible to use programs like Hyperterminal to control the motor.

The interface is RS232 compatible and uses 8 data bits and no parity.

The SMC75 motor is completely controlled by reading and writing to registers.

The registers are numbered 1-255. The width of the registers is 16 bits or 32 bits.

To protect communication from errors, the data is transmitted twice.

First the data byte is transmitted and then an inverted version (255-x) is transmitted.

The easiest way to become familiar with the registers and MacTalk communication is to use the MacRegIO program. This program lists all of the registers, and the serial commands sent and received can be monitored.

12.5.1 Supported commands

Sync	Response Sync	Description
0x50	0x52	Read register
0x51	0x52	Read register block
0x52	0x11 (Ack)	Write register
0x54	0x11 (Ack)	Enter safe mode
0x55	0x11 (Ack)	Exit safe mode
0x56	0x11 (Ack)	Write to flash
0x57	None	Reset controller
0x59	None	Group write register
0x61	0x61	Program status and command
0x62	0x11 (Ack)	Write program flash
0x63	0x63	Read program flash

12.5.2 Read register

This command can read a register. All registers are read as 32-bit. If the register is only 16-bit, the high part must be discarded.

Master sends	SMC75 Response
<Read><Address><RegNum><End>	<Write><MAddress><RegNum><Len><Data><End>

Block description

Block name	Protected	Example	Description
<Read>	No	50h,50h,50h	Read command
<Address>	Yes	07h,F8h (Address 7)	The address of the SMC75
<RegNum>	Yes	05h,FAh (RegNum 5)	The register number to read
<End>	No	AAh, AAh	Command termination
<Write>	No	52h,52h,52h	Write command
<MAddress>	Yes	00h,FFh (Address 0)	This will always be 0, because this is the address of the master
<RegNum>	Yes	05h,FAh (RegNum 5)	This will always be the same as requested
<Len>	Yes	04h,FBh (Len = 4)	The length will always be 4
<Data>	Yes	E8h,17h, 03h,FCh, 00h, FFh, 00h,FFh (Data = 1000)	The data read from the register
<End>	No	AAh, AAh	Command termination

12.5 Serial communication

12.5.3 Read register block

Using this command it is possible to read 64 consecutive registers at once.

Master sends	SMC75 Response
<ReadB><Address><RegNum><End>	<Write><MAddress><RegNum><Len><Data><End>

Block description

Block name	Protected	Example	Description
<ReadB>	No	51h,51h,51h	Read block command
<Address>	Yes	07h,F8h (Address 7)	The address of the SMC75
<RegNum>	Yes	05h,FAh (RegNum 5)	The first register to read
<End>	No	AAh, AAh	Command termination
<Write>	No	52h,52h,52h	Write command
<MAddress>	Yes	00h,FFh (Address 0)	This will always be 0, because this is the Address of the master
<RegNum>	Yes	05h,FAh (RegNum 5)	This will always be the same as requested
<Len>	Yes	80h,7Fh (Len = 128)	The length will always be 128, so 64 registers is read in each block.
<Data>	Yes	E8h,17h, ..., 03h,FCh	The data read from the registers

12.5.4 Write Register

Using this command, a register can be written.

Controller sends	SMC75 Response
<Write><Address><RegNum><Len><Data><End>	<Accept>

Block description

Block Name	Protected	Example	Description
<Write>	No	52h,52h,52h	Write command
<Address>	Yes	07h,F8h (Address 7)	The address of the SMC75
<RegNum>	Yes	05h,FAh (RegNum 5)	The register number to write to
<Len>	Yes	02h,FDh (Len = 2)	The number of data bytes
<Data>	Yes	E8h,17h, 03h,FCh (Data = 1000)	The data to write to the register
<End>	No	AAh, AAh	Command termination
<Accept>	No	11h, 11h,11h	Accept from SMC75

12.5.5 Enter safe mode

When this command is sent, the SMC75 switches to safe mode. In safe mode, no program or commands can enable the motor. The mode can only be exited using either an "Exit safe mode" or "Reset" command.

Controller sends	SMC75 response
<EntSafe><Address><End>	<Accept>

Block description

Block Name	Protected	Example	Description
<EntSafe>	No	54h,54h,54h	Enter safe mode command
<Address>	Yes	07h,F8h (Address 7)	The address of the SMC75
<End>	No	AAh, AAh	Command termination
<Accept>	No	11h, 11h,11h	Accept from SMC75

12.5 Serial communication

12.5.6 Exit safe mode

When this command is sent, the SMC75 switches back to normal mode.

Controller sends	SMC75 response
<ExitSafe><Address><End>	<Accept>

Block description

Block Name	Protected	Example	Description
<ExitSafe>	No	55h,55h,55h	Exit safe mode command
<Address>	Yes	07h,F8h (Address 7)	The address of the SMC75
<End>	No	AAh, AAh	Command termination
<Accept>	No	11h, 11h,11h	Accept from SMC75

12.5.7 Write to flash

This command writes the register values to flash memory. The values will then be retained after a power down. The command will only work if the motor is in "Safe mode" After the command is executed, the motor will reset. The response will only be transmitted if the command failed, e.g. if the motor is not in safe mode.

Controller sends	SMC75 response
<WriteFlash><Address><End>	<Accept>

Block description

Block Name	Protected	Example	Description
<WriteFlash>	No	56h,56h,56h	Write to flash command
<Address>	Yes	07h,F8h (Address 7)	The address of the SMC75
<End>	No	AAh, AAh	Command termination
<Accept>	No	11h, 11h,11h	Accept from SMC75

12.5.8 Reset controller

This command resets the SMC75. No response will be transmitted from the SMC75.

Controller sends	SMC75 response
<Reset><Address><End>	None

Block description

Block Name	Protected	Example	Description
<Reset>	No	57h,57h,57h	Reset command
<Address>	Yes	07h,F8h (Address 7)	The address of the SMC75
<End>	No	AAh, AAh	Command termination

12.5 Serial communication

12.5.9 Group write register

Using this command it is possible to write a register in several SMC75s with one command.

The command includes a sequence number which must be changed for each write. This is used so that the same command can be written several times, to ensure that all controllers received it. The last received sequence id can be read in register I48.

Controller sends	SMC75 Response
<GWrite><Group><Sequence><RegNum><Len><Data><End>	None

Block description

Block Name	Protected	Example	Description
<GWrite>	No	59h,59h,59h	Group write command
<Group>	Yes	07h,F8h (Address 7)	The group id of the SMC75s to write to.
<Sequence>	Yes	04h,FBh (Sequence 4)	The sequence number of the write.
<RegNum>	Yes	05h,FAh (RegNum 5)	The register number to write to
<Len>	Yes	02h,FDh (Len = 2)	The number of data bytes
<Data>	Yes	E8h,17h, 03h,FC h (Data = 1000)	The data to write to the register
<End>	No	AAh, AAh	Command termination

12.5.10 Program status and command

Using this command, different actions can be executed. The command also returns some information about the program state.

The table below shows the possible commands:

Com- mand	Data 1	Data 2	Description
0	-	-	No operation
1	-	-	Start program execution
2	-	-	Stop program execution
3	-	-	Pause program execution
4	Start Address (16bit)	End Address (16bit)	Run the program until the program pointer is outside the area [Start Address,End Address] Then the program is paused
5	Set outputs (8bit)	Clear outputs (8bit)	Modifies the outputs. The bits set in the "Set outputs" data will be set and cleared for "Clear outputs". Example: The data 0x06,0x01 sets output 2+3 and clears output 1
6			Reserved
7	Size (16 bit)		Prepare the flash for a new program. Data 1 specifies the size of the program in bytes.

The command number is placed in the first command data byte. Data 1 + Data 2 are placed in the following command data bytes.

Controller sends	SMC75 Response
<PStat><Address><Len1><Data1><End>	<PStat><MAddress><Len2><Data2><End>

12.5

Serial communication

Block description

Block Name	Protected	Example	Description
<PStat>	No	61h,61h,61h	Program status command
<Address>	Yes	07h,F8h (Address 7)	The address of the SMC75's to write to.
<Len1>	Yes	01h,FEh (Len = 1)	Length of the command data
<Data1>	Yes	01h,FEh (Start)	Command data
<MAAddress>	Yes	00h,FFh (Address 0)	This will always be 0, because this is the address of the master
<Len2>	Yes	08h,F7h (Len = 8)	The length of the return data
<Data2>	Yes	09h,F6h, (Program state) 00h,FFh, 00h,FFh, (Program pointer) 00h,FFh, (Stack pointer) 00h,FFh, 00h,FFh, (Program checksum) 80h,7Fh, (Inputs) 00h,FFh (Outputs)	Data returned from SMC75
<End>	No	AAh, AAh	Command termination

The returned data has the following format:

Data offset	Size	Description
0	8 bit	Program state. See table below for states.
1	16 bit	Program pointer. The current location of the program pointer.
3	8 bit	Stack pointer
4	16 bit	Program checksum. This checksum is calculated when the program is started.
6	8 bit	Input status.
7	8 bit	Output status

Program states:

Program state	Name	Description
0	Passive	The program execution is stopped. This state is only entered shortly at power-up.
1	Running	The program execution is running
2	Single Step	A single step is in progress. The program will run until the selected program position is reached.
3	Paused	The program execution is paused, but can be resumed again.
4	Stack Ovf.	The stack pointer has overflowed
5	Program Ovf.	The program pointer has overflowed.
6	Invalid Ins.	An invalid instruction is encountered in the program.
7	Stopped	The program execution is stopped.
8	Com. Error	Internal communication error has occurred. This cannot happen on SMC75.
9	Starting Prg.	Program execution is being prepared. After this is completed the state will change to running.
10	Flash Error	The program data is corrupted.
11	Flash Checksum Error	The program data checksum is incorrect.

12.6

MIS Ordering Information

Motor Type	Size	Generation	IP and shaft	Connection	Feedback	Driver Technology	Step Resolution	mA in driver	Input format	Standby current ratio	
MIS	232	A	I	M2	N0	73	8	10	E	3	Revision September 26, 2007
											01 to 31 Standby current ratio (03 = 1/3 standby current) #
											D 24V NPN inputs E 24V PNP inputs F 5V inputs
											xx xx specifies mA*100/phase. See SMD73 data-sheet
											0 No driver # 1 1/1 step (with 200step/rev motor 200 pulses/rev.) 2 1/2 step (with 200step/rev motor 400 pulses/rev.) 4 1/4 step (with 200step/rev motor 800 pulses/rev.) 5 1/5 step (with 200step/rev motor 1000 pulses/rev.) 8 1/8 step (with 200step/rev motor 1600 pulses/rev.)
											73 SMD73 driver 15-28VDC. Pulse and direction driver. (Only orders more than 10 pcs.)* 74 Driver 12-48VDC based on SMC75 technology (Future option) 75 SMC75 controller with MAC protocol. 12-48VDC and optional encoder/hall sensor feedback # 76 Controller based on SMD41 driver and SMC75 controller functionality. # 41 SMD41 driver technology 20-80VDC. Pulse and direction driver. Only MIS34x. (Future option) 42 SMD42 driver technology 30-160VDC. Pulse and direction driver. Only MIS34x. (Future option)
											N0 No feedback H1 Magnetic encoder feedback. 32 pulses/rev. Only if controller supports this feature (Future option) H2 Magnetic encoder feedback. 256x4 pulses/rec. Only if controller supports this feature E1 Encoder feedback. 1024 lines = 4096 pulses/rev. Only if controller supports this feature. (Future option)
											M1 M12 1 pcs. 5pin male . SMD73 pulse/direction driver. M2 M12 2 pcs. 5 pin male (power). 8 pin female (RS485, 4IOA) M3 M12 3 pcs. 5 pin male (power), 8 pin female (RS485, IOA 1-4), 5 pin female (RS485). SMC75 M4 M12 3 pcs. 5 pin male (power), 8 pin female (RS485, IOA 1-4), 8 pin female (5V serial, IOA5-8). SMC75 M5 M12 4 pcs. 5 pin male (power), 8 pin female (RS485, IOA 1-4), 5 pin female (RS485), 8 pin female (5V serial, IOA 5-8). SMC75 M6 M12 4 pcs. CANopen 5 pin male (power), 8 pin female (RS485, IOA 1-4), 8 pin female (5V serial, IOA 5-8), 5 pin male (CAN) SMC75 M7 M12 4 pcs. DeviceNet 5 pin male (power), 8 pin female (RS485, IOA 1-4), 8 pin female (5V serial, IOA 5-8), 5 pin male (Device) SMC75 W0 PG16 and no cable W1 PG16 and 2m cable. Flying leads with shield. EX Long hosing ready for MAC00-xx expansion board (Future option)
											1 6,35mm shaft and IP42 2 6,35mm shaft and IP55 (motor shaft and body). IP65 (Rear end and connector) 3 10,0 mm shaft and IP42 4 10,0mm shaft and IP55 (motor shaft and body). IP65 (Rear end and connector) 5 14mm shaft and IP42 6 14mm shaft and IP55 (motor shaft and body). IP65 (Rear end and connector) 7 8mm shaft 52mm long for HFOS worm gear
											A Motor driver for 3,0A/phase B Motor driver for 5,2A/phase (Future option)
											230 NEMA23 stepper motor 231 NEMA23 stepper motor 232 NEMA23 stepper motor 234 NEMA23 stepper motor 340 NEMA34 stepper motor (Future option) 341 NEMA34 step motor (Future option) 342 NEMA34 step motor (Future option)
											MIS MISxxx Motor Integrated Stepper Motor.
											Examples MIS 231A I W1 N0 73 8 25 D Motor 6,35 shaft, flying leads, SMD73 driver MIS 233A 3 M1 N0 73 2 30 D Motor 10mm shaft, M12 , SMD73 MIS 232A I M3 N0 75 Motor 6,35mm shaft. SMC75. 3 pcs M12 connectors MIS 234A 3 M6 N0 75 Motor 10mm shaft. SMC75. 4 pcs M12 connectors, CANopen MIS 232A I M7 H2 75 Motor 6,35mm shaft. SMC75. 4 pcs M12 connectors. DeviceNet. Encoder H2 option MIS 340B 5 M1 N0 41 Motor 14,0 mm shaft. 1 pcs M12 connector. 80V driver MIS 342B 5 M7 N0 76 Motor 14,0 mm shaft. 4 pcs M12 connectors. 80V controller. DeviceNet. Encoder H2 option
											# : End of number. No more letters or numbers should be added.
											*: For orders less than 10 pcs., use Controller SMC75 instead, allowing current and gear ratio to be freely programmed.

12.7 SMC75 Ordering Information

SMC75 selection chart

SMC Step motor controller				
75 Version 3ARMS 12-48VDC with 8IOA and optional CANopen/DeviceNet and encoder				
85 Version 12-160VDC with 8IOA and optional CANopen/DeviceNet and encoder				
A PCB 3ARMS (default)				
B PCB 6ARMS				
C PCB 9ARMS				
1 Hardware version 1. (default)				
2 Hardware version 2.				
M1 M12 2 pcs. 5 pin male (power), 8 pin female (RS485, 4IOA). SMC75				
M2 M12 2 pcs. 5 pin male (power), 8 pin female (RS485, 4IOA). SMC75				
M3 M12 3 pcs. 5 pin male (power), 8 pin female (RS485, IOA 1-4), 5 pin female (RS485). SMC75				
M4 M12 3 pcs. 5 pin male (power), 8 pin female (RS485, IOA 1-4), 8 pin female (5V serial, IOA5-8). SMC75				
M5 M12 4 pcs. 5 pin male (power), 8 pin female (RS485, IOA 1-4), 5 pin female (RS485), 8 pin female (5V serial, IOA 5-8). SMC75				
M6 M12 4 pcs. CANopen 5 pin male (power), 8 pin female (RS485, IOA 1-4), 8 pin female (5V serial, IOA 5-8), 5 pin male (CAN)				
M7 M12 4 pcs. DeviceNet 5 pin male (power), 8 pin female (RS485, IOA 1-4), 8 pin female (5V serial, IOA 5-8), 5 pin male (DeviceNet)				
SMC75				
W1 PG16 and 2m cable. Flying leads with shield.				
AA No fieldbus (default). Only PCB				
AC Fieldbus CANopen. Only PCB				
AD Fieldbus DeviceNet. Only PCB				
H1 Magnetic encoder chip 1.				
H2 Magnetic encoder chip2 mounted 256x4=1024 counts (AS5040)				
SMC75	A	1	M4	H1

Examples

SMC 75	A	1			Steppermotor controller only PCB. No housing and encoder chip
SMC 75	A	1	AC		Steppermotor controller only PCB, CANopen. No housing and encoder chip
SMC 75	A	1	AA	H2	Stepper motor controller only PCB with magnetic encoder chip type H2 mounted. No housing
SMC 75	A	1	AC	H2	Stepper motor controller only PCB with Fieldbus CANopen and magnetic encoder chip type H2 mounted. No housing
SMC 75	A	1	M7		Stepper motor controller in a box with connector M7 and CANopen and DeviceNet
SMC 75	A	1	M6	H1	Stepper motor controller in a box with connector M7 and CANopen and H1 magnetic sensor

12.7

SMC75 Ordering Information

QuickStep MST motor selection chart					
MST Stepper motor with housing but without electronics. IP55					
					230 NEMA23 Stepper motor
					231 NEMA23 Stepper motor
					232 NEMA23 Stepper motor
					234 NEMA23 Stepper motor
					340 NEMA23 Stepper motor. (Future option)
					341 NEMA23 Stepper motor .(Future option)
					342 NEMA23 Stepper motor .(Future option)
				A	For 3Amp. driver/controller
				B	For 6 Amp. driver/controller
				C	For 9 or 12 Amp. driver/controller
					1 6.35mm shaft and IP42
					2 6.35mm shaft and IP55 (motor shaft and body) IP65 /Rear end and connector)
					3 10.0mm shaft and IP42
					4 10.0mm shaft and IP55 (motor shaft and body) IP65 /Rear end and connector)
					5 14mm shaft and IP42
					6 14mm shaft and IP55 (motor shaft and body) IP65 Rear end and connector)
				B	Motor type
					M1 m12 connector
					W0 PG16 and no cable
					W1 PG16 and 2m cable
MST	232	A	1	3	M1

Examples

- MST 232 A 1 3 M1 Stepper motor NEMA23 with housing
- MST 234 A 3 3 M1 Stepper motor NEMA23 with housing
- MST 340 B 5 3 W1 Stepper motor NEMA34 with housing

13

MIS Motor Technical Data

Supply Voltage (P+)	Voltage Range	+ 12 to 48VDC		
	Ampere (no motor) 5mA	Power supply current requirements = 2A (max.). Refer to illustration. Actual power supply currents will depend on voltage and load		
Control Voltage (CV)	Range	+ 12 to + 28VDC maintains power to control output driver and feed-back circuits (only) when input voltage is removed. If no motor connected or passive mode: 100mA.		
Analog Input	Resolution	10 Bit		
	Voltage Range	0 to +5VDC		
General Purpose I/O	Number/Type	8 Sources of output or input		
	Logic Range	Inputs and Outputs tolerant to +24VDC. Inputs TTL level compatible		
	Output Source Current	Up to 350 mA per Channel. See Chart section 2.5		
	Protection	Over Temp. Short Circuit. Transient. Over Voltage. Inductive Clamp.		
	Input Filter	0.1 or 1 to 100 ms		
Communication	Type (Standard)	RS485		
	Type (Optional)	RS422		
	Baud Rate	9.6 to 921.6 kbps		
	Type (Optional)	CANopen DSP402 (V2.0), DS301 (VS3.0), 2.0B Active		
	Isolation	None		
	Features	Node Guarding, heartbeat, SDOs, PDOs (Static mapping)		
Motion	Open Loop Configuration	Number of settings	2	
		Steps per revolution	1600	
	Internal Encoder (optional)	Type	Internal, magnetic, absolute 1 rev.	
		Steps per Revolution	1024	
		Resolution	256 Lines	
	Counters	Type	Position, Encoder/32 Bit	
		Edge Rate (Max.)	27.280 kHz	
	Velocity	Range	1.43 to 1023 RPM	
		Resolution	1 RPM	
	Accel./Decel.	Range	3x10 ⁵ RPM/s	
Resolution		9.54 RPM/s		
Electronic Gearing	Range/Resolution/Threshold (External Clock In)	0.00003 to 32768/32 Bit		
Software	Program Storage	Type/Size	Flash 3072 Bytes	
	User Registers	2248 Bytes/32 bits		
	User program variables	Up to 224		
	Math Functions	+, -, x, /, >, <, =, <=, >=, AND, OR, XOR, NOT, !, &, ^ .		
	Branch Functions	Branch & Call		
	General Purpose I/O Functions	Inputs	Home, Limit Plus, Limit Minus, Analog In, General Purpose	
		Outputs	Moving, Fault, general Purpose	
	Party Mode Addresses	254		
Encoder Functions	Stall Detection, Position maintenance, Find Index			
Thermal	Operating Temperature	0-45°C ambient		


13.1

SMC75 Technical Data

Power supply	Condition	Min.	Norm.	Max.	Unit
P+ - P-		12		48	V
PP supply current (No load)	@ 24V @ 48 V		125 100		mA (RMS)
CV		7		35	V
CV supply current (Unconnected I/O)	@12V @24V		160 90		mA mA
V+ for CAN		4.5	5	5.5	V
V+ supply current for CAN				1	mA
User outputs O1-O8					
Output source current pr. channel	CV = 35V @ 8 sourcing @ 4 sourcing @ 1 sourcing			75 100 350	mA mA mA
Output sink current				0	mA
Output voltage	@ 100mA	CV - 2.4	CV - 2.2		V
User inputs I1-I8					
Input impedance			10		kOhm
Voltage applied to any input		-0.5		22	V
Analog input nominal		0		5.0	V
Logic "0"		0		0.9	V
Logic "1"		1.9		22	V
RS232 (5V)					
Tx output low level			0.45	1	V
Tx output high level		4	4.55		V
Tx output source current				1	mA
Tx output sink current				1	mA
Rx input low level		-0.5		0.9	V
Rx input high level		1.9		48	V
RS422					
Input ($V_{BI+} - V_{BI-}$)		± 0.2		± 6	V
Input leakage current			0.7	1	mA
Output ($V_{AI+} - V_{AI-}$)	@ 50 ohm	± 1.1	± 2.2	± 5.0	V
Output source current				60	mA
RS485					
Input ($V_A - V_B$)		± 0.2		± 12	V
Input leakage current			0.7	1	mA
Output ($V_A - V_B$)	@ 50 ohm	± 1.5	± 2.5	± 5.0	V
Output source current				60	mA
CAN (ISO 11898-24V)					
Voltage at any input		-36		36	V
Input ($V_{CAN H} - V_{CAN L}$)	Dominant	0.9		5	V
Input ($V_{CAN H} - V_{CAN L}$)	Recessive	-1.0		0.5	V
Output ($V_{CAN H} - V_{CAN L}$)	Dominant	1.5		3.0	V
Output ($V_{CAN H} - V_{CAN L}$)	Recessive	-500		50	mV

13.2


Torque Curves



13.3

Physical Dimensions

13.3.1 Physical dimensions MIS231, MIS232 and MIS234



13.4

Trouble-shooting guide

13.4.1 Problems related to communication with the motor

Problem : “RS232 - MacTalk is not communicating with the motor”

The status at the bottom of the screen shows “*** No Connection ***” but the power LED on the motor is lit and the serial cable is connected.

Action :

- Check that the correct COM port is selected in the MacTalk “Setup” menu.
- Check using Control Panel/System/Hardware/Device Manager/Ports (COM&LPT).
- Check that the connection to the motor is made according to specifications. If only one motor is used on the RS232 bus, TX-PD must be shorted to TX, otherwise communication can be very unstable.
- Ensure that a firmware update has not been interrupted before the communication problem was observed. If such an update is aborted/interrupted, it must be restarted and completed before the internal processor is back to normal and can handle communication.

14 Connection to other Equipment

The SMC75 can be connected to other JVL products. These connections are described in the following chapter.

14.1 Connecting SMI30/SMC35 to MIS/SMC75


The SMI3x or the SMC35B can control the MIS/SMC75 in gear mode.

To do this, some parameters in both the SMI3x and SMC35B must be set up correctly.

In the SMI3x, the definition of the number of pulses pr. revolution, PR, can be selected freely. So normally it is recommended to set PR=1600. The SMI3x has inputs from external drivers for alarm and in Position signals. If these are not connected, set CBI5=0 and CBI6=0.

The SMC75 must also be configured correctly. The mode must be set to Gear Mode (Reg. 2 = 3). If gear factor input=1 and gear factor output=1, then the motor will run at 100 rpm if velocity=100 in the SMI3x/SMC35B.

The connection between the SMI3x Indexer or SMC35B Controller should be made according to the following diagram:



The Controller SMC75 must be set to gear mode and the input and output for gear factor must be adjusted according to the actual application.

14.2 Connecting SMC75 to SMD73

14.3 Connecting SMC75 to SMD41

14.4 Connecting SMC75 to MAC00B1/B4

14.5 Connection to PLC/PC Boards

The following accessories are available for the MIS motor series.

15.2

Power Supplies

15.2.1 PSU00-PD1

Combined power dump, resistor, and capacitor unit. For a complete power supply system, only a transformer with a secondary winding supplying 32VAC is required.

For systems with up to 5-8 QuickStep motors, this unit can serve as a central power dump unit.

The capacitor offers an efficient and economical way of storing the energy returned from the motors during deceleration of high inertias. See also www.jvl.dk

15.2.2 PSU48-240

A compact switch-mode power supply with 240W output power at 48VDC.

The power supply is UL and CSA approved. It is protected against overvoltage, overtemperature and short-circuit or overload of the output. The power supply can either be mounted on a DIN rail or "wall" mounted. See also the data-sheet LD0047 which can be downloaded from www.jvl.dk

15.2.3 Other power supplies

JVL offers a wide range of power supplies in the power range 45W to 1.5kW with output voltages 24 and 48VDC. They all use switch-mode technology in order to minimize physical dimensions and for easy adaptation to mains voltages in the range 90 to 240VAC.

The product range covers the following types: PSU05-045, PSU24-075, PSU24-240, PSU48-240, PSU48-800, PSU48-1000, PSU48-1500.

See also the data-sheet LD0058 (overview) or LD0053 (detailed) which can be downloaded from www.jvl.dk.

15.3 Brakes and shaft reinforcement

2 brake units are available for the MAC50-141 motors. The MAB23x-01 offers a 10mm output shaft and MAB23x-02 offers a 6.35mm output shaft. Both types can be mounted directly on all the MAC50-141 motors and require 24VDC applied to release the motor

No brakes are available for the MAC400 and 800 since they are constructed with an integrated brake which is a part of the order number for the complete motor.

See also the data-sheet LD0055-xx which can be downloaded from www.jvl.dk.

16 CE Declaration of Conformity



Index

A

A_SOLL 73, 103–107, 138
Abort SDO 153
Acc_Emerg 77
Acceleration factor 145
Address, CANopen 125
Address, MacTalk 45
Afzup_ConfMax 81
Afzup_ConfMin 81
Afzup_Filter 82
Afzup_MaxSlope 82
Afzup_ReadIndex 81
Afzup_WriteBits 81
An 79
Analog input filters 25
AnalogFiltered 80
AnalogIn 80
Analogue inputs 24
Auto correction 32
Available_IO 90

B

Baud rate 38, 76, 88, 127, 162, 173
Binary command 117
Bipolar motors 34
Boot up telegram 149
Bootloader_Ver 90
Brakes and shaft reinforcement 188
Busvol 80

C

Cables 186
Cabling 33, 126
Calculator (basic) 118
Calculator (options) 119
CAN A 125
CAN B 125
CAN bus connectors 128
CANbus 39
CANopen 11, 14, 39, 67, 91, 121–158, 162
 CAN bus connectors 128
 CanOpen Explorer 127, 130–134
 Communication test 130
 Connecting the SMC75 Controller to the CAN bus 126
 DS-301 122
 DS-301 device profiles 148
 DSP-402 122
 Node id and baud rate 127
 PDOs 122
 slave 122

CanOpen 70
CANopen network 122
Capacitor 17
CE requirements 33, 189
Checksum 89
CiA DS-301 standard 122
CiA membership 122
Clear errors 45
COB-ID 125, 138
Command 76
Command timing 161
Conditional jump (multiple inputs) 110
Conditional jump (single input) 109
Confidence alarms 26
Confidence check 25
Connecting the SMC75 Controller to the CAN bus 126
Connection of motor 34–35
Connection of motor phases 35
Connections
 Driver 7
 M12 7
 MIS23x 13
 Motor 34
 SMC75 12
Connectors 129
 M12 129
Control voltage 17
Current, motor phase current 51
CVI control voltage 17

D

Declaration of Conformity 189
Digital inputs 23
Dimensions 176
Direction inputs 22
Download SDO 151
Driver connections 7
DS-301 122, 135
DS301 specified Communications objects 135
DSP 402 70
DSP-402 122
DSP-402 Support 141

E

EDS file 126
EMCY 136
Emergency object 136
Enable and Disable PDOs 137
Encoder outputs 31
Encoder_Pos 75

Index

- Encoder_Type 80
- End-of-travel inputs 22
- Enter safe mode 166
- Err_Bits 29, 78
- Error acceleration 63
- Error Control Services 156
- Error handling 63
- Error output 30
- Error_Mask 87
- Errors, clearing 45
- Exit safe mode 167
- Ext_Encoder 91
- Ext_Encoder_Vel 91
- F**
- Factors 144
- Fbus_Baud 91
- Fbus_Node Id 91
- Filtering 25
- Filters 36, 45
- Filters, analog input 25
- FilterStatus 82
- Flash 45
- Flwerr 76
- Flwerrmax 76
- Follow error 63
- Fuse dimensioning 17
- G**
- Galvanic isolation 21, 24, 29
- Gear mode 57
- GEAR1 10, 53, 72, 75
- GEAR2 10, 53, 72, 75
- GND 129
- Ground 21
- Grounding 129
- Grounding, power supply 17
- Group write register 168
- Group_Id 88
- Group_Seq 89
- H**
- Hardware_Rev 90
- Heartbeat 156–157
- Home input 23
- Home sensor 60
- Home_Bits 84
- Homemode 79
- Homing mode 146
- I**
- In physical position output 30
- In position output 30
- Index_Offset 84
- Indexer SMI30 183
- Inpos_Mask 87
- Input_Filter_Cnt 87
- Input_Filter_Mask 87
- Inputs 76
 - Analogue 24
 - Digital 23
 - End-of-travel 22
 - Home 23
 - SMC75 20
 - Step pulse and direction 22
 - User inputs 21
- Interface
 - RS485 41
 - Serial 39
- Isetup 76, 85
- IP67 129
- J**
- Jump 109
- Jump according to a comparison 120
- Jump according to a register in the MAC motor 113
- Jumps 109–110, 113, 120
- L**
- Life Guarding 156
- M**
- M12 129
- M12 connector 7
- MAB23x-01 188
- MAB23x-02 188
- MAC00-B1/B4 182
- MacTalk 43–49
- Main Loop Time 162
- Max_P_Ist 77
- Max_Voltage 90
- Min bus voltage 63
- Min_Busvol 80
- Min_P_Ist 77
- Ministeps 11
- MIS23x connections 13
- MLT 162
- MODE_REG 138
- Mode_Reg 23, 71, 133, 138
- Modes of operation 10, 53, 102, 146
 - Gear mode 57
 - Passive mode 54
 - Positioning mode 56
 - Velocity mode 55
 - Zero search mode 58–62
- Motor Connection 34–35
- Motor Connections 163

Index

- Motor phase current 51
- Motor Phases 34
- Motortype 89
- Move (Absolute) 106
- Move (Relative + set outputs) 105
- Move (Relative + velocity change at a distance) 104
- Move (Relative) 103
- Move (Sensor) 107
- Move current 51
- Move operations 102
- Multi-Master capability 124
- My_Addr 89
- N**
- Negative limit 22
- NL, negative limit 22
- NL_Mask 86
- NMT (Network Management services) 155
- Node address 125
- Node Guarding/Life Guarding 156
- Node id 127
- Noise 33
- Noise emission 33
- No-loss bus arbitration 124
- Notsaved 90
- NPN output 21
- O**
- Object dictionary 137
- Object dictionary defined for DSP-402 support 142
- Opening a file 45
- Operating modes 10, 53–62, 102, 146
- Optical isolation 21, 24, 29
- Option_Bits 91
- Ordering Information 170
- Outputs 76
 - Encoder 31
 - Error output 30
 - In position 30
 - In physical position 30
 - Pulse/Direction 31
 - SMC75 special outputs 30
 - SMC75 user outputs 28
- P**
- P- terminal 17
- P+ terminal 17
- P_Home 78
- P_Ist 74, 76, 88, 139
- P_New 79, 88
- P_Soll 10, 32, 53, 119, 138
- Parallel connection of motor phases 34–35
- Parallel connection of motors 35
- Passive mode 54
- PDOs 122, 137, 139, 147, 150–151
- Phase current 51
- Phases 34
- PL, positive limit 22
- PLC systems 30
- PLC/PC 184
- Pn 79
- PNP 22
- PNP output 21
- Position factor 144
- Position limit min and max 63
- Position mode 10
- Positioning mode 56
- Positioning-Speed Control 8–9
- Positive limit 22
- Power Supplies 187
- Power Supply
 - Capacitor 17
- Power supply
 - Grounding 17
- Power supply, SMC75 17
- Profile position mode 146
- Prog_Vers 71
- Program comments 102
- Program jumps 109–110, 113, 120
- Program status and command 168
- Programming 93–120
- PSU05-045 187
- PSU24-075 187
- PSU24-240 187
- PSU48-1000 187
- PSU48-1500 187
- PSU48-240 187
- PSU48-800 187
- Pull-up resistor 21
- Pulse/Direction driver 6
- Pulse/direction outputs 31
- PulseDirMask 82
- PulseDirMod 83
- Q**
- Quick start 38
- QuickStep motors 10
- R**
- Read register 165
- Read register block 166
- Receive PDOs 137, 147
- Register overview 67

Index

- Registers 65–91
 - A_Soll 73, 103–107, 138
 - Acc_Emerg 77
 - Afzup_ConfMax 81
 - Afzup_ConfMin 81
 - Afzup_MaxSlope 82
 - Afzup_ReadIndex 81
 - Afzup_WriteBits 81
 - An 79
 - AnalogFiltered 80
 - AnalogIn 80
 - Available_IO 90
 - Bootloader_Ver 90
 - Busvol 80
 - Checksum 89
 - Command 76
 - Encoder_Pos 75
 - Encoder_Type 80
 - Err_Bits 29, 78
 - Error_Mask 87
 - Ext_Encoder 91
 - Ext_Encoder_Vel 91
 - Fbus_Baud 91
 - Fbus_NodeId 91
 - FilterStatus 82
 - Flwerr 76
 - Flwerrmax 76
 - GEAR1 10, 53, 72, 75
 - GEAR2 10, 53, 72, 75
 - Group_Id 88
 - Group_Seq 89
 - Hardware_Rev 90
 - Home_Bits 84
 - Homemode 79
 - Index_Offset 84
 - Inpos_Mask 87
 - Input_Filter_Cnt 87
 - Input_Filter_Mask 87
 - Inputs 76
 - losetup 76, 85
 - Max_P_Ist 77
 - Max_Voltage 90
 - Min_Busvol 80
 - Min_P_Ist 77
 - Mode_Reg 23, 71, 133, 138
 - Motortype 89
 - My_Addr 89
 - NL_Mask 86
 - Notsaved 90
 - Option_Bits 91
 - Outputs 76
 - P_Home 78
 - P_Ist 74, 76, 88, 139
 - P_New 79, 88
 - P_Soll 10, 32, 53, 119, 138
 - Pn 79
 - Prog_vers 71
 - PulseDirMask 82
 - PulseDirMod 83
 - Register descriptions 71–91
 - Register overview 67–70
 - Run_Current 73, 138
 - Serial_Number 89
 - Setup_Bits 85, 91
 - Standby_Current 74
 - Standby_Time 73
 - Startmode 78
 - Statusbits 32, 77
 - Temp 77
 - Tn 80
 - Turntable_Mode 85
 - V_Home 79
 - V_Ist 74, 139
 - V_Soll 10, 53, 73, 103–107, 116, 133, 138, 160
 - V_Start 71–72, 75
 - Vn 79
- Remarks 102
- Reset controller 167
- Reset motor 45
- Reset position 45
- Resistors, termination 36
- Resonances 11
- RS232/RS485 165
- RS485 interface 39, 41
- Run_Current 73, 138
- S**
- Save in flash 45
- Save position 114
- Saving a file 45
- Scope function 49
- Screened cable 33
- SDO (Service Data Objects) 151
- Send FastMAC command 116–117
- Serial communication 165
- Serial connection of motor phases 34–35

Index

- Serial connection of motors 35
- Serial interface 39
- Serial_Number 89
- Set a register in the MIS motor 113
- Set operation mode 102
- Set outputs 108
- Set position 115
- Setup_Bits 85, 91
- Short block length 124
- Slope alarms 26
- Slope limitation 25
- SMC35 180
- SMC35B 180
- SMC75 8–9, 11, 180–182
 - CANopen slave 122
 - Inputs 20
 - User inputs 21
- SMC75 analogue inputs 24
- SMC75 connector 12
- SMC75 Power Supply 17
- SMC75 special outputs 30
- SMC75 user outputs 28
- SMD41 182
- SMD73 181–182
 - Pulse/Direction driver 7
- SMI30 180, 183
- Special outputs, SMC75 30
- Specifications 173–176
- Standby current 51
- Standby time 51
- Standby_Current 74
- Standby_Time 73
- Startmode 78
- Statusbits 32, 77
- Step pulse and direction inputs 22
- Step pulse inputs 22
- SYNC (Synchronisation Object) 154
- T**
- Technical Data 173–176
- Temp 77
- Temperature protection 30
- Termination 126, 128
- Termination resistors 36
- Tn 80
- Torque 35, 51
- Transmit PDOs 139, 147
- Trouble-shooting 177
- Turntable_Mode 85
- U**
- Unconditional jump 109
- Unipolar Motors 34
- Upload SDO protocol 152
- User inputs, SMC75 21
- User outputs 28
- V**
- V 116
- V_Home 79
- V_Ist 74, 139
- V_Soll 10, 53, 73, 103–107, 116, 133, 138, 160
- V_Start 71–72, 75
- Velocity accuracy 160
- Velocity encoder factor 145
- Velocity mode 10, 55, 146
- Vn 79
- Voltage Overload 24
- W**
- Wait for (x) ms before continuing 111
- Wait for a register value before continuing 114
- Wait for an input combination before continuing (multiple inputs) 112
- Wait for an input combination before continuing (single input) 111
- Write Register 166
- Write to flash 167
- Z**
- Zero search 115
- Zero search mode 58–62